



2010

LS 460 / LS 460 L

OWNER'S MANUAL

## TABLE OF CONTENTS

|          |                               |                                                                                                             |
|----------|-------------------------------|-------------------------------------------------------------------------------------------------------------|
| <b>1</b> | <b>Before driving</b>         | Adjusting and operating features such as door locks, mirrors, and steering column                           |
| <b>2</b> | <b>When driving</b>           | Driving, stopping and safe-driving information                                                              |
| <b>3</b> | <b>Interior features</b>      | Air conditioning and audio systems, as well as other interior features for a comfortable driving experience |
| <b>4</b> | <b>Maintenance and care</b>   | Cleaning and protecting your vehicle, performing do-it-yourself maintenance, and maintenance information    |
| <b>5</b> | <b>When trouble arises</b>    | What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident                |
| <b>6</b> | <b>Vehicle specifications</b> | Detailed vehicle information                                                                                |
| <b>7</b> | <b>For owners</b>             | Reporting safety defects for U.S. owners and seat belt instructions for Canadian owners                     |
|          | <b>Index</b>                  | Alphabetical listing of information contained in this manual                                                |

|             |                                                               |     |
|-------------|---------------------------------------------------------------|-----|
| <b>1</b>    | <b>Before driving</b>                                         |     |
| <b>1-1.</b> | <b>Key information</b>                                        |     |
|             | Keys .....                                                    | 32  |
| <b>1-2.</b> | <b>Opening, closing and locking the doors and trunk</b>       |     |
|             | Smart access system with push-button start .....              | 36  |
|             | Wireless remote control .....                                 | 50  |
|             | Doors.....                                                    | 53  |
|             | Trunk.....                                                    | 58  |
| <b>1-3.</b> | <b>Adjustable components (seats, mirrors, steering wheel)</b> |     |
|             | Front seats .....                                             | 65  |
|             | Power rear seat.....                                          | 71  |
|             | Driving position memory .....                                 | 81  |
|             | Rear seat position memory .....                               | 87  |
|             | Head restraints.....                                          | 89  |
|             | Seat belts .....                                              | 92  |
|             | Steering wheel.....                                           | 99  |
|             | Anti-glare inside rear view mirror .....                      | 100 |
|             | Outside rear view mirrors .....                               | 101 |
| <b>1-4.</b> | <b>Opening and closing the windows and moon roof</b>          |     |
|             | Power windows.....                                            | 103 |
|             | Moon roof .....                                               | 105 |
| <b>1-5.</b> | <b>Refueling</b>                                              |     |
|             | Opening the fuel tank cap.....                                | 109 |
| <b>1-6.</b> | <b>Theft deterrent system</b>                                 |     |
|             | Engine immobilizer system.....                                | 112 |
|             | Alarm.....                                                    | 114 |
| <b>1-7.</b> | <b>Safety information</b>                                     |     |
|             | Correct driving posture .....                                 | 117 |
|             | SRS airbags .....                                             | 119 |
|             | Front passenger occupant classification system.....           | 132 |
|             | Child restraint systems .....                                 | 137 |
|             | Installing child restraints.....                              | 142 |

## 2 When driving

### 2-1. Driving procedures

|                                                                    |     |
|--------------------------------------------------------------------|-----|
| Driving the vehicle .....                                          | 152 |
| Engine (ignition) switch .....                                     | 161 |
| Automatic Transmission<br>(without paddle shift<br>switches) ..... | 165 |
| Automatic Transmission<br>(with paddle shift switches) ....        | 169 |
| Turn signal lever .....                                            | 176 |
| Parking brake .....                                                | 177 |
| Brake Hold.....                                                    | 180 |
| Horn.....                                                          | 182 |

### 2-2. Instrument cluster

|                                       |     |
|---------------------------------------|-----|
| Gauges and meters .....               | 183 |
| Indicators and warning<br>lights..... | 186 |
| Multi-information display.....        | 190 |

### 2-3. Operating the lights and windshield wipers

|                                      |     |
|--------------------------------------|-----|
| Headlight switch.....                | 195 |
| Automatic High Beam .....            | 198 |
| Fog light switch .....               | 203 |
| Windshield wipers and<br>washer..... | 204 |
| Headlight cleaner switch .....       | 207 |

### 2-4. Using other driving systems

|                                                  |     |
|--------------------------------------------------|-----|
| Cruise control .....                             | 208 |
| Dynamic radar cruise<br>control.....             | 212 |
| Intuitive parking assist .....                   | 223 |
| LKA (Lane-Keeping Assist) ....                   | 232 |
| Electronically modulated air<br>suspension ..... | 239 |
| Rear view monitor system .....                   | 241 |
| Advanced parking guidance<br>system .....        | 244 |
| Driving assist systems.....                      | 285 |
| Pre-Collision System.....                        | 291 |

### 2-5. Driving information

|                           |     |
|---------------------------|-----|
| Cargo and luggage.....    | 300 |
| Vehicle load limits.....  | 303 |
| Winter driving tips ..... | 305 |
| Trailer towing.....       | 309 |
| Dinghy towing .....       | 310 |

1

2

3

4

5

6

7

### 3 Interior features

#### 3-1. Using the touch screen

|                                                           |     |
|-----------------------------------------------------------|-----|
| Touch screen .....                                        | 314 |
| Set up screen<br>(without navigation<br>system).....      | 321 |
| Information screen<br>(without navigation<br>system)..... | 326 |

#### 3-2. Using the air conditioning system and defogger

|                                                                |     |
|----------------------------------------------------------------|-----|
| Front air conditioning system<br>(without touch screen).....   | 328 |
| Front air conditioning system<br>(with touch screen).....      | 337 |
| Rear air conditioning<br>system .....                          | 351 |
| Rear window and<br>outside rear view<br>mirror defoggers ..... | 359 |
| Windshield wiper de-icer .....                                 | 361 |

#### 3-3. Using the audio system

|                                             |     |
|---------------------------------------------|-----|
| Audio system<br>(without touch screen)..... | 363 |
| Using the radio .....                       | 365 |
| Using the CD player .....                   | 369 |
| Playing back MP3 and<br>WMA discs .....     | 375 |
| Optimal use of the audio<br>system .....    | 381 |

|                             |     |
|-----------------------------|-----|
| Using the AUX adapter ..... | 383 |
|-----------------------------|-----|

|                                                  |     |
|--------------------------------------------------|-----|
| Using the steering wheel<br>audio switches ..... | 384 |
|--------------------------------------------------|-----|

|                                                                        |     |
|------------------------------------------------------------------------|-----|
| Audio system type<br>(touch screen without<br>navigation system) ..... | 386 |
|------------------------------------------------------------------------|-----|

|                       |     |
|-----------------------|-----|
| Using the radio ..... | 390 |
|-----------------------|-----|

|                              |     |
|------------------------------|-----|
| Using the CD/DVD player..... | 399 |
|------------------------------|-----|

|                                                |     |
|------------------------------------------------|-----|
| Playing an audio CD and<br>MP3/WMA discs ..... | 402 |
|------------------------------------------------|-----|

|                               |     |
|-------------------------------|-----|
| Playing DVD video/audio ..... | 407 |
|-------------------------------|-----|

|                          |     |
|--------------------------|-----|
| Playing a video CD ..... | 420 |
|--------------------------|-----|

|                                                       |     |
|-------------------------------------------------------|-----|
| CD/DVD player and DVD<br>video disc information ..... | 424 |
|-------------------------------------------------------|-----|

|                                        |     |
|----------------------------------------|-----|
| Listening to Bluetooth®<br>audio ..... | 434 |
|----------------------------------------|-----|

|                                           |     |
|-------------------------------------------|-----|
| Listening to a USB memory/<br>iPod® ..... | 446 |
|-------------------------------------------|-----|

|                                                 |     |
|-------------------------------------------------|-----|
| Optimal use of the audio/<br>video system ..... | 456 |
|-------------------------------------------------|-----|

|                             |     |
|-----------------------------|-----|
| Using the AUX adapter ..... | 458 |
|-----------------------------|-----|

|                                             |     |
|---------------------------------------------|-----|
| Using the rear seat audio<br>controls ..... | 459 |
|---------------------------------------------|-----|

|                                                  |     |
|--------------------------------------------------|-----|
| Using the steering wheel<br>audio switches ..... | 464 |
|--------------------------------------------------|-----|

#### 3-4. Using the rear seat entertainment system

|                                                                                 |     |
|---------------------------------------------------------------------------------|-----|
| Rear seat entertainment<br>system features (without<br>navigation system) ..... | 468 |
|---------------------------------------------------------------------------------|-----|

|                       |     |
|-----------------------|-----|
| Using the radio ..... | 477 |
|-----------------------|-----|

|                                 |     |
|---------------------------------|-----|
| Using the front DVD player..... | 478 |
|---------------------------------|-----|

|                                |     |
|--------------------------------|-----|
| Using the rear DVD player..... | 479 |
|--------------------------------|-----|

Playing an audio CD and  
MP3/WMA discs..... 482

Playing a DVD video/  
audio..... 483

Playing a video CD ..... 493

DVD player and DVD video  
disc information ..... 497

Using the video mode ..... 499

Changing other setting..... 501

### 3-5. Using the hands-free system (for cellular phone)

Hands-free system  
(for cellular phone)  
(without navigation  
system)..... 503

Using the Bluetooth®  
phone ..... 509

Setting the hands-free  
system ..... 523

### 3-6. Using the interior lights

Interior lights list..... 552

• Interior lights ..... 553

• Personal lights ..... 554

### 3-7. Using the storage features

List of storage features..... 556

• Glove box ..... 558

• Coin holder..... 559

• Door pockets ..... 559

• Cup holders..... 560

• Console box..... 562

• Non smokers boxes ..... 563

• Cool box/auxiliary box..... 564

• Auxiliary boxes ..... 568

### 3-8. Other interior features

Sun visors..... 570

Vanity mirrors..... 571

Clock..... 572

Outside temperature  
display ..... 574

Ashtrays ..... 575

Cigarette lighters..... 576

Power outlets..... 578

Heated steering wheel ..... 581

Climate control seats/  
seat heaters ..... 583

Armrest (5-seat models)..... 587

Retractable table  
(4-seat models)..... 588

Rear sunshade..... 590

Rear door sunshades..... 593

Trunk storage extension ..... 596

Coat hooks ..... 598

Floor mat..... 599

Trunk features..... 600

Garage door opener..... 602

Compass ..... 608

Safety Connect ..... 612

**4 Maintenance and care****4-1. Maintenance and care**

|                                                       |     |
|-------------------------------------------------------|-----|
| Cleaning and protecting<br>the vehicle exterior.....  | 620 |
| Cleaning and protecting<br>the vehicle interior ..... | 623 |

**4-2. Maintenance**

|                                                                |     |
|----------------------------------------------------------------|-----|
| Maintenance requirements .....                                 | 626 |
| General maintenance .....                                      | 628 |
| Emission inspection and<br>maintenance (I/M)<br>programs ..... | 631 |

**4-3. Do-it-yourself maintenance**

|                                             |     |
|---------------------------------------------|-----|
| Do-it-yourself service<br>precautions ..... | 632 |
| Hood.....                                   | 635 |
| Positioning a floor jack.....               | 636 |
| Engine compartment.....                     | 638 |
| Tires .....                                 | 654 |
| Tire inflation pressure .....               | 662 |
| Wheels.....                                 | 666 |
| Air conditioning filter.....                | 668 |
| Electronic key battery .....                | 671 |
| Checking and replacing<br>fuses .....       | 673 |
| Headlight aim.....                          | 678 |
| Light bulbs .....                           | 680 |

**5 When trouble arises****5-1. Essential information**

|                                           |     |
|-------------------------------------------|-----|
| Emergency flashers.....                   | 692 |
| If your vehicle needs to be<br>towed..... | 693 |
| If you think something is<br>wrong .....  | 699 |
| Fuel pump shut off system .....           | 700 |
| Event data recorder .....                 | 701 |

**5-2. Steps to take in an emergency**

|                                                                    |     |
|--------------------------------------------------------------------|-----|
| If a warning light turns on<br>or a warning buzzer<br>sounds... .. | 703 |
| If a warning message is<br>displayed.....                          | 712 |
| If you have a flat tire.....                                       | 715 |
| If the engine will not start .....                                 | 723 |
| If the shift lever cannot be<br>shifted from "P" .....             | 725 |
| If the parking brake cannot<br>be released .....                   | 726 |
| If the electronic key does<br>not operate properly .....           | 728 |
| If the vehicle battery is<br>discharged .....                      | 732 |
| If your vehicle overheats .....                                    | 735 |
| If the vehicle becomes<br>stuck.....                               | 738 |

## 6 Vehicle specifications

### 6-1. Specifications

|                                                  |     |
|--------------------------------------------------|-----|
| Maintenance data<br>(fuel, oil level, etc.)..... | 740 |
| Fuel information.....                            | 752 |
| Tire information.....                            | 755 |

### 6-2. Customization

|                             |     |
|-----------------------------|-----|
| Customizable features ..... | 766 |
|-----------------------------|-----|

## 7 For owners

|                                                                   |     |
|-------------------------------------------------------------------|-----|
| Reporting safety defects<br>for U.S. owners.....                  | 778 |
| Seat belt instructions<br>for Canadian owners<br>(in French)..... | 779 |

## Index

|                         |     |
|-------------------------|-----|
| Abbreviation list ..... | 782 |
| Alphabetical index..... | 784 |
| What to do if... ..     | 794 |

1

2


3

4

5

6

7



Fuel filler door P.109

Doors P.53

Turn signal lights P.176

Rear window defogger P.359

Trunk P.58

Tires

- Rotation P.654
- Replacement P.715
- Inflation pressure P.749
- Information P.755

Tail lights P.195

Side marker lights P.195



# Pictorial index

## Front interior

Seat belts P. 92


Head restraints P. 89

Door pockets P. 559

A

B

C



Power outlets P. 578

AUX adapter P. 383 \*1

USB adapter P. 446 \*1

SRS side airbags P. 119

SRS driver airbag P. 119

Shift lock override button P. 725

SRS knee airbags P. 119

SRS front passenger airbag P. 119

Ashtray \* P. 575

Cigarette lighter \* P. 576

Non smokers box \* P. 563

Automatic transmission shift lever  
P. 165, 169

Cup holders P. 560

Front seats P. 65

Console box P. 562

A

Anti-glare inside rear view mirror P. 100


Interior lights P. 553

Personal lights P. 554

Moon roof switches P. 105

Garage door opener switches P. 602

"SOS" button \* P. 612



Compass \* P. 608

SRS curtain shield airbags P. 119

Sun visors P. 570

Vanity mirrors P. 571

Auxiliary boxes P. 568


\*: If equipped

\*1: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

B

Inside lock buttons P. 53

Driving position memory switches P. 81



Shoulder anchor control switches P. 92


Window lock switch P. 103

Door lock switch P. 53


Power window switches P. 103

C

### ► Without rear console display



### ► With rear console display



\*: If equipped

## Pictorial index

## Instrument panel

Headlight switch P.195

Turn signal lever P.176

Fog light switch P.203

Paddle shift switches \*  
P.172, 173

Gauges and meters P.183

Multi-information display P.190

Windshield wiper and washer switch P.204


Engine (ignition) switch P.161

Clock

● Without Navigation system P.572

● With Navigation system \*1

Emergency flasher switch P.692



Trunk opener main switch P.59

Glove box P.558

Volume adjust knob P.40

Tire pressure warning reset switch P.655

Pre-collision braking off switch \* P.292

Parking brake switches P.177

Horn P.182

Trunk opener P.58


Floor mat  
P.599

Hood release lever  
P.635


Fuel filler door opener P.109

A

► Without heated steering wheel



► With heated steering wheel




\*: If equipped

\*1: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".


# Pictorial index

# Instrument panel

## B ▶ Without advanced parking guidance system




## ▶ With advanced parking guidance system




## C ▶ Without touch screen



## ▶ With touch screen



## D ▶ Without LKA (Lane-Keeping Assist) ▶ With LKA (Lane-Keeping Assist)



Cruise control switch P. 208, 212

Distance switch \* P. 212

"LKA" switch P. 232




# E

## ► Without touch screen

Air conditioning  
system P. 328

Audio system  
P. 363



Rear window and  
outside rear view  
mirror defoggers  
P. 359

## ► With touch screen (without navigation system)

Touch screen  
P. 314

Air conditioning  
system P. 337



Rear window and  
outside rear view  
mirror defoggers  
P. 359

Audio system  
P. 386

## ► With touch screen (with navigation system)

Touch screen  
P. 314

Navigation  
system \*2

Air conditioning  
system P. 337



Rear window and  
outside rear view  
mirror defoggers  
P. 359


Audio system \*2

\*: If equipped

\*2: Refer to "Navigation System Owner's Manual".

## Pictorial index

## Rear interior (5-seat models without relaxation seat)



**A**

Interior lights P. 553  
Personal lights P. 554



SRS curtain shield  
airbags P. 119

Vanity mirrors P. 571  
Coat hooks P. 598


**B**

Power seat  
switches \* P. 71

Seat heater  
switches \* P. 583

Rear climate control  
seat switches \*  
P. 583

Rear door sunshade  
switches \* P. 593




Rear audio  
switches \* P. 459 \*1

Rear air conditioning  
switches \* P. 351

Rear sunshade switch \*  
P. 590

\*: If equipped

\*1: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".



A

Interior lights P. 553

Personal lights P. 554



SRS curtain shield  
airbags P. 119

Vanity mirrors P. 571

Coat hooks P. 598

B

Headphone jacks P. 472 \*1


Rear seat entertainment system  
controller P. 468 \*1

Rear seat relaxation system/pelvic  
support seat controller P. 71



\*1: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

C



# D

Rear seat entertainment system P. 468 <sup>\*1</sup>

DVD player P. 479 <sup>\*1</sup>

Auxiliary boxes P. 568

A/V input adapter P. 499 <sup>\*1</sup>



Power outlets P. 578

<sup>\*1</sup>: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

## Pictorial index

## Rear interior (4-seat models)

DVD player P. 479 \*1

Headphone jacks P. 472 \*1


Seat position memory  
switches P. 87

Power window  
switches P. 103

Head restraints P. 89

SRS side airbags  
P. 119

A



Seat belts P. 92

Power outlets \* P. 578

Cup holders P. 560

SRS seat cushion airbag P. 119


Auxiliary boxes P. 568

A

Interior lights P. 553

Personal lights P. 554

Rear seat entertainment system P. 468 <sup>\*1</sup>



SRS curtain shield  
airbags P. 119

Vanity mirrors P. 571

Coat hooks P. 598

\*: If equipped

<sup>\*1</sup>: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

B

A/V input adapter P.499 \*1

Cigarette lighters \* P.576

Power outlets \* P.578




Rear seat entertainment system  
controller P.468 \*1

Rear seat relaxation system/pelvic  
support seat controller P.71

Cool box/auxiliary box P.564

# C



\*: If equipped

<sup>\*1</sup>: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

## For your information

### Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Lexus policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustration may differ from your vehicle in terms of color and equipment.

### Noise from under vehicle after turning off the engine

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

### Accessories, spare parts and modification of your Lexus

A wide variety of non-genuine spare parts and accessories for Lexus vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Lexus vehicle.

This vehicle should not be modified with non-genuine Lexus products. Modification with non-genuine Lexus products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

### Installation of a mobile two-way radio system

As the installation of a mobile two-way radio system in your vehicle could affect electronic systems such as the multiport fuel injection system/sequential multiport fuel injection system, cruise control system, anti-lock brake system, SRS airbag system and seat belt pretensioner system, be sure to check with your Lexus dealer for precautionary measures or special instructions regarding installation.

## Scrapping of your Lexus

The SRS airbag and seat belt pretensioner devices in your Lexus contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Lexus dealer before you scrap your vehicle.

## Perchlorate Material

Special handling may apply, See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate).

Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries.

### CAUTION

#### ■ General precautions while driving

**Driving under the influence:** Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

**Defensive driving:** Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

**Driver distraction:** Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

#### ■ General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the cigarette lighter, the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

## Symbols used throughout this manual

### Cautions & Notices

#### CAUTION

This is a warning against something which, if ignored, may cause injury to people. You are informed about what you must or must not do in order to reduce the risk of injury to yourself and others.

#### NOTICE

This is a warning against something which, if ignored, may cause damage to the vehicle or its equipment. You are informed about what you must or must not do in order to avoid or reduce the risk of damage to your Lexus and its equipment.

### Symbols used in illustrations



#### Safety symbol

The symbol of a circle with a slash through it means “Do not”, “Do not do this”, or “Do not let this happen.”



#### Arrows indicating operations

 Indicates the action (pushing, turning, etc.) used to operate switches and other devices.

 Indicates the outcome of an operation (e.g. a lid opens).

**1-1. Key information**

Keys ..... 32

**1-2. Opening, closing and locking the doors and trunk**Smart access system with  
push-button start ..... 36

Wireless remote control ..... 50

Doors ..... 53

Trunk ..... 58

**1-3. Adjustable components  
(seats, mirrors,  
steering wheel)**

Front seats ..... 65

Power rear seat ..... 71

Driving position memory ..... 81

Rear seat position memory .... 87

Head restraints ..... 89

Seat belts ..... 92

Steering wheel ..... 99

Anti-glare inside rear view  
mirror ..... 100

Outside rear view mirrors .... 101

**1-4. Opening and closing the  
windows and moon roof**

Power windows ..... 103

Moon roof ..... 105

**1-5. Refueling**Opening the fuel tank  
cap ..... 109**1-6. Theft deterrent system**Engine immobilizer  
system ..... 112

Alarm ..... 114

**1-7. Safety information**

Correct driving posture ..... 117

SRS airbags ..... 119

Front passenger occupant  
classification system ..... 132

Child restraint systems ..... 137

Installing child restraints ..... 142

## 1-1. Key information

### Keys

The following keys are provided with the vehicle.



#### 1 Electronic keys

- Operating the smart access system with push-button start (→P. 36)
- Operating the wireless remote control function (→P. 50)

#### 2 Mechanical keys

#### 3 Key number plate

### ■ Card key (if equipped)



#### 1 Electronic key

Operating the smart access system with push-button start (→P. 36)

#### 2 Mechanical key

## Using the mechanical key



### Take out the mechanical key.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. (→P. 728)

1

Before driving

### ■ Card key

- The mechanical key that is stored inside the card key should be used only if a problem arises, such as when the key does not operate properly.
- If it is difficult to take out the mechanical key, push down the lock release button using a pen tip etc. If it is difficult to pull it out, use a coin etc.



- To store the mechanical key in the card key, insert it inside while pressing the lock release button.

## 1-1. Key information



- If the battery cover is not installed and the battery falls out or if the battery was removed because the key got wet, reinstall the battery with the positive terminal facing the Lexus emblem.

- The card key is not waterproof.

### ■ When required to leave the vehicle's key with a parking attendant

Turn the trunk opener main switch off and lock the glove box and the trunk storage extension as circumstances demand. (→P. 59, 558, 596)

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

### ■ Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. To have a new key made, the key number is required.

### ■ To have a new key made

New genuine Lexus keys can be made by your Lexus dealer using the keys provided with your vehicle; the electronic keys, card key and key number plate.

### ■ When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc, ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

## ⚠ NOTICE

### ■ To prevent key damage

Observe the following.

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for a long period of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.

 NOTICE

- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the electronic keys.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems, glass top ranges, or medical electrical equipment, such as low-frequency therapy equipment.

#### ■ When a vehicle key is lost

If the key remains lost, the risk of vehicle theft increases significantly. Visit your Lexus dealer immediately with all remaining electronic keys and the card key that was provided with your vehicle.


#### ■ Precautions for handling the card keys

- Do not apply excess force when inserting the mechanical key to the card key. Doing so may damage the card key.
- If the battery or card key terminals get wet, the battery may rust and the smart access system with push-button start become inoperable.  
If the key is dropped into water, or if drinking water etc. is spilled on the key, immediately remove the battery cover and wipe the battery and terminals. (To remove the battery cover, lightly grasp it and pull.) If the battery is rusted, have your Lexus dealer replace the battery.
- Do not crush the battery cover or use a screwdriver to remove the battery cover. Forcibly removing the battery cover may bend or damage the key.
- If the battery cover is frequently removed, the battery cover may become loose.
- When installing the battery, make sure to check the direction of the battery. Installing the battery in the wrong direction may cause the battery to deplete rapidly.
- The surface of the card key may be damaged, or its coating may peel off in the following situations.
  - The card key is carried together with hard objects, such as coins or keys.
  - The card key is scraped with a sharp object, such as a tip of mechanical pencil.
  - The surface of the card key is wiped with thinners or benzene.

## 1-2. Opening, closing and locking the doors and trunk Smart access system with push-button start

The following operations can be performed simply by carrying the electronic key (including the card key) on your person, for example in your pocket.

(The driver should always carry the electronic key.)




**1** Unlocks and locks the doors (→P. 37)

**2** Opens the trunk (→P. 37)

**3** Starts and stops the engine (→P. 161)

## Unlocking and locking the doors



Grip the handle to unlock the door.

Make sure to touch the sensor on the back of the handle.

The door cannot be unlocked for 3 seconds after the door is locked.



Press the lock button to lock the door.

Pressing and holding the button closes the windows and moon roof.

## Opening the trunk




Press the button.

If the vehicle is equipped with a power trunk opener and closer, the trunk lid automatically opens fully.


Antenna location and effective range

Antenna location



- 1 Antennas outside cabin
- 2 Antennas inside cabin
- 3 Antenna inside trunk
- 4 Antenna outside trunk

■ Effective range (areas within which the electronic key is detected)



- When locking or unlocking the doors

The system can be operated when the electronic key is within about 2.3 ft. (70 cm) of an outside door handle. (Only the doors detecting the key can be operated.)

- When unlocking the trunk

The system can be operated when the electronic key is within about 2.3 ft. (70 cm) of the trunk release button.

- When starting the engine or changing "ENGINE START STOP" switch modes

The system can be operated when the electronic key is inside the vehicle.

### ■ Operation signals

Doors: A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Trunk: A buzzer sounds to indicate that the trunk has been unlocked.

Windows and moon roof: A buzzer sounds to indicate that the windows and moon roof are operating.

### ■ Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously. Fully close the door to stop the buzzer, and lock the vehicle once more.

### ■ Adjusting the volume of the buzzer

The operation signal buzzer and door lock buzzer can be set to the desired volume.



**1** Increases the volume.

**2** Decreases the volume.

The buzzer can be turned off by turning the knob fully clockwise.

### ■ Conditions affecting operation

The smart access system with push-button start uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart access system with push-button start, wireless remote control and engine immobilizer system from operating properly:  
(Ways of coping: →P. 728)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication devices
- When the electronic key is in contact with, or is covered by the following metallic objects
  - Cards to which aluminum foil is attached
  - Cigarette boxes that have aluminum foil inside
  - Metallic wallets or bags
  - Coins
  - Hand warmers made of metal
  - Media such as CDs and DVDs
- When multiple electronic keys are in the vicinity
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
  - Another vehicle's electronic key or a wireless key that emits radio waves
  - Personal computers or personal digital assistants (PDAs)
  - Digital audio players
  - Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window


■ Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control.

**STEP 1** Turn the “ENGINE START STOP” switch OFF.

**STEP 2** When the indicator light on the key surface is not on, press and hold  ,  , or  for about 5 seconds while pressing and holding  on the key.

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

| Multi-information display                                                           | Unlocking doors                                                       | Beep                                            |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------|-------------------------------------------------|
|    | Hold the driver's door handle to unlock only the driver's door.       | Exterior: Beeps 3 times<br>Interior: Rings once |
|                                                                                     | Hold a passenger's door handle to unlock all the doors.               |                                                 |
|   | Hold the door handle to unlock the front and rear doors on your side. | Exterior: Beeps 4 times<br>Interior: Rings once |
|  | Hold the door handle to unlock the door.                              | Exterior: Beeps once<br>Interior: Rings once    |
|  | Hold a door handle to unlock all doors.                               | Exterior: Beeps twice<br>Interior: Rings once   |

**STEP 3** Unlock the doors using the wireless remote control and open one of the doors.

If a door is not opened within 60 seconds after  is pressed, the doors will be locked again and the alarm will automatically be set. In case that the alarm is triggered, immediately stop the alarm. (→P. 114)

1

Before driving

### ■ Battery-saving function

In the following circumstances, the entry function is disabled in order to prevent the vehicle battery from discharging and electronic key battery from depleting.

- When the entry function has not been used for 30 days or more
- When the electronic key has been left within approximately 6 ft. (2 m) of the vehicle for 10 minutes or more

The system will resume operation when

- The vehicle is locked using the door handle lock switch when carrying the electronic key on your person.
- The vehicle is locked/unlocked using the wireless remote control function. (→P. 50)
- The vehicle is locked/unlocked using the mechanical key. (→P. 728)

### ■ Electronic key battery depletion

- The standard battery life is 1 to 2 years. (The card key battery life is about a year and a half.)
- If the battery becomes low, an alarm will sound in the cabin when the engine stops. (→ P. 45)
- The battery becomes depleted even if the electronic key is not used because the key always transmits radio waves. If the smart access system with push-button start or the wireless remote control does not operate, or the detection area becomes smaller, the battery may be depleted. Replace the battery when necessary. (→ P. 671)

## 1-2. Opening, closing and locking the doors and trunk

- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field.
  - TVs
  - Personal computers
  - Cellular phones, cordless phones and battery chargers
  - Recharging cellular phones or cordless phones
  - Glass top ranges
  - Table lamps

### ■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention may not function.)

### ■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
  - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
  - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is unlocked.
  - The electronic key is on the instrument panel, rear package tray, floor or door pockets, or in the glove box when the engine is started or “ENGINE START STOP” switch modes are changed.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash when the electronic key is within the effective range. (The door will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- Gripping the door handle when wearing a glove may not unlock the door.

- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.

### ■ When the vehicle is not driven for extended periods

To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.

### ■ Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the anti-theft system automatically locks the vehicle again.

### ■ Alarms and warning indicators

A combination of exterior and interior alarms as well as warnings displayed on the multi-information display are used to prevent theft of the vehicle and unforeseeable accidents resulting from erroneous operation. Perform the appropriate correction procedure described in the following table:

| Alarm                                      | Situation                                                                                                                                              | Correction procedure                                                                 |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Exterior alarm sounds once for 2 seconds.  | An attempt was made to lock the doors using the entry function while the electronic key was still inside the passenger compartment.                    | Retrieve the electronic key from the passenger compartment and lock the doors again. |
|                                            | The trunk was closed with the electronic key inside and all doors were locked.                                                                         | Retrieve the electronic key from the trunk and close the trunk lid.                  |
| Exterior alarm sounds once for 60 seconds. | An attempt was made to exit the vehicle and lock the doors while carrying the electronic key without first turning the "ENGINE START STOP" switch OFF. | Turn the "ENGINE START STOP" switch OFF and lock the doors again.                    |

## 1-2. Opening, closing and locking the doors and trunk

| Alarm                                                          | Situation                                                                                                                                                                                  | Correction procedure                                                                                     |
|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| Exterior alarm sounds once for 10 seconds.                     | An attempt was made to lock the vehicle while a door was open.                                                                                                                             | Close all of the doors and lock the doors again.                                                         |
| Interior alarm pings continuously.                             | The "ENGINE START STOP" switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the "ENGINE START STOP" switch was in ACCESSORY mode). | Turn the "ENGINE START STOP" switch OFF and close the driver's door.                                     |
|                                                                | The "ENGINE START STOP" switch was turned OFF while the driver's door was open.                                                                                                            | Close the driver's door.                                                                                 |
| Interior alarm sounds continuously. <sup>*1</sup>              | When the "ENGINE START STOP" switch is in IGNITION ON or ACCESSORY mode, an attempt was made to open the door and exit the vehicle, and the shift lever was not in "P".                    | Shift the shift lever to "P" and turn the "ENGINE START STOP" switch OFF.                                |
| Interior and exterior alarms sound continuously. <sup>*1</sup> | When the "ENGINE START STOP" switch is in IGNITION ON or ACCESSORY mode, the driver's door was closed after the key was carried outside the vehicle, and the shift lever was not in "P".   | Shift the shift lever to "P", turn the "ENGINE START STOP" switch OFF and close the driver's door again. |

| Alarm                                                                      | Situation                                                                                                                             | Correction procedure                                                       |
|----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| Interior alarm pings once. <sup>*1</sup>                                   | The electronic key has a low battery.                                                                                                 | Replace the electronic key battery.                                        |
|                                                                            | An attempt was made to start the engine without the electronic key being present, or the electronic key was not functioning normally. | Start the engine with the electronic key present. <sup>*2</sup>            |
| Interior alarm pings once and exterior alarm sounds 3 times. <sup>*1</sup> | The driver's door was closed after the key was carried outside the vehicle, and the "ENGINE START STOP" switch was not turned OFF.    | Turn the "ENGINE START STOP" switch OFF and close the driver's door again. |
|                                                                            | An occupant carried the electronic key outside the vehicle and closed the door while the "ENGINE START STOP" switch was not OFF.      | Bring the electronic key back into the vehicle.                            |

<sup>\*1</sup>: A warning message will be shown on the multi-information display in the instrument cluster.

<sup>\*2</sup>: If the engine does not start when the electronic key is inside the vehicle, the electronic key battery may be depleted or there may be difficulties receiving the signal from the key. (→P. 43)

■ If the smart access system with push-button start does not operate properly

- Locking and unlocking the doors and trunk: Use the mechanical key. (→P. 728)
- Starting the engine: →P. 730

■ When the electronic key battery is fully depleted

→P. 671

### ■ Customization

Settings (e.g. smart access system with push-button start) can be changed.  
(Customizable features →P. 766)

### ■ Certification for the smart access system with push-button start

► For vehicles sold in the U.S.A.

FCC ID: NI4TMLF-4

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

 **CAUTION****■ Caution regarding interference with electronic devices**

- People with implanted pacemakers or cardiac defibrillators should keep away from the smart access system antennas. (→P. 38) The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Lexus dealer for details, such as frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if you should disable the entry function.
- User of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.  
Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Lexus dealer for details for disabling the entry function.

## 1-2. Opening, closing and locking the doors and trunk

### Wireless remote control

The wireless remote control can be used to lock and unlock the vehicle and the trunk from outside the vehicle.



**1** Locks all doors

**2** Unlocks all doors

Pressing the button unlocks the driver's door. Pressing the button again within 3 seconds unlocks the other doors.

**3** Opens the windows and moon roof (press and hold)\*

**4** Unlocks the trunk  
(press and hold)

Vehicles equipped with a power trunk opener and closer: Opens the trunk (press and hold)

**5** Sounds alarm  
(press and hold) (→P. 115)

\*: This setting must be customized at your Lexus dealer.

#### ■ Operation signals

Doors: A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Trunk: A buzzer sounds to indicate that the trunk has been unlocked.

Windows and moon roof: A buzzer sounds to indicate that the windows and moon roof are opening.

#### ■ Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously. Fully close the door to stop the buzzer, and lock the vehicle once more.

**■ Adjusting the volume of the buzzer**

The operation signal buzzer and door lock buzzer can be set to the desired volume.  
(→P. 40)

**■ Alarm**

Using the wireless remote control to lock the doors will set the alarm system.  
(→P. 114)

**■ Electronic key battery depletion**

→P. 43

**■ Security feature**

→P. 45

**■ If the wireless remote control does not operate properly**

- Locking and unlocking the doors and trunk: Use the mechanical key.  
(→P. 728)

- Starting the engine: →P. 730

**■ When the electronic key battery is fully depleted**

→P. 671

**■ Conditions affecting operation**

→P. 41

**■ Customization**

Settings (e.g. trunk unlocking function) can be changed.  
(Customizable features →P. 766)

### ■ Certification for wireless remote control

► For vehicles sold in the U.S.A.

FCC ID: HYQ14ACX

FCC ID: HYQ14ADF

FCC ID: NI4TMRF-002

FCC ID: NI4TMRF-001

FCC ID: HYQ14AEB

FCC ID: HYQ14AEF

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## 1-2. Opening, closing and locking the doors and trunk

### Doors

The vehicle can be locked and unlocked using the entry function, wireless remote control or door lock switch.

#### ■ Entry function

→P. 37

#### ■ Wireless remote control

→P. 50

#### ■ Door lock switch



1 Locks all doors

2 Unlocks all doors

#### ■ Inside lock button



1 Locks the door

2 Unlocks the door


The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.

**Locking the front doors from the outside without a key**

The door cannot be locked if the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle.

The key may not be detected correctly and the door may be locked.

**Rear door child-protector lock**



The door cannot be opened from inside the vehicle when the locks are set.

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.

**Automatic door locking and unlocking systems**

The following functions can be set or cancelled:

| Function                                      | Operation                                                                                                                   |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Shift position linked door locking function   | Shifting the shift lever out of “P” locks all doors.                                                                        |
| Shift position linked door unlocking function | Shifting the shift lever to “P” unlocks all doors.                                                                          |
| Speed linked door locking function            | All doors are locked when the vehicle speed is approximately 12 mph (20 km/h) or higher.                                    |
| Driver's door linked door unlocking function  | All doors are unlocked when the driver's door is opened within 10 seconds after turning the “ENGINE START STOP” switch OFF. |

### ■ Setting and canceling the functions (without navigation system)

To switch between setting and canceling, follow the procedure below.

**STEP 1** Close all the doors and switch the “ENGINE START STOP” switch to IGNITION ON mode. (Perform the step 2 within 20 seconds.)



Shift the shift lever to “P” or “N”, press and hold the driver's door lock switch (  or  ) for about 5 seconds then release.

The shift lever and switch positions corresponding to the desired function to be set are shown as follows.

Use the same procedure to cancel the function.

| Function                                      | Shift lever position | Driver's door lock switch position                                                  |
|-----------------------------------------------|----------------------|-------------------------------------------------------------------------------------|
| Shift position linked door locking function   | P                    |    |
| Shift position linked door unlocking function |                      |   |
| Speed linked door locking function            | N                    |  |
| Driver's door linked door unlocking function  |                      |  |

When the setting or canceling operation is complete, all doors are locked and then unlocked.

### ■ Door closer (if equipped)

In the event that a door is left slightly open, the door closer will automatically close it to the fully closed position.

- The door closer will operate regardless of “ENGINE START STOP” switch mode.
- The door closer will not function if the door has been closed while pulling the inside or outside door handle.
- The door can be opened by pulling the inside or outside door handle, even when the door closer is operating (except when the lock button is in the lock position or the child-protector lock is set).
- The motor sound may be heard for several seconds after the door closer closes the door. This does not indicate a malfunction.

### ■ Impact detection door lock release system

In the event that the vehicle is subject to a strong impact, all the doors are unlocked. Depending on the force of the impact or the type of accident, however, the system may not operate.

### ■ Using the mechanical key

The doors can also be locked and unlocked with the mechanical key. (→P. 728)

### ■ Customization

Settings (e.g. unlocking function using a key) can be changed.  
(Customizable features →P. 766)

 **CAUTION****■ To prevent an accident**

Observe the following precautions while driving the vehicle.

Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- Always use a seat belt.
- Always lock all doors.
- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving.

The doors may be opened and the passengers are thrown out of the vehicle and it may result in serious injury or death.

Be especially careful for the front doors, the doors may be opened even if the inside lock buttons are in locked position.

- Set the rear door child protector locks when children are seated in the rear seat.

**■ Door closer**

In the event that a door is left slightly open, the door closer will automatically close it to the fully closed position.

If the child-protector lock is set, the door closer will not stop during operation even if an attempt is made to open the door from inside the vehicle. Be careful not to catch fingers or anything else in the door. Failure to do so may result in serious injury.

 **NOTICE****■ To prevent door closer malfunction**


Do not frequently repeat opening and closing of doors, or apply excessive force to a door while the door closer is operating.

## 1-2. Opening, closing and locking the doors and trunk

### Trunk

The trunk can be opened using the trunk opener, entry function or wireless remote control.

#### ■ Opening the trunk from inside the vehicle



Press the opener switch.

If the vehicle is equipped with a power trunk opener and closer, the trunk lid automatically opens fully.

#### ■ Opening the trunk from outside the vehicle

##### ► Entry function

→P. 37

##### ► Wireless remote control

→P. 50

#### Trunk closer switch (with power trunk opener and closer)



Pressing the switch closes the trunk lid automatically. (A buzzer sounds.)

Pressing the switch while the trunk lid is closing opens the trunk lid again.

## Canceling the trunk opener feature



Turn the main switch in the glove box off to disable the trunk opener.

1 On

2 Off

The trunk lid cannot be opened even with the wireless remote control or the entry function.

1

Before driving

### ■ Trunk handle



Use the trunk handle when closing the trunk.

### ■ Trunk easy closer

In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position.

### ■ Function to prevent the trunk being locked with the electronic key inside (when all the doors are locked)

Closing the trunk lid with the electronic key left inside the trunk will sound an alarm. In this case, the trunk lid can be opened by pressing the button on the trunk lid.

### ■ Overload protection function (with a power trunk opener and closer)

The trunk lid will not operate when excessive load is present on the top of the trunk lid.

## 1-2. Opening, closing and locking the doors and trunk

### ■ Fall-down protection function (with a power trunk opener and closer)

While the trunk lid is opening automatically, applying excessive force to it will stop the opening operation to prevent the trunk lid from rapidly falling down.

### ■ Jam protection function (with a power trunk opener and closer)

While the trunk lid is closing automatically, the trunk lid will stop closing and open if something gets caught.

### ■ Internal trunk release lever



The trunk lid can be opened by pulling down on the glow-in-the-dark lever located on the inside of the trunk lid.

The lever will continue to glow for some time after the trunk lid is closed.

### ■ Using the mechanical key

The trunk can be also opened using the mechanical key. (→P. 728)

### ■ Customization

Setting of power trunk opener and closer function can be deactivated.  
(Customizable features →P. 766)

 **CAUTION****■ Caution while driving**

- Keep the trunk lid closed while driving.

If the trunk lid is left open, it may hit near-by objects while driving or luggage in the trunk may be unexpectedly thrown out, causing an accident.

In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the trunk lid before driving.

- Before driving the vehicle, make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving, causing an accident.
- Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

**■ When children are in the vehicle**

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not allow children to enter the trunk.

If a child is accidentally locked in the trunk, they could overheat or suffocate.

- Do not allow a child to open or close the trunk lid.

Doing so may cause the trunk lid to operate unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

### CAUTION

#### ■ Using the trunk

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to fall closed again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.



- The trunk lid may fall if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.
- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface. If the trunk handle is used to fully close the trunk lid, it may result in hands or arms being caught.

- Do not attach any accessories other than genuine Lexus parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to fall closed again after it is opened.

## ⚠ CAUTION

### ■ Trunk easy closer



In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position. It takes several seconds before the trunk easy closer begins to operate. Be careful not to catch fingers or anything else in the trunk lid, as this may cause bone fractures or other serious injuries.

### ■ Power trunk opener and closer

Observe the following precautions when operating the power trunk opener and closer.

Failure to do so may cause serious injury.

- Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- If the trunk closer switch is pressed while the trunk lid is opening during automatic operation, the trunk lid stops opening. Take extra care when on an incline, as the trunk lid may open or close suddenly.
- On an incline, the trunk lid may fall after it opens automatically. Make sure the trunk lid is fully open and secure before using the trunk.
- In the following situations, the power trunk opener and closer may detect an abnormality and automatic operation may be stopped. In this case, the trunk lid has to be operated manually. Take extra care in this situation, as the stopped trunk lid may suddenly fall, causing an accident.
  - When the trunk lid contacts an obstacle
  - When the battery voltage suddenly drops, such as when the “ENGINE START STOP” switch is turned to IGNITION ON mode or the engine is started during automatic operation
- Do not attach any accessories other than genuine Lexus parts to the trunk lid. The power trunk opener and closer may not operate, causing itself to malfunction, or the trunk lid may fall closed again after it is opened.

### CAUTION

#### ■ Jam protection function

Observe the following precautions.

Failure to do so may cause serious injury.

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the trunk lid fully closes. Be careful not to catch fingers or anything else in the trunk lid.
- The jam protection function may not work depending on the shape of the object that is caught. Be careful not to catch fingers or anything else.

### NOTICE

#### ■ To prevent trunk easy closer malfunction


Do not apply force to the trunk lid while the trunk easy closer is operating.

#### ■ To prevent damage to the power trunk opener and closer

- Make sure that there is no luggage or snow on the trunk lid before operating the power trunk opener and closer. In addition, make sure that there is no ice between the trunk lid and frame that prevents movement of the trunk lid. Operating the power trunk opener and closer when excessive load is present on the trunk lid may cause a malfunction.
- Do not apply excessive force to the trunk lid while the power trunk opener and closer is operating.

## 1-3. Adjustable components (seats, mirrors, steering wheel)

### Front seats



#### 1 Seat position switch

The height of the driver's head restraint is automatically adjusted simultaneously with the seat position adjustment operation.

#### 2 Seatback angle switch

#### 3 Head restraint height adjustment switch (→P. 89)

#### 4 Seat cushion (front) angle switch

#### 5 Vertical height adjustment switch

#### 6 Lumbar support switch

Driver's seat: 4 way

Front passenger's seat: 2 way

#### 7 Seat cushion length adjustment switch


### Operating the front passenger's seat from the driver's seat

#### ► Without rear console display



- 1 Tilts the seatback forward
- 2 Tilts the seatback backward
- 3 Moves the seat forward
- 4 Moves the seat backward


#### ► With rear console display



- 1 Tilts the seatback forward
- 2 Tilts the seatback backward
- 3 Moves the seat forward
- 4 Moves the seat backward

## Operating the front passenger's seat from the rear seat (with relaxation seat)

### ► 5-seat models




- 1 Moves the front passenger's seat forward

The signal beeps when the seat operation stops at the forward limit.

- 2 Moves the front passenger's seat backward

The seatback will return to the neutral position.

### ► 4-seat models




- 1 Moves the front passenger's seat forward

The signal beeps when the seat operation stops at the forward limit.

- 2 Moves the front passenger's seat backward

The seatback will return to the neutral position.

### Active head restraints



If the vehicle detects an impact during a rear-end collision, the front part of the head restraint moves forward and upward to help reduce the risk of whiplash to the seat occupant.

When reversing, even a small amount of force applied from the rear, such as a minor rear impact, may cause the head restraints to move.

#### ■ Operating the front passenger's seat from the rear seat (with relaxation seat)

The front passenger's seat can be operated when the "ENGINE START STOP" switch is in IGNITION ON mode. However, in the following situations, the front passenger's seat does not move even when the switch is operated:

- The weight of an occupant or heavy object, etc. is detected on the front passenger's seat.
- The front passenger's seat belt is fastened.
- The front passenger's door is open. (The front seat will not move forward.)

#### ■ Seat cushion automatic length adjustment (driver's seat)

If the front of the cushion gets too close to the area around the instrument panel when the seat position is being adjusted, the seat cushion will automatically retract.

#### ■ Seat operation automatic stop function (with relaxation seat)

If a front seat is likely to come into contact with the retractable table (4-seat models) or the ottoman during seat operation or activation of the auto away function, a buzzer will sound and seat slide operation will be stopped partway. (A warning message will be shown on the multi-information display.)

### ■ Active head restraints

- The active head restraint on the front passenger seat will not activate if the seat is unoccupied. However, it may activate during a rear-end collision if luggage is in the seat or the seat belt is fastened.
- Once the active head restraint has activated, the head restraint remains protruded forward and upward. After it has operated, have it repaired at your Lexus dealer.

### CAUTION

#### ■ Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.

If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.

Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

#### ■ Operating the front passenger's seat from the driver's seat or rear seat

Do not operate the front passenger's seat when a passenger is seated in it. In addition, do not let anyone sit down in the front passenger's seat while the seat is being operated. The front passenger may catch their legs between the instrument panel and seat, resulting in injury.

#### ■ The active head restraint on the front passenger seat

Do not place anything, such as a cushion, on the front passenger's seat.

Doing so will disperse the passenger's weight, which may prevent the sensor from detecting the passenger's weight properly. As a result, the active head restraint may not activate in the event of an accident.

#### ■ Active head restraint precautions

- Do not put head restraint covers.
- For removal, installation, modification, disassembly or disposal of the active head restraints, contact your Lexus dealer.  
Inappropriate handling of the active head restraints may prevent them from operating properly during an accident.



#### NOTICE


##### ■ Operating the front passenger's seat from the driver's seat or rear seat

Before operating the front passenger's seat, make sure that there is no luggage or any other objects on the seat or in the footwell that could prevent its operation.

Failure to do so may result in excess force being applied, causing damage to the seat and/or the luggage.

## Power rear seat\*

#### ► 5-seat models without relaxation seat



#### 1 Seat selection switch

The indicator light for the seat that can be operated comes on.

#### 2 Seat position adjustment switch


#### 3 Seatback upper angle adjustment switch

#### 4 Head restraint height adjustment switch (→P. 89)

#### 5 Pelvic support seat controller

The seat return function linked to the door opening operation allows the seat to automatically return to the neutral position for easier access to and from the vehicle.

#### ► 5-seat models with relaxation seat



The right-hand rear seat is a relaxation seat, which is equipped with a seatback angle adjustment function and an ottoman.

#### 1 Seat selection switch

The indicator light for the seat that can be operated comes on.

#### 2 Seat position adjustment switch

#### 3 Seatback upper angle adjustment switch

#### 4 Head restraint height adjustment switch (→P. 89)

#### 5 Seatback angle adjustment switch

#### 6 Ottoman angle adjustment switch


#### 7 Front passenger's seat control switch (→P. 67)

#### 8 Relaxation mode switch

#### 9 Rear seat relaxation system/pelvic support seat controller

The seat return function linked to the door opening operation allows the seat to automatically return to the neutral position for easier access to and from the vehicle.

## ► 4-seat models



The right-hand rear seat is a relaxation seat, which is equipped with a seatback angle adjustment function and an ottoman.

**1** Seat selection switch

The indicator light for the seat that can be operated comes on.

**2** Seat position adjustment switch**3** Seatback upper angle adjustment switch**4** Head restraint height adjustment switch (→P. 89)**5** Seatback angle adjustment switch**6** Ottoman angle adjustment switch**7** Front passenger's seat control switch (→P. 67)**8** Relaxation mode switch**9** Rear seat relaxation system/pelvic support seat controller

The seat return function linked to the door opening operation allows the seat to automatically return to the neutral position for easier access to and from the vehicle.

### Returning the rear seat from the front seats




The seat will return to the neutral position while the button is pressed and held.

### Relaxation mode operation (relaxation seat)

Relaxation mode can be entered by operating a switch. The front passenger seat will move forward, and then the seatback of the relaxation seat will recline and the ottoman will simultaneously rise.

#### ► 5-seat models




Pressing the switch will cause a beep to sound and operation will start.

**1** Enters relaxation mode

**2** Returns to the neutral position.

To stop the operation part-way through, press either side of the switch again, or press any other seat adjustment button.

## ► 4-seat models



Pressing the switch will cause a beep to sound and operation will start.

**1** Enters relaxation mode

**2** Returns to the neutral position.

To stop the operation part-way through, press either side of the switch again, or press any other seat adjustment button.

1

Before driving

**Pelvic support seat with seat vibrator**

Pelvic support seat with seat vibrator, which feature a support plate mounted in the seatback and a vibration function, are equipped on each outside rear seat. The support plate position and vibration speed can be adjusted according to the occupant's preferences.

► Without relaxation seat




**1** Support plate position adjustment switch

**2** Vibration switch

Press  to operate the vibration function. Vibration will start in the same speed level as when previously operated. Each time  is pressed, the speed changes between 3 levels. Pressing "OFF" stops the vibration function.

► With relaxation seat




**1** Support plate position adjustment switch

**2** Vibration switch

Press  to operate the vibration function. Vibration will start in the same speed level as when previously operated. Each time  is pressed, the speed changes between 3 levels. Pressing "OFF" stops the vibration function.

## Rear seat relaxation system (with relaxation seat)

Pneumatic chambers built into the right-hand rear seat provide the occupant with pressure of different speeds and intensities.



### 1 Turns the system on and off

If no buttons are selected within approximately 3 minutes of operating this switch, the system will automatically turn off.

### 2 Starts the "SHIATSU" program

Partial pressure for the whole back

### 3 Starts the "STRETCH" program

Stretches and relaxes the lower back

### 4 Starts operation for the upper back

### 5 Starts operation for the lower back

### 6 Adjusts the intensity of the air pressure

3 intensity levels are available.

### 7 Adjusts the speed of the air unit

3 speed levels are available.

1

Before driving

### ■ Seat return function linked to the door opening operation

- Operating conditions  
The “ENGINE START STOP” switch is in IGNITION ON mode.
- Canceling operation partway through  
During the seat return operation, performing either of the following actions cancels the operation:
  - Pressing the “SET”, “M” or “C” button
  - Pressing any of the seat adjustment switches
- Disabling the seat return function



Pressing the “C” button will disable the seat return function.

The indicator light comes on when the seat return function is disabled.

Pressing the button again will enable the seat return function.

- Seat return operation after turning the “ENGINE START STOP” switch OFF  
The seat will automatically return to the neutral position if the door is opened within approximately 45 seconds of the “ENGINE START STOP” switch being turned OFF.

### ■ Relaxation mode (relaxation seat)

- Operating conditions  
Relaxation mode can be entered when the “ENGINE START STOP” switch is in IGNITION ON mode. However, in the following situations, relaxation mode cannot be entered even when the switch is operated:
  - The weight of an occupant or heavy object etc. is detected on the front passenger's seat.
  - The front passenger's seat belt is fastened.
  - The front passenger's door is open. (The front seat will not move forward.)
- Operation after turning the “ENGINE START STOP” switch OFF  
The rear seat can be returned to the neutral position as long as the relaxation mode switch is operated within approximately 45 seconds of the “ENGINE START STOP” switch being turned OFF.

### ■ Pelvic support seat with seat vibrator

- Operating conditions  
The "ENGINE START STOP" switch is in IGNITION ON mode.
- Automatic stop function
  - Vibration will automatically stop approximately 15 minutes after starting.
  - Vibration will automatically stop if the adjacent rear door is opened.
- Pelvic support seat return function
  - The position of the support plate will automatically return to the neutral position within approximately 5 seconds of the "ENGINE START STOP" switch being turned OFF.
  - The position of the support plate will automatically return to the neutral position if the adjacent rear door is opened.

### ■ Rear seat relaxation system (with relaxation seat)

- Operating conditions  
The "ENGINE START STOP" switch is in IGNITION ON mode.
- Automatic stop function  
Each operation will automatically stop approximately 15 minutes after starting.



### CAUTION

#### ■ Power rear seats

- Seat adjustment  
To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.  
If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may come into contact with the shoulder belt, increasing the risk of death or serious injury in the event of an accident.  
Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.
- When returning the rear seats from the front seats  
To avoid injuring the rear passengers, wait until they have gotten out of the vehicle before returning the rear seats to the neutral position.

### CAUTION

- When adjusting the seat position and ottoman angle (with relaxation seat)  
Keep sufficient footwell space to prevent your feet from being caught by the front seat.
- Using the ottoman (with relaxation seat)
  - Do not sit on the ottoman.  
If someone sits on the ottoman, the seat belt cannot be fitted properly, and they may be thrown from the seat in the event of an accident or sudden braking, resulting in death or serious injury.
  - When getting in or out of the vehicle, retract the ottoman. If the ottoman is not retracted, it may cause a fall, resulting in an injury.
- **Using the pelvic support seat with seat vibrator and rear seat relaxation system**
  - Those who are pregnant, have recently given birth, or suffer from ailments requiring rest (heart disease etc.) should consult a doctor before use.
  - Do not allow children to use the pelvic support seat vibration function or the rear seat relaxation function.
  - Do not use immediately after consuming a meal or alcohol, or for an extended period of time.
  - If you feel sick while using the pelvic support seat vibration function or the rear seat relaxation function, immediately discontinue use.

### NOTICE

- **To prevent an ottoman malfunction (with relaxation seat)**
  - Do not place any objects in the rear seat footwell that could prevent the operation of the ottoman.
  - Do not place heavy luggage on the ottoman.
  - Do not place any objects under the ottoman while it is raised for use. These objects may interfere with the ottoman being folded, causing damage to the ottoman or the objects themselves.

### Driving position memory

Your preferred driving position (the position of the driver's seat and steering wheel, angle of the outside rear view mirrors, and height of seat belt shoulder anchor) can be memorized and recalled with the touch of a button. It is also possible to set this function to activate automatically when the doors are unlocked.

Three different driving positions can be entered into memory.

The same buttons are found on the front passenger's side, allowing the front passenger's seat position and seat belt shoulder anchor height to be memorized.

#### ■ Entering a position to memory

**STEP 1** Check that the shift lever is in "P".

**STEP 2** Turn the "ENGINE START STOP" switch to IGNITION ON mode.

**STEP 3** Adjust the driver's seat, steering wheel, outside rear view mirrors and seat belt shoulder anchor height to the desired positions (When memorizing the front passenger's seat, adjust the front passenger's seat to the desired positions.)

**STEP 4**



Press the "SET" button, then within 3 seconds press button "1", "2" or "3" until the signal beeps.

If the selected button has already been preset, the previously recorded position will be overwritten.

### ■ Recalling the memorized position

**STEP 1** Check that the shift lever is in "P".

**STEP 2** Turn the "ENGINE START STOP" switch to IGNITION ON mode.

**STEP 3**



Press button "1", "2" or "3" to recall the memorized position.

Front passenger's seat (with relaxation seat): When retractable table (4-seat models) or ottoman is used, rearward memories cannot be recalled.

### ■ Linking driving position memory with door unlock operation (driver's seat)

One memorized driving position can be registered to each electronic key. This driving position will then be recalled when the driver's door is unlocked using the electronic key's entry function or wireless remote control and the driver's door is opened.

► Using the wireless remote control

**STEP 1** Turn the "ENGINE START STOP" switch OFF and close the driver's door.

**STEP 2**



While pressing the desired button ("1", "2" or "3"), push  on the wireless remote control until the signal beeps.


**STEP 3** Open one of the doors.

If a door is not opened within 60 seconds after  is pressed, the doors will be locked again and the alarm will automatically be set.

In case that the alarm is triggered, immediately stop the alarm.  
(→P.114)


## ► Using the door lock switch

Carry only one of the keys (including the card key) to which you want to link the driving position. If 2 or more keys are in the vehicle, the driving position cannot be linked properly.

**STEP 1** Turn the “ENGINE START STOP” switch OFF and close the driver's door.**STEP 2**

While pressing the desired button (“1”, “2” or “3”), press the lock or unlock side on the door lock switch (either the driver or passenger side) until the signal beeps.

### Power easy access system (driver's seat)



The auto away/return function enables easy access by activating when the driver attempts to enter or exit the vehicle.

#### ► Auto away function (exiting the vehicle)

When all of the following actions have been performed, the steering wheel will move up and back to the point farthest away from the driver and the seat will move backward:

- The shift lever has been shifted to "P".
- The "ENGINE START STOP" switch has been turned OFF.
- The driver seat belt has been unfastened.

#### ► Auto return function (entering the vehicle)

When either of the following actions has been performed, the steering wheel will move toward the driver and seat will move forward:

- The "ENGINE START STOP" switch has been turned to ACCESSORY mode.
- The driver seat belt has been fastened.

### ■ When driving position memory is linked with door unlock operation

If the driver's door is opened, the driver's seat will move toward the memorized position but stop slightly beforehand to allow easy access to the vehicle. Turning the "ENGINE START STOP" switch to ACCESSORY mode or fastening the driver's seat belt moves the seat fully into the memorized position.

### ■ Canceling the linked door unlock operation

**STEP 1** Turn the "ENGINE START STOP" switch OFF and close the driver's door.

**STEP 2** Using the wireless remote control: While pushing the "SET" button, press



on the wireless remote control until the signal beeps.

Using the door lock switch: While pressing the "SET" button, press the lock or unlock side on the door lock switch until the signal beeps.

### ■ Operating the driving position memory after turning the "ENGINE START STOP" switch OFF

Driver's seat: Memorized positions (except the steering wheel position) can be activated up to 180 seconds after the driver's door is opened and 60 seconds after it is closed again, even after the "ENGINE START STOP" switch is turned OFF.

Front passenger's seat: Memorized position can be activated up to 180 seconds after the front passenger's door is opened, even after the "ENGINE START STOP" switch is turned OFF.

### ■ Stopping memorized position recall operations part-way through

To stop all memorized position recall operations part-way through, perform one of the following actions:

- Press the "SET" button.
- Press button "1", "2" or "3".

To individually stop a memorized position recall operation for a seat, the steering wheel, outside rear view mirrors, or a seat belt shoulder anchor, operate the corresponding position adjustment switch while the memorized position is being recalled. All items can still be adjusted manually even if their recall operation is stopped part-way through.

### ■ Seat operation automatic stop function (with relaxation seat)

If a front seat is likely to come into contact with the retractable table (4-seat models) or the ottoman during seat operation or activation of the auto away function, a buzzer will sound and seat slide operation will be stopped partway. (A warning message will be shown on the multi-information display.)

### ■ The auto away function for exiting the driver seat

If the seat is already close to the rearmost position, the auto away function may not operate when the driver exits the vehicle.

### ■ Customization

The distance that the driver's seat moves backward during the auto away function can be changed. (Customizable features →P. 766)

## CAUTION

### ■ Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel. Always check that there is no rear passenger or luggage behind your seat during the auto away function is activated when you stop and exit from the vehicle.

## 1-3. Adjustable components (seats, mirrors, steering wheel)

### Rear seat position memory\*

The rear seat position can be memorized and recalled with the touch of a button.

#### ■ Entering a position to memory

**STEP 1** Turn the “ENGINE START STOP” switch to IGNITION ON mode.

**STEP 2** Adjust the rear seat to the desired position.



Press the “SET” button until the signal beeps.

If the preset is being used, the previously recorded seat position will be overwritten.

#### ■ Recalling the memorized position



Press the “M” button until the signal beeps.

Relaxation seat: The memorized position will only be recalled if the ottoman is in a position higher than the memorized position. It will not move in an upward direction.

\*: If equipped

### ■ Seat return function linked to the door opening operation

When the door is opened, the rear seat will automatically return to the neutral position. This function is available for 45 seconds after the "ENGINE START STOP" switch is turned OFF.

### ■ Canceling the seat position recall or return function



Pressing the "C" button will disable the seat position recall or seat return function.

The indicator light comes on when the function is disabled.

Pressing the button again will enable the seat position recall or seat return function.

Performing either of the following cancels the seat returning operation:

- Press the "SET", "M" or "C" button.
- Press any of the seat adjustment switches.

### ⚠ CAUTION


#### ■ Seat adjustment caution

Take care during seat adjustment so that the rear passengers do not strike the front seats.

### Head restraints

Head restraints are provided for all seats.


#### ■ Front seats



- 1 Vertical adjustment  
→P. 65
- 2 Horizontal adjustment


#### ■ Outside rear seats

##### ► Power type



- 1 Vertical adjustment  
→P. 71
- 2 Side support adjustment

##### ► Manual type



- 1 Vertical adjustment  
Pull the head restraints up when raising.  
Push and hold the lock release button when lowering.
- 2 Horizontal adjustment

### 1-3. Adjustable components (seats, mirrors, steering wheel)

#### Rear center seat (5-seat models)



**1** To use

**2** To fold

#### Removing the head restraints

For removal and installation of the head restraint, contact your Lexus dealer.

#### Adjusting the height of the head restraints (except rear center seat)



Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.

#### Rear center seat

Make sure to pull the head restraint forward when using the rear center seat.

 **CAUTION**

■ **Head restraint precautions**

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- Manual type: After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

## 1-3. Adjustable components (seats, mirrors, steering wheel)

### Seat belts


Make sure that all occupants are wearing their seat belts before driving the vehicle.

#### ■ Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.

#### ■ Fastening and releasing the seat belt



##### 1 Fastening the belt

Push the tab into the buckle until a clicking sound is heard.

##### 2 Releasing the belt

Press the release button.  
If the seat belt cannot be pulled out of the retractor, firmly pull the belt and release it.

### ■ Adjusting the seat belt shoulder anchor height (front seats)




- 1 Up
- 2 Down

### ■ Seat belt comfort guide (outside rear seats)



If the shoulder belt sits close to a person's neck, slide the seat belt comfort guide forward.

### ■ Seat belt pretensioners (front and outside rear seats)



The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal collision.

The pretensioner may not activate in the event of a minor frontal impact, a side impact or a rear impact.

### Pre-collision seat belts (front seats of vehicles with pre-collision system)

If the pre-collision sensor detects that a collision is unavoidable, the pre-collision system will retract the seat belt, thus enhancing the effectiveness of the seat belt pretensioner in a crash.

The same will happen if the driver makes an emergency braking or loses control of the vehicle. (→P. 291)

#### ■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### ■ Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. (→P. 148)

#### ■ Pregnant women



Obtain medical advice and wear the seat belt in the proper way. (→P. 92)

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants. Extend the shoulder belt completely over the shoulder and position the belt across the chest. Avoid belt contact over the round part of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.

### ■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way.

### ■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 137)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 92 regarding seat belt usage.

### ■ Automatic adjustment of the seat belt shoulder anchor height (front seats)

A desired seat belt shoulder anchor height can be entered to memory and recalled automatically by the driving position memory and seat position memory. (→P. 81)

### ■ Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

### ■ Seat belt extender



If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Lexus dealer free of charge.

#### CAUTION

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failing to do so may cause death or serious injury.

##### ■ **Wearing a seat belt**

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Lexus recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

##### ■ **Adjustable shoulder anchor**

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. (→P. 93)

##### ■ **Seat belt pretensioners**

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Lexus dealer.

 **CAUTION**

1

Before driving

**■ Child restraint lock function belt precaution**

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

**■ Seat belt damage and wear**

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and tab are locked and the belt is not twisted.  
If the seat belt does not function correctly, immediately contact your Lexus dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Lexus dealer. Inappropriate handling of the pretensioner may prevent it from operating properly resulting in death or serious injury.

**■ Precaution for pre-collision seat belts**

Do not rely on the pre-collision system to avoid accidents. Always pay attention to the surrounding conditions, and drive safely and responsibly.

**■ Using a seat belt extender**

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.



#### NOTICE

##### ■ When using a seat belt extender


When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.

This helps prevent damage to the vehicle interior and the extender itself.

### 1-3. Adjustable components (seats, mirrors, steering wheel)

## Steering wheel

The steering wheel can be adjusted to a comfortable position while the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode, or when the driver’s seat belt is fastened.



- 1 Up
- 2 Down
- 3 Away from the driver
- 4 Toward the driver

1

Before driving

#### ■ Automatic adjustment of the steering position

A desired steering position can be entered to memory and recalled automatically by the driving position memory. (→P. 81)

#### ■ Power easy access system

The steering wheel and driver's seat move in accordance with “ENGINE START STOP” switch mode and the driver's seat belt condition. (→P. 84)

### ! CAUTION

#### ■ Caution while driving


Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

### 1-3. Adjustable components (seats, mirrors, steering wheel)

## Anti-glare inside rear view mirror

In automatic mode, sensors are used to detect the headlights of vehicles behind and automatically reduce the reflected light.



Turns automatic mode on/ off

The indicator comes on when automatic mode is turned on.

The mirror will revert to automatic mode each time the "ENGINE START STOP" switch is turned to IGNITION ON mode.

#### ■ To prevent sensor error



To ensure that the sensors operate properly, do not touch or cover them.

### ⚠ CAUTION

#### ■ Caution while driving

Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.

## 1-3. Adjustable components (seats, mirrors, steering wheel)

### Outside rear view mirrors

Mirror angle can be adjusted using the switch when the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode.



- 1 Selects a mirror to adjust (“L”: left or “R”: right)
- 2 Adjusts the mirror up, down, in, or out using the switch

1

Before driving

### Folding and extending the mirrors



- 1 Folds the mirrors
- 2 Extends the mirrors

Putting the outside rear view mirror folding switch in the neutral position sets the mirrors in automatic mode. Automatic mode allows the folding or extending of the mirrors to be linked to locking/unlocking of the doors.

#### ■ When the mirrors are fogged up

Turn on the mirror defoggers to defog the mirrors. (→P. 359)

#### ■ Automatic adjustment of the mirror angle

A desired mirror face angle can be entered to memory and recalled automatically by the driving position memory. (→P. 81)

### ■ Linked mirror function when reversing

The outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground. However, this function will not operate when the mirror select switch is in the neutral position (between "L" and "R").

### ■ Auto anti-glare function

When the anti-glare inside rear view mirror is set to automatic mode, the outside rear view mirrors will activate in conjunction with the anti-glare inside rear view mirror to reduce reflected light. (→P. 100)

### CAUTION

#### ■ When driving the vehicle

Observe the following precautions while driving.

Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

#### ■ When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

#### ■ When the mirror defoggers are operating

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

## 1-4. Opening and closing the windows and moon roof

### Power windows

The power windows can be opened and closed using the following switches.



- 1 Closing
- 2 One-touch closing\*
- 3 Opening
- 4 One-touch opening\*

\*: Pushing the switch in the opposite direction will stop window travel partway.



### Lock switch



Press the switch down to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.

### ■ The power windows can be operated when

The “ENGINE START STOP” switch is in IGNITION ON mode.

### ■ Door lock linked window operation

- The power windows can be closed using the entry function. (→P. 37)
- The power windows can be opened and closed using the mechanical key. (→P. 728)

### ■ Operating the power windows after turning the “ENGINE START STOP” switch OFF

The power windows can be operated for approximately 45 seconds even after the “ENGINE START STOP” switch is switched to ACCESSORY mode or turned OFF. They cannot, however, be operated once either front door is opened.

### ■ Jam protection function

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

### ■ Customization

Settings (e.g. linked door key operation) can be changed.  
(Customizable features →P. 766)

## CAUTION

### ■ Closing the windows

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- Do not allow children to operate the power windows.  
Closing a power window on someone can cause serious injury, and in some instances, even death.

### ■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the window fully closes.

## 1-4. Opening and closing the windows and moon roof

### Moon roof

Use the overhead switches to open, close, and tilt the moon roof up and down.

#### ■ Opening and closing



##### 1 Open

The moon roof stops slightly before the fully open position to reduce wind noise. Press the switch again to fully open.

##### 2 Close

Lightly press either of the moon roof switches to stop the moon roof partway.

#### ■ Tilting up and down



##### 1 Tilt up

##### 2 Tilt down

Lightly press either of the moon roof switches to stop the moon roof partway.

### ■ The moon roof can be operated when

The “ENGINE START STOP” switch is in IGNITION ON mode.

### ■ Moon roof open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument panel when the “ENGINE START STOP” switch is turned OFF and the driver's door is opened with the moon roof open.

### ■ Door lock linked moon roof operation

- The moon roof can be closed using the entry function. (→P. 37)
- The moon roof can be opened and closed using the mechanical key. (→P. 728)

### ■ Operating the moon roof after turning the “ENGINE START STOP” switch OFF

The moon roof can be operated for approximately 45 seconds even after the “ENGINE START STOP” switch is switched to ACCESSORY mode or turned OFF. It cannot, however, be operated once either front door is opened.

### ■ Jam protection function

If an object is detected between the moon roof and the frame while closing or tilting down, travel is stopped and the moon roof opens slightly.

### ■ Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

### ■ When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly

**STEP 1** Stop the vehicle.

**STEP 2** Press and hold the "CLOSE" switch.\*<sup>1</sup>

The moon roof will close, reopen and pause for approximately 10 seconds.\*<sup>2</sup> Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.

**STEP 3** Check to make sure that the moon roof is completely closed and then release the switch.

- If the moon roof tilts down but then tilts back up

**STEP 1** Stop the vehicle.

**STEP 2** Press and hold the "UP" switch\*<sup>1</sup> until the moon roof moves into the tilt up position and stops.

**STEP 3** Release the "UP" switch once and then press and hold the "UP" switch again.\*<sup>1</sup>

The moon roof will pause for approximately 10 seconds in the tilt up position.\*<sup>2</sup> Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

**STEP 4** Check to make sure that the moon roof is completely closed and then release the switch.

\*<sup>1</sup>: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

\*<sup>2</sup>: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the "CLOSE" or "UP" switch, and the moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

### ■ Customization

Settings (e.g. linked door key operation) can be changed.  
(Customizable features →P. 766)

### CAUTION

#### ■ Opening the moon roof

Observe the following precautions.

Failing to do so may cause death or serious injury.

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

#### ■ Closing the moon roof

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the moon roof is being operated.
- Do not allow children to operate the moon roof.  
Closing the moon roof on someone can cause death or serious injury.

#### ■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

## 1-5. Refueling

### Opening the fuel tank cap

Perform the following steps to open the fuel tank cap:

#### ■ Before refueling the vehicle

Close all the doors and windows, and turn the "ENGINE START STOP" switch OFF.

#### ■ Opening the fuel tank cap



Press the opener switch.



Turn the fuel tank cap slowly to open.



Hang the fuel tank cap on the back of the fuel filler door.

### Closing the fuel tank cap



When replacing the fuel tank cap, turn it until a clicking sound is heard.

After releasing your hand, the cap will turn slightly to the opposite direction.

### Fuel types

Use unleaded gasoline. (Octane rating 91 [Research Octane Number 96] or higher)

### Fuel tank capacity

Approximately 22.1 gal. (84 L, 18.4 Imp. gal.)

### When the fuel filler door opener is inoperable



The lever can be used to open the fuel filler door if the fuel filler door cannot be opened using the inside switch.

 **CAUTION****■ Refueling the vehicle**

Observe the following precautions while refueling the vehicle.  
Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it.  
A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their bodies to come close to an open fuel tank.
- Do not inhale vaporized fuel.  
Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.  
Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.  
This may cause static electricity to build up, resulting in a possible ignition hazard.

**■ When replacing the fuel cap**

Do not use anything but a genuine Lexus fuel tank cap designed for your vehicle.  
Doing so may cause a fire or other incident which may result in death or serious injury.

 **NOTICE****■ Refueling**

Do not spill fuel during refueling.  
Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

## 1-6. Theft deterrent system

### Engine immobilizer system

The vehicle's keys have built-in transponder chips that prevent the engine from starting if the key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.



The indicator light flashes after the "ENGINE START STOP" switch has been turned OFF to indicate that the system is operating.

The indicator light stops flashing after the "ENGINE START STOP" switch has been turned to ACCESSORY or IGNITION ON mode to indicate that the system has been canceled.

---

#### ■ System maintenance

The vehicle has a maintenance-free type of engine immobilizer system.

#### ■ Conditions affecting operation

Depending on surrounding environment and conditions, the engine immobilizer system may not operate properly. This may prevent the engine from starting.

(→P. 41)

### ■ Certifications for the engine immobilizer system

- For vehicles sold in the U.S.A.

FCC ID: NI4TMIMB-2

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### NOTICE

#### ■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

# Alarm

The system sounds the alarm and flashes the lights when forcible entry is detected.

### ■ Triggering of the alarm

The alarm is triggered in the following situations:

- A locked door or trunk is unlocked or opened in any way other than using the entry function, wireless remote control or key. (The doors will lock again automatically.)
- The hood is opened while the vehicle is locked.

### ■ Setting the alarm system



Close the doors, trunk and hood, and lock all doors.

The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.

### ■ Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm:

- Unlock the doors or trunk.
- Start the engine. (The alarm will be deactivated or stopped after a few seconds.)

## ■ System maintenance

The vehicle has a maintenance-free type of alarm system.

## ■ Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:

- Nobody is in the vehicle.
- The windows and moon roof are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

## ■ Triggering of the alarm

The alarm may be triggered in the following situations:  
(Stopping the alarm deactivates the alarm system.)



- A person inside the vehicle opens a door, the trunk or hood.



- The battery is recharged or replaced when the vehicle is locked.

## ■ Alarm-operated door lock

- When the alarm is operating, the doors are locked automatically to prevent intruders.
- Do not leave the key inside the vehicle when the alarm is operating, and make sure the key is not inside the vehicle when recharging or replacing the battery.

### ■ Panic mode



When  is pressed for longer than about one second, an alarm will sound for about 60 seconds and the vehicle lights flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the wireless remote control.

### NOTICE

#### ■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

### Correct driving posture

Drive in a good posture as follows:



- 1 Sit upright and well back in the seat. (→P. 65)
- 2 Adjust the position of the seat forward or backward to ensure the pedals can be reached and easily depressed to the extent required. (→P. 65)
- 3 Adjust the seatback so that the controls are easily operable.
- 4 Adjust the tilt and telescopic positions of the steering wheel downward so the SRS driver airbag is facing your chest. (→P. 99)
- 5 Adjust the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 89)
- 6 Wear the seat belt correctly. (→P. 92)

### CAUTION

#### ■ While driving


- Do not adjust the position of the driver's seat while driving.  
Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback.  
A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint, increasing the risk of death or serious injury to the driver or passenger.
- Do not place anything under the front seats.  
Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident. The adjustment mechanism may also be damaged.

#### ■ Adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.  
Fingers or hands may become jammed in the seat mechanism.

### SRS airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.



#### ► SRS front airbags

##### 1 SRS driver airbag/front passenger airbag

Can help protect the head and chest of the driver and front passenger from impact with interior components

##### 2 SRS knee airbags

Can help provide driver and front passenger protection

CLY17AD231

### ► SRS side and curtain shield airbags

#### 3 Front SRS side airbags

Can help protect the torso of the front seat occupants

#### 4 Rear SRS side airbags (power rear seat)

Can help protect the torso of the outside rear seat occupants

#### 5 SRS curtain shield airbags


Can help protect primarily the head of outside occupants



#### 6 SRS seat cushion airbag (relaxation seat)

Can help restrain the relaxation seat occupant

## SRS airbag system components



- |                                                               |                                                  |
|---------------------------------------------------------------|--------------------------------------------------|
| 1 Front passenger occupant detection system (ECU and sensors) | 9 "AIR BAG ON" and "AIR BAG OFF" indicator light |
| 2 Front passenger's seat belt buckle switch                   | 10 Curtain shield airbag sensors                 |
| 3 Knee airbags                                                | 11 SRS warning light                             |
| 4 Front passenger airbag                                      | 12 Rear side airbags                             |
| 5 Curtain shield airbags                                      | 13 Seat cushion airbag                           |
| 6 Front side airbags                                          | 14 Driver airbag                                 |
| 7 Active head restraints                                      | 15 Driver's seat belt buckle switch              |
| 8 Side and curtain shield airbag sensors                      | 16 Driver's seat position sensor                 |
|                                                               | 17 Airbag sensor assembly                        |
|                                                               | 18 Front airbag sensors                          |

Your vehicle is equipped with ADVANCED AIRBAGS designed based on US motor vehicle safety standards (FMVSS208). The airbag system controls airbag deployment power for the driver and front passenger. The driver airbag system consists of the driver seat's position sensor etc. The front passenger's airbag system consists of the front passenger occupant classification sensor etc.

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. The airbag sensor assembly consists of a safing sensor and an airbag sensor.

In certain types of severe frontal or side impacts, the SRS airbag system triggers the airbag inflators. A chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

---

### ■ SRS warning light

This warning light system monitors the airbag sensor assembly, front airbag sensors, side and curtain shield airbag sensor assemblies, curtain shield airbag sensor assemblies, driver's seat position sensor, driver's seat belt buckle switch, front passenger occupant classification system, "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioner assemblies, active head restraint assemblies, inflators, interconnecting wiring and power sources. (→P. 704)

### ■ If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the seats, and parts of the front pillar and roof side rail, may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- For Safety Connect subscribers, if the SRS airbags deploy or in the event of a severe rear-end collision, the system is designed to send an emergency call to the response center, notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 612)

### ■ SRS airbag deployment conditions (SRS front airbags and SRS seat cushion airbag)


- The SRS front airbags and SRS seat cushion airbag will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to a 12 - 18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher if the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact, or if the vehicle is involved in an underride collision (e.g. a collision in which the front of the vehicle “underrides”, or goes under, the bed of a truck, etc.).

- It is possible that in some collisions where the forward deceleration of the vehicle is very close to the designed threshold level, the SRS front airbags, SRS seat cushion airbag and the seat belt pretensioners may not activate together.
- The SRS front passenger airbag will not activate if there is no passenger sitting in the front passenger seat. However, the front passenger airbag may deploy if luggage is put in the seat, or the seat belt is fastened, even if the seat is unoccupied. (→P. 92)

### ■ Conditions under which the SRS airbags may deploy (inflate), other than a collision (SRS front airbags and SRS seat cushion airbag)

The SRS front airbags and SRS seat cushion airbag may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.



- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or vehicle falling

### ■ SRS airbag deployment conditions (SRS side airbags and SRS curtain shield airbags)

- The SRS side airbags and SRS curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by a 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at a speed of 12 - 18 mph [20 - 30 km/h]).
- The front SRS side airbag on the passenger seat will not activate if there is no passenger sitting in the front passenger seat. However, the front SRS side airbag on the passenger seat may deploy if luggage is put in the seat, even if the seat is unoccupied. (→P. 92)

### ■ Types of collisions that may not deploy the SRS airbag (SRS front airbags and SRS seat cushion airbag)

The SRS front airbags and SRS seat cushion airbag are generally not designed to inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags and SRS seat cushion airbag may occur.



- Collision from the side
- Collision from the rear
- Vehicle rollover

### ■ Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)

The SRS side airbag and curtain shield airbag system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.



- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle

The SRS side airbags and curtain shield airbags are not generally designed to inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.




- Collision from the front
- Collision from the rear
- Vehicle rollover


### ■ When to contact your Lexus dealer

In the following cases, contact your Lexus dealer as soon as possible. Do not disconnect the battery cables before contacting them.

- Any of the SRS airbags has been inflated.



- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.



- A portion of the doors is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.



- The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



- Relaxation seat: The seat cushion surface is scratched, cracked, or otherwise damaged.



- The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.
- The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked, or otherwise damaged.

## ⚠ CAUTION

### ■ SRS airbag precautions

Observe the following precautions regarding the SRS airbags.  
Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly. The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration ("NHTSA") advises:

Since the risk zone for driver airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.

### CAUTION

#### ■ SRS airbag precautions

- Slightly recline the back of the seat.  
Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.



- If the seat belt extender has been connected to the driver's seat belt buckle but the seat belt extender has not also been fastened to the latch plate of the driver's seat belt, the SRS driver's airbag system will judge that the driver is wearing the seat belt even though the seat belt has not been connected. In this case, the driver's airbag may not activate correctly in a collision, resulting in death or serious injury in the event of collision. Be sure to wear the seat belt with the seat belt extender.
- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Lexus strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are the safest for infants and children. (→P.137)

# CAUTION

## SRS airbag precautions



- Do not sit on the edge of the seat or lean against the dashboard.
- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not drive the vehicle while the driver or passenger have items resting on their knees.
- Do not lean against the door, the roof side rail or the front, side and rear pillars.
- Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle.

1

Before driving

### CAUTION

#### ■ SRS airbag precautions



- Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad or lower portion of the instrument panel.

These items can become projectiles when SRS driver, front passenger and knee airbags deploy.

- Do not attach anything to areas such as the door, windshield glass, side door glass, front and rear pillars, roof side rail or assist grip.

- Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and seriously injure or kill you, should the SRS curtain shield airbag deploy.

- If the vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags and SRS seat cushion airbag inflate as they may interfere with inflation of the SRS airbags.
- Do not strike or apply significant levels of force to the area of the SRS airbag components shown on P. 121.  
Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front pillar garnish, are damaged or cracked, have them replaced by your Lexus dealer.

 **CAUTION****■ SRS airbag precautions**

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front passenger airbag may not deploy in the event of a collision.

**■ Modification and disposal of SRS airbag system components**

Do not dispose of your vehicle or perform any of the following modifications without consulting your Lexus dealer.

The SRS airbag may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rails
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of snow plows, winches, etc. to the front grille (bull bars, kangaroo bar etc.)
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios or CD players
- Modifications to your vehicle for a person with a physical disability.

## 1-7. Safety information

### Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for front passenger.



- 1 SRS warning light
- 2 Front passenger's seat belt reminder light
- 3 "AIR BAG OFF" indicator light
- 4 "AIR BAG ON" indicator light

## Condition and operation in the front passenger occupant classification system

### ■ Adult<sup>\*1</sup>

|                             |                                                    |                        |
|-----------------------------|----------------------------------------------------|------------------------|
| Indicator/<br>warning light | "AIR BAG ON" and "AIR BAG OFF"<br>indicator lights | "AIR BAG<br>ON"        |
|                             | SRS warning light                                  | Off                    |
|                             | Front passenger's seat belt reminder light         | Flashing <sup>*2</sup> |
| Devices                     | Front passenger airbag                             | Activated              |
|                             | Side airbag on the right side<br>passenger seats   |                        |
|                             | Curtain shield airbag in the front passenger side  |                        |
|                             | Front passenger knee airbag                        |                        |
|                             | Front passenger's seat belt pretensioner           |                        |
|                             | Active head restraints                             |                        |

### ■ Child<sup>\*3</sup> or child restraint system<sup>\*4</sup>

|                             |                                                    |                                |
|-----------------------------|----------------------------------------------------|--------------------------------|
| Indicator/<br>warning light | "AIR BAG ON" and "AIR BAG OFF"<br>indicator lights | "AIR BAG<br>OFF" <sup>*5</sup> |
|                             | SRS warning light                                  | Off                            |
|                             | Front passenger's seat belt reminder light         | Flashing <sup>*2</sup>         |
| Devices                     | Front passenger airbag                             | Deactivated                    |
|                             | Side airbag on the right side<br>passenger seats   |                                |
|                             | Curtain shield airbag in the front passenger side  | Activated                      |
|                             | Front passenger knee airbag                        | Deactivated                    |
|                             | Front passenger's seat belt pretensioner           | Activated                      |
|                             | Active head restraints                             |                                |

1

Before driving

■ Unoccupied

|                             |                                                    |                 |
|-----------------------------|----------------------------------------------------|-----------------|
| Indicator/<br>warning light | "AIR BAG ON" and "AIR BAG OFF"<br>indicator lights | Not illuminated |
|                             | SRS warning light                                  | Off             |
|                             | Front passenger's seat belt reminder light         |                 |
| Devices                     | Front passenger airbag                             | Deactivated     |
|                             | Side airbag on the right side<br>passenger seats   |                 |
|                             | Curtain shield airbag in the front passenger side  | Activated       |
|                             | Front passenger knee airbag                        | Deactivated     |
|                             | Front passenger's seat belt pretensioner           |                 |
|                             | Active head restraints                             |                 |

■ There is a malfunction in the system

|                             |                                                    |                  |
|-----------------------------|----------------------------------------------------|------------------|
| Indicator/<br>warning light | "AIR BAG ON" and "AIR BAG OFF"<br>indicator lights | "AIR BAG<br>OFF" |
|                             | SRS warning light                                  | On               |
|                             | Front passenger's seat belt reminder light         | Off              |
| Devices                     | Front passenger airbag                             | Deactivated      |
|                             | Side airbag on the right side<br>passenger seats   |                  |
|                             | Curtain shield airbag in the front passenger side  | Activated        |
|                             | Front passenger knee airbag                        | Deactivated      |
|                             | Front passenger's seat belt pretensioner           | Activated        |
|                             | Active head restraints                             |                  |

- \*1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.
- \*2: In the event the front passenger does not wear a seat belt.
- \*3: When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending on his/her physique or posture.

- \*4: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 137)
- \*5: In case indicator light is not illuminated, consult this manual on how to install the child restraint system properly. (→P. 142)

### CAUTION

#### ■ Front passenger occupant classification system precautions

Observe the following precautions regarding front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt tab has not been left inserted into the buckle before someone sits in the front passenger seat.
- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, then reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the front passenger airbag, side airbag on the front passenger side and front passenger knee airbag may not activate correctly, which could cause death or serious injury in the event of collision.
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

### CAUTION

#### ■ Front passenger occupant classification system precautions

- Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the “AIR BAG OFF” indicator light to be illuminated, which indicates that the passenger’s airbags will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the “AIR BAG ON” indicator light is illuminated. If the “AIR BAG OFF” indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the “AIR BAG OFF” indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install the forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P. 142)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the detection system. In this case, contact your Lexus dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion or seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

# Child restraint systems

A child restraint system for a small child or baby must itself be properly restrained on the seat with the lap portion of the lap/shoulder belt.

The laws of all 50 states of the U.S.A. and Canada now require the use of child restraint systems.

### Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual. (→P. 142)

### Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child.

- Rear facing — Infant seat/convertible seat



- Forward facing — Convertible seat



- Booster seat



### ■ When installing the child restraint system on a rear outboard seat (power rear seat)



When you have to use a child restraint system in a rear outboard seat, adjust the following:

- The upper seatback to the rearmost position
- Relaxation seat: The seatback to the most upright position
- The seat cushion to the fully rearward position
- The head restraint to the lowmost and rearmost position

### ■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 92)

### CAUTION

#### ■ Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Lexus strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be allowed to be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seat-back as upright as possible and always move the seat as far back as possible even if "AIR BAG OFF" indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of an accident.

 **CAUTION**

1

Before driving

**■ Child restraint precautions**

- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front pillar or roof side rail from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop or an accident.

**■ Child restraint lock function belt precaution**

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

**■ When the child restraint system is not in use**

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the restraint unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop or an accident.

## 1-7. Safety information

### Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the outside rear seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.



#### Child restraint LATCH anchors

LATCH anchors are provided for the rear outside seats. (Buttons displaying the location of the anchors are attached to the seats.)



Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts except driver's seat belt) (→P. 92)




#### Anchor bracket (for top tether strap)

Anchor brackets are provided for each rear seat.

## Installation with LATCH system

**STEP 1** Vehicles with power rear seat: Adjust the seatback as upright as possible.

► Type A




**STEP 2** Widen the gap between the seat cushion and seatback slightly.

**STEP 3** Latch the hooks of the lower straps onto the LATCH anchors.

**STEP 4** If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:  
The symbol on a child restraint system indicates the presence of a lower connector system.

► Type B



**STEP 2** Widen the gap between the seat cushion and seat-back slightly.

**STEP 3** Latch the buckles onto the LATCH anchors.


**STEP 4** If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchors.

For owners in Canada:

The symbol on a child restraint system indicates the presence of a lower connector system.

**Installing child restraints using a seat belt (child restraint lock function belt)****■ Rear-facing — Infant seat/convertible seat****STEP 1**

Place the child restraint system on the rear seat facing the rear of the vehicle.

**STEP 2**

Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.

**STEP 3**


Fully extend the shoulder belt and then allow it to retract slightly in order to activate the ALR lock mode.

Lock mode allows the seat belt to retract only.

1

Before driving

### STEP 4



While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

### ■ Forward-facing — Convertible seat

#### STEP 1



Place the child restraint system on the seat facing the front of the vehicle.

#### STEP 2



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.

#### STEP 3



Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

**STEP 5** If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

### ■ Booster seat



Place the booster seat on the seat facing the front of the vehicle.



Sit the child in the booster seat. Fit the seat belt to the booster seat according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.


Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible. (→P. 92)

## Removing a child restraint installed with a seat belt



Push the buckle release button and fully retract the seat belt.

## Child restraint systems with a top tether strap



Secure the child restraint using a seat belt or a lower anchors, and move the head restraint in place at the lowest position. (→P. 89)



Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.

### ■ Laws and regulations pertaining to anchors

The LATCH system conforms to FMVSS225 or CMVSS210.2.

Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to the SAE J1819.

## ⚠ CAUTION

### ■ When installing a booster seat

To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. (→P. 94)

In ALR lock mode, the belt is locked in the position and cannot be extended, which could cause injury or discomfort to the child seated in the booster seat.

### ■ When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.



- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat.
- Adjust the front passenger seat or rear seats so that it does not interfere with the child restraint system.
- Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint on the front passenger seat, move the seat as far back as possible even if "AIR BAG OFF" indicator light is illuminated. Failure to do so may result in death or serious injury if the airbags deploy (inflate).

### CAUTION

#### ■ When installing a child restraint system

- 5-seat models: When installing a child restraint system in the rear center seat, adjust both seat seatbacks as upright as possible. The seatbacks must be adjusted to the same angle. The seatbacks must be adjusted to the same angle. Otherwise, the child restraint system cannot be securely restrained and this may cause death or serious injuries in the event of sudden braking, sudden swerving or an accident.
- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- When using the LATCH anchors for a child restraint system, adjust the seatback as upright as possible.
- Ensure that the belt and tab are securely locked and the seat belt is not twisted.
- Push and pull the child restraint system from side to side and forward to be sure it is secure.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

#### ■ Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.

#### ■ To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or an accident.

**2-1. Driving procedures**

|                                                                    |     |
|--------------------------------------------------------------------|-----|
| Driving the vehicle.....                                           | 152 |
| Engine (ignition) switch.....                                      | 161 |
| Automatic Transmission<br>(without paddle shift<br>switches) ..... | 165 |
| Automatic Transmission<br>(with paddle shift<br>switches) .....    | 169 |
| Turn signal lever .....                                            | 176 |
| Parking brake .....                                                | 177 |
| Brake Hold .....                                                   | 180 |
| Horn .....                                                         | 182 |

**2-2. Instrument cluster**

|                                        |     |
|----------------------------------------|-----|
| Gauges and meters .....                | 183 |
| Indicators and warning<br>lights ..... | 186 |
| Multi-information display .....        | 190 |

**2-3. Operating the lights and windshield wipers**

|                                       |     |
|---------------------------------------|-----|
| Headlight switch.....                 | 195 |
| Automatic High Beam.....              | 198 |
| Fog light switch .....                | 203 |
| Windshield wipers and<br>washer ..... | 204 |
| Headlight cleaner switch.....         | 207 |

**2-4. Using other driving systems**

|                                                 |     |
|-------------------------------------------------|-----|
| Cruise control.....                             | 208 |
| Dynamic radar cruise<br>control .....           | 212 |
| Intuitive parking assist.....                   | 223 |
| LKA<br>(Lane-Keeping Assist).....               | 232 |
| Electronically modulated<br>air suspension..... | 239 |
| Rear view monitor system....                    | 241 |
| Advanced parking<br>guidance system.....        | 244 |
| Driving assist systems.....                     | 285 |
| Pre-Collision System.....                       | 291 |

**2-5. Driving information**

|                           |     |
|---------------------------|-----|
| Cargo and luggage .....   | 300 |
| Vehicle load limits ..... | 303 |
| Winter driving tips ..... | 305 |
| Trailer towing .....      | 309 |
| Dinghy towing.....        | 310 |

## 2-1. Driving procedures

# Driving the vehicle

The following procedures should be observed to ensure safe driving.

### ■ Starting the engine (→P. 161)

### ■ Driving

**STEP 1** With the brake pedal depressed, shift the shift lever to "D".  
(→P. 165, 169)

**STEP 2** Release the parking brake.  
(→P. 177)

**STEP 3** Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

### ■ Stopping

**STEP 1** With the shift lever in "D", depress the brake pedal.

**STEP 2** If necessary, set the parking brake.

When the vehicle is stopped for an extended period of time, shift the shift lever to "P" or "N".  
(→P. 165, 169)

### ■ Parking the vehicle

**STEP 1** With the shift lever in "D", depress the brake pedal.

**STEP 2** Set the parking brake.  
(→P. 177)

**STEP 3** Shift the shift lever to "P".  
(→P. 165, 169)

**STEP 4** Press the "ENGINE START STOP" switch to stop the engine.

**STEP 5** Lock the door, making sure that you have the electronic key on your person.

## Starting on a steep uphill

**STEP 1** Set the parking brake and shift the shift lever to "D".

**STEP 2** Gently depress the accelerator pedal.

**STEP 3** Release the parking brake.

**■ Starting off on a hill**

Hill-start assist control will operate. (→P. 285)

**■ Driving in the rain**

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

**■ Breaking in your new Lexus**

To extend the life of the vehicle, the following precautions are recommended to observe:

- For the first 186 miles (300 km):  
Avoid sudden stops.
- For the first 621 miles (1000 km):
  - Do not drive at extremely high speeds.
  - Avoid sudden acceleration.
  - Do not drive continuously in the low range in the "S" (without paddle shift switches) or "M" (with paddle shift switches) position.
  - Do not drive at a constant speed for extended periods.

**■ Drum-in-disc type parking brake system**

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Lexus dealer perform the bedding down.

**■ Operating your vehicle in a foreign country**

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. (→P. 743)

### CAUTION

#### ■ When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

#### ■ When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
  - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident that could result in death or serious injury.
  - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
  - Make sure to keep a correct driving posture even when moving the vehicle only slightly, allowing you to depress the brake and accelerator pedals properly.
  - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials.
- Do not let the vehicle roll backwards while the shift lever is in a driving position, or roll forward while the shift lever is in "R".  
Doing so may result in an accident or damage to the vehicle.
- If the smell of exhaust is noticed inside the vehicle, open the windows and check that the trunk is closed. Large amounts of exhaust in the vehicle can cause driver drowsiness and an accident, resulting in death or a serious health hazard. Have the vehicle inspected by your Lexus dealer immediately.
- Do not under any circumstances shift the shift lever to "P" or "R" while the vehicle is moving.  
Doing so can cause significant damage to the transmission system and may result in a loss of vehicle control.
- Do not shift the shift lever to "N" while the vehicle is moving.  
Doing so may cause insufficient engine braking and lead to an accident.
- Do not turn the engine off while driving.  
The power steering system will not operate properly if the engine is not running.

## CAUTION

- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.  
Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P. 165, 169)
  - When stopped on an inclined surface, use the brake pedal and parking brake to prevent the vehicle from rolling backward or forward and causing an accident.
  - Do not adjust the position of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.  
Doing so may result in a loss of vehicle control that can cause accidents that may result in death or serious injury.
  - Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle, as this may result in death or serious injury.
  - Do not drive the vehicle off-road.  
This is not a AWD vehicle designed for real off-road driving. Proceed with all due caution if it becomes unavoidable to drive off-road.
  - Do not drive across river crossings or through other bodies of water.  
This may cause electric/electronic components to short circuit, damage the engine or cause other serious damage to the vehicle.
  - Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has high-speed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.
- **When driving on slippery road surfaces**
- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle, resulting in an accident.
  - Sudden changes in engine speed, such as engine braking caused by up-shifting or down-shifting, may cause the vehicle to skid, resulting in an accident.
  - After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected, resulting in an accident.

### CAUTION

#### ■ When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

#### ■ When the vehicle is stopped

- Do not race the engine.

If the vehicle is in any gear other than “P” or “N”, the vehicle may accelerate suddenly and unexpectedly, and may cause an accident.

- Do not leave the vehicle with the engine running for a long time.

If such a situation cannot be avoided, park the vehicle in an open space and check that exhaust fumes do not enter the vehicle interior.

- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.

- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.

- Avoid revving or racing the engine.

Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

## CAUTION

### ■ When the vehicle is parked

- Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of eye glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Always apply the parking brake, shift the shift lever to "P", stop the engine and lock the vehicle.  
Do not leave the vehicle unattended while the engine is running.
- Do not touch the exhaust pipes and the rear bumper diffusers while the engine is running or immediately after turning the engine off.  
Doing so may cause burns.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.

### ■ Exhaust gases

Exhaust gases include harmful carbon monoxide (CO) that is colorless and odorless. Inhaling exhaust gases may lead to death or a serious health hazard.

- If the vehicle is in a poorly ventilated area, stop the engine. In a closed area, such as a garage, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.
- The exhaust should be checked occasionally. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Lexus dealer. Failure to do so may allow exhaust gases to enter the vehicle, resulting in death or a serious health hazard.

### CAUTION

#### ■ When taking a nap in the vehicle

Always turn the engine off. Otherwise, you may accidentally move the shift lever or depress the accelerator pedal, which could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

#### ■ When braking the vehicle

- When the brakes are wet, drive more cautiously.

Braking distance increases when the brakes are wet, and may cause one side of the vehicle to brake differently than the other side. Also the parking brake may not securely hold the vehicle.

- If the electronically controlled brake system does not operate, do not follow other vehicles closely and avoid downhill or sharp turns that require braking. In this case, even though the brakes still operate, the brake pedal should be depressed more firmly than usual. Braking distance also becomes longer.

- The brake system consists of 3 individual hydraulic systems: if one of the systems fails, the others will still operate. In this case, the brake pedal should be depressed more firmly than usual and braking distance becomes longer. If this happens, do not continue to drive the vehicle. If the brake system warning light (red indicator) comes on together with buzzer sound while driving, immediately stop the vehicle in a safe place and contact your Lexus dealer.

#### ■ If the vehicle becomes stuck or bogged (AWD models)

Do not spin the wheels recklessly when any of the tires is up in the air, or stuck in sand or mud, etc. This may damage the drive system components or propel the vehicle forward (or in another direction) and cause an accident.

 NOTICE

### ■ When driving the vehicle

Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

### ■ When parking the vehicle

Always put the shift lever in "P". Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

### ■ Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for a long time.  
Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

### ■ If a brake pad wear warning message is displayed

Have your Lexus dealer check and replace the brake pads as soon as possible. The rotor damage can result if the pads are not replaced when needed.

Moderate levels of the brake pad and disc wear allow enhanced braking power. As a result, the discs may wear more quickly than conventional brake discs. Therefore, when replacing the brake pads, Lexus recommends that you also have the thickness of the discs measured.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

### ■ If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds.
- The vehicle will behave abnormally.

Information on what to do in case of a flat tire. (→P. 715)

### NOTICE

#### ■ When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Lexus dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transmission, differential, etc.
- Lubricant condition for the propeller shaft, bearings and suspension joints (where possible) and the function of all joints, bearings, etc.

## 2-1. Driving procedures

### Engine (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the engine or changes “ENGINE START STOP” switch modes.

#### ■ Starting the engine


**STEP 1** Check that the parking brake is set.

**STEP 2** Check that the shift lever is set in “P”.

**STEP 3** Sit in the driver’s seat and firmly depress the brake pedal.

The “ENGINE START STOP” switch indicator turns green.

**STEP 4**



Press the “ENGINE START STOP” switch.

The engine can be started from any mode.

### ■ Changing “ENGINE START STOP” switch mode

Modes can be changed by pressing the “ENGINE START STOP” switch with the brake pedal released. (The mode changes each time the switch is pressed.)



#### 1 OFF\*

The emergency flashers can be used.

#### 2 ACCESSORY mode

Some electrical components such as the audio system can be used.

The “ENGINE START STOP” switch indicator turns amber.

#### 3 IGNITION ON mode

All electrical components can be used.

The “ENGINE START STOP” switch indicator turns amber.

\*: If the shift lever is in a position other than “P” when turning off the engine, the “ENGINE START STOP” switch will be turned to ACCESSORY mode, not to OFF.

### ■ If the engine does not start

The engine immobilizer system may not have been deactivated. (→P. 112)

### ■ When the steering lock cannot be released



The green indicator light on the “ENGINE START STOP” switch will flash and a message will be shown on the multi-information display. Press the “ENGINE START STOP” switch again while turning the steering wheel left and right.

### ■ When the “ENGINE START STOP” switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

### ■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than an hour with the shift lever in “P”, the “ENGINE START STOP” switch will automatically turn OFF.

### ■ Electronic key battery depletion

→P. 43

### ■ When the electronic key battery is discharged

→P. 671

### ■ Conditions affecting operation

→P. 41

### ■ Note for the entry function

→P. 44

### CAUTION

#### ■ When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

#### ■ Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, push and hold the "ENGINE START STOP" switch for more than 3 seconds. However, do not touch the "ENGINE START STOP" switch while driving except in an emergency. If the engine stops while the vehicle is being driven, this could lead to an unexpected accident.

### NOTICE

#### ■ To prevent the battery from being discharged

Do not leave the "ENGINE START STOP" switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.

#### ■ When starting the engine

- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have the engine checked immediately by your Lexus dealer.

2-1. Driving procedures

Automatic Transmission (without paddle shift switches)

Select a shift position appropriate for the driving conditions.

■ Shifting the shift lever



← While the “ENGINE START STOP” switch is in IGNITION ON mode, depress the brake pedal and move the shift lever.

■ Shift position uses


| Shift position | Function                                 |
|----------------|------------------------------------------|
| P              | Parking the vehicle/starting the engine  |
| R              | Reversing                                |
| N              | Neutral                                  |
| D              | Normal driving <sup>*1</sup>             |
| S              | “S” mode driving <sup>*2</sup> (→P. 167) |

<sup>\*1</sup>: To improve fuel efficiency and reduce noises, set the shift lever in the “D” position for normal driving.

<sup>\*2</sup>: Selecting shift ranges using “S” mode restricts the upper limit of the possible gear ranges, controls engine braking forces, and prevents unnecessary upshifting.


### ■ Selecting a driving mode

The following modes can be selected in any shift position to suit driving conditions:



- 1 Power mode  
For powerful acceleration and driving in mountainous regions
- 2 Normal mode
- 3 Snow mode  
For accelerating and driving on slippery road surfaces, such as on snow

To cancel power mode or snow mode, press the same side of the switch again.



- 4 Eco mode  
When eco mode is turned on, the "ECO MODE" indicator will come on and the multi-information display will change to the Eco Driving Indicator Zone Display and Average fuel consumption screen. (→P. 191)  
Pressing the "ECO MODE" switch again turns eco mode off.

## Changing shift ranges in "S" mode

Shift the shift lever to the "S" position and operate the shift lever.



- 1 Upshifting
- 2 Downshifting

The initial shift range in "S" mode is automatically set to "4", "5", "6" or "7" according to vehicle speed. However, the initial shift range may be set to "2" or "3" if the AI-SHIFT has operated while the shift lever was in the "D" position. (→P. 168)

### Shift ranges and their functions

| Meter display | Function                                                                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|
| S2 - S8       | A gear in the range between "1" and the selected gear is automatically chosen depending on vehicle speed and driving conditions |
| S1            | Setting the gear at "1"                                                                                                         |

A lower shift range will provide greater engine braking forces than a higher shift range.

### "S" mode

- When the shift range is "6" or lower, holding the shift lever toward "+" sets the shift range to "8."
- When the shift range is "6" or higher, moving the shift lever toward "-" may change down by 2 shift ranges or more depending on driving conditions.
- To prevent the engine from over-revving, upshifting may automatically occur.

### ■ Downshifting restrictions warning buzzer (in the “S” mode)

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

### ■ When driving with the cruise control system

Engine brake will not operate in the “S” mode, even when downshifting to “7”, “6”, “5” or “4”. (→P. 208, 212)

### ■ Snow mode automatic deactivation

Snow mode is automatically deactivated if the “ENGINE START STOP” switch is turned OFF after driving in snow mode.

### ■ Eco mode

When the vehicle is driven in eco mode, vehicle driving force and operation of the air conditioning system is controlled to improve fuel efficiency. If eco mode is turned on when the driving mode is in power mode or snow mode, power mode or snow mode will be canceled.

### ■ If the shift lever cannot be shifted from “P”

→P. 725

### ■ AI-SHIFT

The AI-SHIFT automatically selects the optimal gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in the “D” and “S” position.

### CAUTION

#### ■ When driving on slippery road surfaces

Be careful of downshifting and sudden acceleration, as this could result in the vehicle skidding to the side or spinning.

2-1. Driving procedures

Automatic Transmission (with paddle shift switches)

Select a shift position appropriate for the driving conditions.

Shifting the shift lever



While the “ENGINE START STOP” switch is in IGNITION ON mode, depress the brake pedal and move the shift lever.

Shift position uses


| Shift position | Function                                |
|----------------|-----------------------------------------|
| P              | Parking the vehicle/starting the engine |
| R              | Reversing                               |
| N              | Neutral                                 |
| D              | Normal driving*                         |
| M              | “M” mode driving (→P.173)               |

\*: To improve fuel efficiency and reduce noises, set the shift lever in the “D” position for normal driving.

| Shift position                                                                    | Meter display                                                                                                          | Function                            | Purpose                                                                              |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|-------------------------------------|--------------------------------------------------------------------------------------|
|  |                                       | Normal “D” position driving         | Gears between “1” and “8” are automatically selected according to driving conditions |
|                                                                                   | <br>(paddle shift switches activated) | Shift range selection (→P. 172)     | Allows optimum use of engine braking                                                 |
|  |                                       | Individual gear selection (→P. 173) | Allows the driver to select gears for sporty driving                                 |

## ■ Selecting a driving mode

The following modes can be selected in any shift position to suit driving conditions:



### 1 Power mode


For powerful acceleration and driving in mountainous regions

### 2 Normal mode

### 3 Snow mode

For accelerating and driving on slippery road surfaces, such as on snow

To cancel power mode or snow mode, press the same side of the switch again.



### 4 Eco mode

When eco mode is turned on, the "ECO MODE" indicator will come on and the multi-information display will change to the Eco Driving Indicator Zone Display and Average fuel consumption screen. (→P.191)

Pressing the "ECO MODE" switch again turns eco mode off.

Selecting shift ranges in the “D” position

To drive using temporary shift range selection, operate the “-” paddle shift switch. The shift range can then be selected by operating the “-” and “+” paddle shift switches. Changing the shift range allows restriction of the highest gear, preventing unnecessary upshifting and enabling the level of engine braking force to be selected.



1 Higher shift range

2 Lower shift range

The selected shift range, from “1” to “8”, will be displayed in the meter.

To return to normal “D” position driving, the “+” paddle shift switch must be held down for a period of time.

Shift ranges and their functions

| Meter display | Function                                                                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|
| D2 - D8       | A gear in the range between “1” and the selected gear is automatically chosen depending on vehicle speed and driving conditions |
| D1            | Setting the gear at “1”                                                                                                         |

A lower shift range will provide greater engine braking forces than a higher shift range.

## Selecting gears in the “M” position

To enter “M” mode, shift the shift lever to the “M” position. Gears can then be selected by operating the shift lever or paddle shift switches, allowing you to drive in the gear of your choosing.



**1** Upshifting

**2** Downshifting

The gear changes once every time the shift lever or paddle shift switch is operated.

The selected gear, from “1” to “8”, will be displayed in the meter.

When in the “M” position, the gear will not change unless the shift lever or paddle shift switches are operated.

However, even when in the “M” position, the gears will be automatically changed in the following situations:

- When vehicle speed drops (downshift only).
- When the automatic transmission fluid or engine coolant temperature is low.
- When the automatic transmission fluid temperature is high.

### **■ Gear functions**

A selected gear from “M1” through “M8” will be set.

### ■ When the “-” paddle shift switch is operated in the “D” position

- When the “-” paddle shift switch is operated in the “D” position, a shift range will be automatically selected. The highest gear of the first shift range will be one gear lower than the gear in use during normal “D” position driving.
- If the “-” paddle shift switch is operated when in range “6” or above, the shift range may be lowered by two ranges or more in accordance with the driving conditions.

### ■ Automatic deactivation of shift range selection in the “D” position

Shift range selection in the “D” position will be deactivated in the following situations:

- When the vehicle comes to a stop
- If the accelerator pedal is depressed for more than a certain period of time in “6”, “7” or “8” without changing the shift range

### ■ Downshift restrictions warning buzzer

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switch is operated. (A buzzer will sound twice.)

### ■ When driving with the cruise control system

Engine braking will not occur during shift range selection in the “D” position, even when downshifting to range “7”, “6”, “5” or “4”. (→P. 208, 212)

### ■ Power mode and snow mode automatic deactivation

Power mode and snow mode are automatically deactivated if the “ENGINE START STOP” switch is turned OFF after driving in power mode or snow mode.

### ■ Eco mode

When the vehicle is driven in eco mode, vehicle driving force and operation of the air conditioning system is controlled to improve fuel efficiency. If eco mode is turned on when the driving mode is in power mode or snow mode, power mode or snow mode will be canceled.

### ■ If the shift lever cannot be shifted from “P”

→P. 725

### ■ If the automatic transmission fluid temperature warning message is displayed

If the automatic transmission fluid temperature warning message is displayed while driving, make sure you return to normal "D" position driving and reduce speed by easing off the accelerator pedal. Stop the vehicle in a safe place, shift the shift lever to the "P" position and let the engine idle until the warning message goes out.

When the warning message goes out, the vehicle can be driven again.

If the warning message does not go out after waiting a while, have your vehicle inspected by your Lexus dealer.

### ■ AI-SHIFT

The AI-SHIFT automatically selects the optimal gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in the "D" position. (Shifting the shift lever to the "M" position cancels the function.)


### CAUTION

#### ■ When driving on slippery road surfaces

Be careful of downshifting and sudden acceleration, as this could result in the vehicle skidding to the side or spinning.

## 2-1. Driving procedures

### Turn signal lever



- 1 Right turn
- 2 Left turn
- 3 Lane change to the right (move the lever partway and then release it)

The right hand signals will flash 3 times.

- 4 Lane change to the left (move the lever partway and then release it)

The left hand signals will flash 3 times.

#### ■ Turn signals can be operated when

The "ENGINE START STOP" switch is in IGNITION ON mode.

#### ■ If the indicators flash faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

#### ■ If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

#### ■ To discontinue flashing of the turn signals during a lane change

Operate the lever in the opposite direction.

#### ■ Customization

The number of times the turn signals flash during a lane change can be changed. (Customizable features→P. 766)

## 2-1. Driving procedures

### Parking brake

For the parking brake, an electrical parking brake system is adopted.

#### ■ Manual mode



#### 1 Sets the parking brake

If the parking brake switch is operated when the "ENGINE START STOP" switch is not in IGNITION ON mode, the parking brake indicator light will come on and stay on for a while.

Press and hold the parking brake switch if an emergency occurs and it is necessary to operate the parking brake while driving.

#### 2 Releases the parking brake

Operate the parking brake switch while depressing the brake pedal. Make sure that the parking brake indicator light goes off.

### ■ Automatic mode



#### On/off

The parking brake is set automatically according to shift lever operation.

Operate the shift lever with the brake pedal depressed.

- When the shift lever is moved out of "P"  
The parking brake will be released.
- When the shift lever is moved into "P"  
The parking brake will be set.

---

### ■ Parking brake operation

- When the "ENGINE START STOP" switch is not in IGNITION ON mode, the parking brake cannot be released using the parking brake switch.
- When the "ENGINE START STOP" switch is not in IGNITION ON mode, automatic mode (automatic brake setting and releasing) is not available.
- If the parking brake is operated repeatedly over a short period of time, the system may restrict operation to prevent overheating. If this happens, refrain from operating the parking brake. Normal operation will return after about 1 minute.

### ■ Parking brake indicator light

When the "ENGINE START STOP" switch is turned OFF with the parking brake set, the parking brake indicator light will stay on for about 15 seconds. This does not indicate a malfunction.

### ■ Parking brake operation sound

When the parking brake operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

### ■ When there is a malfunction in the system

Warning lights and/or warning messages will turn on or flash. (→P. 703, 712)  
Depending on the condition, the parking brake indicator light may flash.

### ■ Usage in winter time

See "Winter driving tips" for parking brake usage in winter time. (→P. 305)



## NOTICE

### ■ When parking the vehicle

Before you leave the vehicle, set the parking brake, shift the shift lever to "P" and make sure that the vehicle does not move.

### ■ When the system malfunctions

Stop the vehicle in a safe place and check the warning messages.

### ■ When the parking brake cannot be released due to a malfunction


Use the parking brake release tool to manually release the parking brake.  
(→P. 726)

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

## 2-1. Driving procedures

# Brake Hold

The brake hold system keeps the brake applied when the shift lever is in "D", "N", or "S" (without paddle shift switches) or "M" (with paddle shift switches) with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in "D", "S" or "M" to allow smooth start off.



Turns the brake hold system on.

The brake hold standby indicator comes on. While the system is holding the brake, the brake hold operated indicator light comes on.

### ■ Brake hold system operating conditions

The brake hold system cannot be turned on in the following conditions:

- The trunk or hood is not closed.
- The driver's door is not closed.
- The driver is not wearing the seat belt.

If any of the conditions above are detected when the brake hold system is enabled, the system will turn off and the brake hold operated indicator light will go off. In addition, if any of the conditions are detected while the system is holding the brake, a warning buzzer will sound and a message will be shown on the multi-information display. The parking brake will then be set automatically.

### ■ Brake hold function

- If the brake pedal is left released for a period of about 3 minutes after the system has started holding the brake, the parking brake will be set automatically. In this case, a warning buzzer sounds and a message is shown on the multi-information display.
- To turn the system off while the system is holding the brake, firmly depress the brake pedal and press the switch again.
- The brake hold function may not hold the vehicle when the vehicle is on a steep incline. In this situation, it may be necessary for the driver to apply the brakes. The multi-information display will inform the driver of this situation.

### ■ When the parking brake is set automatically while the system is holding the brakes

The parking brake will not be released automatically. Release the parking brake by operating the parking brake switch, making sure that the parking brake indicator light goes off. (→P. 177)

### ■ When there is a malfunction in the system

Warning lights and/or warning messages will turn on or flash. (→P. 703, 712)

## CAUTION

### ■ When stopped on a slippery road

The system cannot stop the vehicle when the gripping ability of the tires has been exceeded. Do not use the system when stopped on a slippery road.

## NOTICE

### ■ When parking the vehicle

The brake hold system is not designed for use when parking the vehicle for a long period of time. Turning the "ENGINE START STOP" switch OFF while the system is holding the brake may release the brake, which would cause the vehicle to move. When operating the "ENGINE START STOP" switch, depress the brake pedal, set the parking brake and shift the shift lever to "P".

# Horn



To sound the horn, press on or close to the  mark.

# Gauges and meters



The units used on the speedometer and the tachometer gauge display may differ depending on the model/type.

The following gauges, meters and display illuminate when the “ENGINE START STOP” switch is in IGNITION ON mode.

### 1 Tachometer

Displays the engine speed in revolutions per minute

### 2 Multi-information display

→P. 190

### 3 Speedometer

Displays the vehicle speed

### 4 Fuel gauge

Displays the quantity of fuel remaining in the tank

### 5 Trip meter and trip meter reset buttons

### 6 Odometer


Displays the total distance the vehicle has been driven

### 7 Trip meter

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters “A” and “B” can be used to record and display different distances independently.

- 8 Shift position and shift range  
→P. 165, 169
- 9 Instrument panel light control buttons
- 10 Engine coolant temperature gauge  
Displays the engine coolant temperature

### Trip meter and trip meter reset buttons



- 1 Changes the display
- 2 Resets the trip meter currently displayed to "0"

### Instrument panel light control buttons

The brightness of the instrument panel lights can be adjusted.



- 1 Darker
- 2 Brighter

 NOTICE**■ To prevent damage to the engine and its components**

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 735)

## 2-2. Instrument cluster

### Indicators and warning lights

The indicator and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

► Instrument cluster



The units used on the speedometer and the tachometer gauge display may differ depending on the model/type.

► Center panel (without touch screen)



► Center panel (with touch screen)



■ Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator  
(→P. 176)



Cruise control indicator  
(→P. 208, 212)



Headlight high beam indicator (→P. 195)



\* "AFS OFF" indicator  
(→P. 196)



(if equipped)

\* Automatic High Beam indicator (→P. 198)



(Flashes)

\* Slip indicator  
(→P. 286)



(U.S.A.)

Headlight indicator  
(→P. 195)



\* VSC off indicator  
(→P. 287)



(Canada)

Tail light indicator  
(→P. 195)



\* Brake hold standby indicator (→P. 180)



Front fog light indicator  
(→P. 203)



\* Brake hold operated indicator (→P. 180)



“ECT PWR” indicator  
(→P. 166)



“ECT SNOW” indicator  
(→P. 166)



Eco Driving Indicator  
Light (→P. 193)



“ECO MODE” indicator  
(→P. 166, 171)



(if equipped)

“SPORT” mode indicator  
(→P. 239)



(if equipped)

“COMFORT” mode indi-  
cator (→P. 239)



(U.S.A.)

Parking brake indicator  
(→P. 177)



(Canada)

Parking brake indicator  
(→P. 177)



(if equipped)

Lane keeping assist indi-  
cator (→P. 232)



(without  
touch  
screen)

“AIR BAG ON” and “AIR  
BAG OFF” indicators  
(→P. 132)



(with touch  
screen)

“AIR BAG ON” and “AIR  
BAG OFF” indicators  
(→P. 132)




(if equipped)

“HEIGHT HIGH” indica-  
tor (→P. 239)

■ Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems. (→P. 703)



\*: These lights turn on when the “ENGINE START STOP” switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Lexus dealer.


⚠ CAUTION

■ If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS airbag warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Lexus dealer immediately if this occurs.

# Multi-information display

The multi-information display presents the driver with a variety of driving-related data, including the current outside air temperature.



### ● Trip information (→P. 191)

Displays cruising range, fuel consumption and other cruising related information.

### ● Intuitive parking assist display (if equipped)\* (→P. 223)

### ● Dynamic radar cruise control display (if equipped)\* (→P. 212)


### ● Warning messages (→P. 712)

Automatically displayed when a malfunction occurs in one of the vehicle's systems.

\*: Automatically displayed when the system is used.

## Trip information

### ► With telephone switch



#### 1 "DISP" switch

Display items can be switched by pressing the "DISP" switch.

#### 2 "RESET" switch

### ► Without telephone switch



#### 1 "DISP" switch

Display items can be switched by pressing the "DISP" switch.

#### 2 "RESET" switch

## ■ Outside temperature

Displays the outside air temperature

The temperature range that can be displayed is from -40°F (-40°C) to 122°F (50°C).

## ■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

### ■ **Eco Driving Indicator Zone Display and Average fuel consumption**

Displays Eco Driving Indicator Zone Display and the average fuel consumption since the function was reset.

The function can be reset by pressing the "RESET" switch when the average fuel consumption is displayed.

On vehicles with a navigation system, the "Past Record" screen on the touch screen will also be updated.

For details on the "Past Record" screen, refer to the "Navigation System Owner's Manual".

### ■ **Current fuel consumption**

Displays the current rate of fuel consumption

### ■ **Average fuel consumption after refueling**

Displays the average fuel consumption since the vehicle was last refueled

### ■ **Distance after refueling**

Displays the distance the vehicle has been driven since the vehicle was last refueled

### ■ **Elapsed time**

Displays the elapsed time since it was last reset

The function can be reset by pressing the "RESET" switch when the elapsed time is displayed.

### ■ **Average vehicle speed**

Displays the average vehicle speed since the function was reset

The function can be reset by pressing the "RESET" switch when the average vehicle speed is displayed.

### ■ Tire inflation pressure

Displays inflation pressure of each tire. There is no correlation between the order of the displayed values and the tire positions

It may take a few minutes to display the tire inflation pressure after the "ENGINE START STOP" switch is turned to IGNITION ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted.

### ■ Eco Driving Indicator customization


Eco Driving Indicator Light can be disabled.

Eco Driving Indicator Light can be enabled or disabled by pressing the "DISP" switch for longer than 1 second when the Eco Driving Indicator customization screen is displayed.

### ■ System check display

After switching the "ENGINE START STOP" switch to IGNITION ON mode, "SYSTEM CHECK" is displayed while system operation is checked. When the system check is complete, the normal screen will return.

### ■ Eco Driving Indicator



- 1 Eco Driving Indicator Light**  
During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- 2 Eco Driving Indicator Zone Display**  
Suggests Zone of Eco driving with current Eco driving ratio based on accelerator pedal operation.
- 3 Zone of Eco driving**
- 4 Eco driving ratio based on accelerator pedal operation**  
In case over-use of the accelerator causes the vehicle to exceed Zone of Eco driving, the right of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.

### ► Without paddle shift switches

Eco Driving Indicator will operate when the vehicle is being driven with the shift lever in "D". Eco Driving Indicator will not operate when the vehicle is in power mode or snow mode.

### ► With paddle shift switches

Eco Driving Indicator will operate when the vehicle is being driven with the shift lever in "D" and the paddle shift switches not used. Eco Driving Indicator will not operate when the vehicle is in power mode or snow mode.

### ■ Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

### ■ To turn off the background images on the trip information screen

When information is displayed together with a background image, press the "DISP" switch for 1 second or more.

Pressing the switch again for longer than 1 second turns on the background images.

### ■ Tire inflation pressure

Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using other gauges.

### ■ Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem to continue using the display.


### ■ Customization

Setting of available languages can be changed. (Customizable features → P. 766)

## 2-3. Operating the lights and windshield wipers

### Headlight switch

The headlights can be operated manually or automatically.




 The side marker, parking, tail, license plate and instrument panel lights turn on.

 The headlights and all lights listed above turn on.

**AUTO** The headlights, other exterior lights and instrument panel lights turn on and off automatically. (When the "ENGINE START STOP" switch is in IGNITION ON mode)

### Turning on the high beam headlights



**1** With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

**2** Pull the lever toward you to turn on the high beams.

Release to turn them off. You can flash the high beams with the headlights on or off.

### AFS

AFS (Adaptive Front-lighting System) improves visibility at intersections and on curves by automatically adjusting the direction of light axis of the headlights according to vehicle speed and the degree of the tire angle that are controlled by steering input.

Operates at speeds of 6 mph (10 km/h) or higher.

#### ■ Deactivating AFS



#### On/off

The indicator turns on when the AFS is deactivated.

#### ■ Daytime running light system

To make your vehicle more visible to other drivers, the headlights turn on automatically (at a reduced intensity) whenever the engine is started and the parking brake is released. Daytime running lights are not designed for use at night.

#### ■ Headlight control sensor



The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.

### ■ Automatic light off system

- When the headlights come on: The headlights turn off 30 seconds after a door is opened and closed if the “ENGINE START STOP” switch has been switched to ACCESSORY mode or turned OFF. (The lights turn off immediately if  on the key is pressed after all doors are locked.)
- When only the tail lights come on: The tail lights turn off automatically if the “ENGINE START STOP” switch is switched to ACCESSORY mode or turned OFF and driver’s door is opened.

To turn the lights on again, switch to IGNITION ON mode, or turn the light switch off once and then back to the  or  position.

### ■ Automatic headlight leveling system

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

### ■ If the “AFS OFF” indicator flashes...

It may indicate a malfunction in the system. Contact your Lexus dealer.

### ■ Customization

Settings (e.g. light sensor sensitivity) can be changed.  
(Customizable features → P. 766)

### NOTICE

### ■ To prevent the battery from being discharged

Do not leave the lights on longer than necessary when the engine is not running.

## 2-3. Operating the lights and windshield wipers

### Automatic High Beam\*


The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.

#### ■ Activating the Automatic High Beam system

##### STEP 1



Head light switch in "AUTO" position.



CLY23AH103

##### STEP 2



Push the lever away from you.

The Automatic High Beam indicator will come on when the headlights are turned on automatically to indicate that the system is active.

CLY23AD152

\*: If equipped

### ■ High beam automatic turning on or off conditions

When all of the following conditions are fulfilled, high beam will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 20 mph (32 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.

If any of the following conditions are fulfilled, high beam will be automatically turned off:

- Vehicle speed drops below approximately 20 mph (32 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.

### ■ Turning the high beam on/off manually

#### ► Switching to low beam



Pull the lever to original position.

### ► Switching to high beam



Turn the light switch to  position.

### ■ The Automatic High Beam can be operated when

The “ENGINE START STOP” switch is in IGNITION ON mode.

### ■ Camera sensor detection information

- High beam may not be automatically turned off in the following situations:
  - When oncoming vehicles suddenly appear from a curve.
  - When the vehicle is cut in front of by another.
- High beam may be turned off if an oncoming vehicle that is using fog lights without using the headlights is detected.
- House lights, street lights, red traffic signals, and illuminated billboards or signs may cause the high beam to turn off.
- The following factors may affect the amount of time taken to turn high beam on or off:
  - The brightness of headlights, fog lights, and tail lights of oncoming and preceding vehicles
  - Road conditions (wetness, ice, snow etc.)
  - The number of passengers and amount of baggage
- High beam may be turned on or off when unexpected by the driver.
- In the situations below, the system may not be able to correctly detect the surrounding brightness levels, and may flash or expose nearby pedestrians to the high beam. Therefore, you should consider turning the high beams on or off manually rather than relying on the Automatic High Beam system.

- In bad weather (rain, snow, fog, sandstorms etc.)
- The windshield is obscured by fog, mist, ice, dirt etc.
- The windshield is cracked or damaged.
- The inside rear view mirror or camera sensor is deformed or dirty.
- Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
- Vehicles ahead have headlights that are either switched off, dirty, are changing color, or have are not aimed properly.
- When driving through an area of intermittently changing brightness and darkness
- When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.)
- When frequently and repeatedly taking curves or driving on a winding road
- There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
- The vehicle's headlights are damaged or dirty.
- The vehicle is listing or tilting, due to a flat tire, a trailer being towed etc.
- The Automatic High Beam indicator is flashing.
- The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby.

#### ■ If the Automatic High Beam indicator flashes

It may indicate a malfunction in the system. Contact your Lexus dealer.

#### ■ Temporary lowering sensor sensitivity

The sensitivity of the sensor can be temporarily lowered.

To lower the sensitivity, push and hold the "AUTO" button on the inside rear view mirror for 15 to 20 seconds, and release. The indicator light on the inside rear view mirror will flash to indicate that the sensitivity has been lowered.

When the "ENGINE START STOP" switch is turned off, the sensitivity will be returned to its normal level.

#### ■ Customization

The Automatic High Beam can be turned off.  
(Customizable features →P. 766)

### CAUTION

#### Limitations of the Automatic High Beam

Do not rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning high beam on or off manually if necessary.

### NOTICE

#### Notes when using the Automatic High Beam system




Observe the following to ensure that the Automatic High Beam functions correctly.

-  Do not touch the camera sensor.
-  Do not subject the inside rear view mirror or the camera sensor to a strong impact.
-  Do not disassemble the camera sensor.
-  Do not spill liquid onto the inside rear view mirror or the camera sensor.
-  Do not apply window tinting or stickers to the camera sensor or the area of windshield near the camera sensor.
-  Do not place items on the dashboard. There is a possibility that the camera sensor will mistake items reflected in the windshield for streetlights, the headlights of other vehicles, etc.
-  Do not install a parking tag or any other accessories near or around the inside rear view mirror and the camera sensor.
-  Do not overload the vehicle.
-  Do not modify the vehicle.
-  Do not replace windshield with non-genuine windshield.  
Contact your Lexus dealer.

## 2-3. Operating the lights and windshield wipers

### Fog light switch

The fog lights improve visibility in difficult driving conditions, such as in rain or fog. The fog lights can be turned on only when the headlights are on low beam.



- 1 Turns the front fog lights off
- 2 Turns the front fog lights on


2-3. Operating the lights and windshield wipers

# Windshield wipers and washer


With “AUTO” selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.



- 1 Rain-sensing wiper operation
- 2 Low speed wiper operation
- 3 High speed wiper operation
- 4 Temporary operation



- 5 Increases the sensitivity
- 6 Decreases the sensitivity



### 7 Wash/wipe operation

Wipers operate automatically. (After operating several times, the wipers operate one more time after a short delay to prevent dripping.)

#### ■ The windshield wipers and washer can be operated when

The “ENGINE START STOP” switch is in IGNITION ON mode.

#### ■ Effects of vehicle speed on wiper operation

With the settings other than “AUTO” also, the time until drip prevention wiper sweep occurs is changed depending on vehicle speed.

With low speed wiper operation selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary. (However, when the sensor sensitivity is adjusted to the highest, the mode cannot be switched.)

#### ■ Raindrop sensor



- The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.

- If the wiper switch is turned to “AUTO” position while the “ENGINE START STOP” switch is in IGNITION ON mode, the wiper will operate once to show that auto mode is activated.

## 2-3. Operating the lights and windshield wipers

- If the temperature of the raindrop sensor is 194°F (90°C) or higher, or 5°F (-15°C) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO".

### ■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked and if there is washer fluid in the windshield washer fluid reservoir.

### ■ Headlight cleaner linked operation (if equipped on headlight cleaner)

When the windshield washer is operated with the headlights on, the headlight cleaner will operate once.

## CAUTION

### ■ Caution regarding the use of windshield wipers in "AUTO" mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else do not become caught in the windshield wipers.

## NOTICE

### ■ When the windshield is dry

Do not use the wipers, as they may damage the windshield.

### ■ When the washer fluid tank is empty

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

### Headlight cleaner switch\*

Washer fluid can be sprayed on the headlights.



Press the switch to clean the headlights.

#### ■ The headlight cleaner can be operated when

When the “ENGINE START STOP” switch is in IGNITION ON mode and the headlight switch is turned on.

#### ■ Windshield washer linked operation

When the windshield washer is operated with the “ENGINE START STOP” switch in IGNITION ON mode and the headlights on, the headlight cleaner will operate once. (→P. 204)

#### NOTICE


#### ■ When the washer fluid tank is empty

Damage to the washer fluid pump may be caused if the switch is pressed continually.

## 2-4. Using other driving systems

### Cruise control\*

Use the cruise control to maintain a set speed without using the accelerator.



1 Indicator

2 Cruise control switch

#### ■ Set the vehicle speed



STEP 1

Press the "ON-OFF" button to activate the cruise control.

Press the button once more to deactivate the cruise control.



STEP 2

Accelerate or decelerate to the desired speed and push the lever down to set the speed.

\*: If equipped

## ■ Adjusting the speed setting



- 1 Increases speed
- 2 Decreases speed

Hold the lever until the desired speed setting is obtained.

Fine adjustment of the set speed can be made by lightly pushing the lever up or down and releasing it.

## ■ Canceling and resuming regular acceleration



- 1 Cancel

Push the lever towards you to cancel cruise control.

The speed setting is also canceled when the brakes are applied.

- 2 Resume

To resume cruise control and return to the set speed, push the lever up.

Resuming is available when vehicle speed is approximately 25 mph (40 km/h) or more.

### ■ Cruise control can be set when

- Without paddle shift switches: The shift lever is in "D" or the "4", "5", "6", "7" or "8" range of "S" position.

With paddle shift switches: The shift lever is in the "D" position. However, it cannot be set if any of the ranges "1" through "3" has been selected using the paddle shift switches.

- Vehicle speed is above approximately 25 mph (40 km/h).

### ■ Accelerating

The vehicle can be accelerated normally. After acceleration, the set speed resumes.

### ■ Automatic cruise control cancellation

The cruise control will stop maintaining the vehicle speed in any of the following situations:

- Actual vehicle speed falls more than 10 mph (16 km/h) below the preset vehicle speed.  
At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 25 mph (40km/h).
- VSC is activated.

### ■ If the cruise control indicator light flashes

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Lexus dealer.

 **CAUTION****■ To avoid operating the cruise control by mistake**

Keep the “ON-OFF” button off when not in use.

**■ Situations unsuitable for cruise control**

Do not use cruise control in any of the following situations.

Doing so may result in control of the vehicle being lost and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On slippery roads, such as those covered with rain, ice or snow
- On winding roads
- On steep hills

Vehicle speed may exceed the set speed when driving down a steep hill.

## 2-4. Using other driving systems

### Dynamic radar cruise control\*

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In the vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.



- 1 Display
- 2 Indicator
- 3 Cruise control switch
- 4 Distance switch

#### ■ Set the vehicle speed



Press the "ON-OFF" button to activate the cruise control.

Press the button once more to deactivate the cruise control.

\*: If equipped

STEP 2



Accelerate or decelerate to the desired speed and push the lever down to set the speed.

Selecting conventional constant speed control mode



1 Press the “ON-OFF” button to activate the cruise control.

Press the button once more to deactivate the cruise control.

2 Switch to constant speed control mode.  
(Push the lever away from you and hold for approximately one second.)

Vehicle-to-vehicle distance control mode is always reset when the “ENGINE START STOP” switch is turned to IGNITION ON mode.

### ■ Adjusting the speed setting



1 Increases speed

2 Decreases speed

Hold the lever until the desired speed setting is displayed.

Fine adjustment of the set speed can be made by lightly pushing the lever up or down and releasing it.

### ■ Canceling and resuming the speed setting



#### 1 Cancel

Push the lever towards you to cancel cruise control.


The setting is also canceled when the brakes are applied.

#### 2 Resume

To resume cruise control and return to the set speed, push the lever up.

Resuming is available when vehicle speed is approximately 25 mph (40 km/h) or more.

### ■ Changing the vehicle-to-vehicle distance



Each press of the switch changes the vehicle-to-vehicle distance

#### 1 Long

#### 2 Medium

#### 3 Short


The vehicle-to-vehicle distance is set automatically to the long mode when the "ENGINE START STOP" switch is turned to IGNITION ON mode.

A mark will be displayed to indicate the presence of the vehicle if a vehicle is running ahead of you.

### Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles within approximately 400 ft. (120 m) ahead and to judge the distance between your vehicle and those vehicles.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



#### 1 Example of constant speed cruising

When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance switch.

#### 2 Example of deceleration cruising

When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, in the same lane, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing on the vehicle ahead.

### 3 Example of follow-up cruising

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

### 4 Example of acceleration

When there are no longer vehicles driving slower than the set speed in the lane ahead

When the vehicle ahead of you executes a lane change, the system slowly accelerates until the set vehicle speed is reached. The system then returns to fixed speed cruising.

## Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

---

### ■ Warning lights and messages for dynamic radar cruise control

Warning lights and messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving. (→P. 712)

### ■ Switching modes

The mode cannot be switched to constant speed control mode if vehicle-to-vehicle distance control mode has been used. The mode also cannot be switched from constant speed control to vehicle-to-vehicle distance control mode. Turn the system off by pressing the "ON-OFF" button, and turn it on again.

### ■ The dynamic radar cruise can be set when

- Without paddle shift switches: The shift lever is in “D” or the “4”, “5”, “6”, “7” or “8” range of “S” position.

With paddle shift switches: The shift lever is in the “D” position. However, it cannot be set if any of the ranges “1” through “3” has been selected using the paddle shift switches.

- Vehicle speed is above approximately 30 mph (50 km/h).

### ■ Accelerating

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

### ■ Automatically canceling vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations.

- Actual vehicle speed falls below 25 mph (40 km/h)
- VSC is activated
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed.
- The driving mode select switch is set to snow mode.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Lexus dealer.

### ■ Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situations:

- Actual vehicle speed is more than 10 mph (16 km/h) below the preset vehicle speed.  
At this time, the memorized set speed is not retained.
- Actual vehicle speed falls below 25 mph (40 km/h).
- VSC is activated.

■ Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 50 mph (80 km/h). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

| Distance options | Vehicle-to-vehicle distance  |
|------------------|------------------------------|
| Long             | Approximately 160 ft. (50 m) |
| Medium           | Approximately 130 ft. (40 m) |
| Short            | Approximately 100 ft. (30 m) |

■ Radar sensor and grille

Always keep the sensor and grille clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice or plastic objects, cannot be detected by the obstruction sensor.)

Dynamic radar cruise control is canceled if an obstruction is detected.



Radar sensor

■ Approach warning

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle's speed
- Immediately after the cruise control speed has been set
- At the instant the accelerator is applied

## ■ Certification

- For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR004

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

- For vehicles sold in Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### CAUTION

#### ■ Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set vehicle speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

#### ■ Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

##### ● Assisting the driver to measure following distance

The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.

##### ● Assisting the driver to judge proper following distance.

The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.

##### ● Assisting the driver to operate the vehicle

The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

#### ■ To avoid operating dynamic radar cruise control by mistake

Keep the "ON-OFF" button off when not in use.

## CAUTION

### ■ Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations. Doing so may result in control of the vehicle being lost and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhill, or where there are sudden changes between sharp up and down gradients  
Vehicle speed may exceed the set speed when driving down a steep hill.
- At entrances to expressways
- When weather conditions are bad enough that they may prevent the sensors from functioning correctly (heavy rain, fog, snow, sandstorm, etc.)
- When the approach warning buzzer can be heard often

### ■ When the radar sensor may not be correctly detecting the vehicle ahead

Apply the brakes as necessary when any of the following types of vehicles are in front of you.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (→P. 216) will not be activated, and an accident may result.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving
- Vehicles with small rear ends (trailers with no load on board etc.)
- Motorcycles traveling in the same lane

### CAUTION

#### ■ Conditions under which the vehicle-to-vehicle distance control may not function correctly

Apply the brakes as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, and an accident may result:

- When water or snow thrown up by the surrounding vehicles hinders the functioning of the radar sensor
- When your vehicle is pointing upwards (caused by a heavy load in the trunk etc.)
- When the road curves or when the lanes are narrow
- When steering wheel operation or your position in the lane is unstable
- When the vehicle ahead of you decelerates suddenly

#### ■ To ensure the radar sensor functions correctly

Do not do the following to the sensor or grille as doing so may cause the sensor not to function correctly and could result in an accident:

- Stick or attach anything to it
- Leave it dirty
- Disassemble, subject it to strong shocks
- Modify or paint it
- Replace it with a non-genuine part

#### ■ Handling the radar sensor

Observe the following to ensure the cruise control system can function effectively:

- Keep the sensor and front grille clean at all times.  
Clean the sensor and front grille with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact.  
If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by a Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille or surrounding area.
- Do not modify or paint the sensor and grille.

## 2-4. Using other driving systems

### Intuitive parking assist\*


The distance to obstacles measured by the sensors is communicated via the multi-information display and a buzzer when parallel parking or maneuvering into a garage. Always check the surrounding area when using this system.

#### ■ Types of sensors



- 1 Front side sensors
- 2 Front corner sensors
- 3 Front center sensors
- 4 Rear corner sensors
- 5 Rear center sensors

#### ■ Intuitive parking assist switch



#### On/off

When on, the indicator light comes on and the buzzer sounds to inform the driver that the system is operational.


Press the button to switch the on/off mode.

\*: If equipped

## Display


When the sensors detect an obstacle, the graphic is shown on the multi-information display and touch screen (if equipped) according to position and distance to the obstacle.

### ■ Multi-information display




- 1 Front side sensors and front corner sensors operation
- 2 Front center sensors operation
- 3 Rear corner sensors operation
- 4 Rear center sensors operation

### ■ Touch screen (if equipped)



When the vehicle is moving forward

The graphic is automatically displayed when an obstacle is detected. The screen can be set so that the graphic is not displayed. (→P. 229)



When the vehicle is moving backward

A simplified image is displayed on the right upper corner of the touch screen when an obstacle is detected.

## The distance display and buzzer

When a sensor detects an obstacle, the direction of and the approximate distance to the obstacle are displayed and the buzzer sounds.

### Center sensors

| Level                                  | 1                                                                                 | 2                                                                                 | 3                                                                                 | 4                                                                                 |
|----------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Display example of front center sensor |  |  |  |  |
| Buzzer                                 | Slow                                                                              | Medium                                                                            | Fast                                                                              | Continuous                                                                        |

2

When driving

### Corner sensors and side sensors

| Level                                 | 1 | 2                                                                                  | 3                                                                                  | 4                                                                                  |
|---------------------------------------|---|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| Display example of front right sensor | - |  |  |  |
| Buzzer                                | - | Medium                                                                             | Fast                                                                               | Continuous                                                                         |

■ Detection level and approximate distance to an obstacle


| Level                | 1                                | 2                                 | 3                                 | 4                          |
|----------------------|----------------------------------|-----------------------------------|-----------------------------------|----------------------------|
| Front side sensors   | -                                | 1.6 to 1.2 ft.<br>(50 to 37.5 cm) | 1.2 to 1.0 ft.<br>(37.5 to 30 cm) | 1.0 ft. (30 cm)<br>or less |
| Front corner sensors | -                                | 2.0 to 1.2 ft.<br>(60 to 37.5 cm) | 1.2 to 1.0 ft.<br>(37.5 to 30 cm) | 1.0 ft. (30 cm)<br>or less |
| Front center sensors | 3.3 to 1.6 ft.<br>(100 to 50 cm) | 1.6 to 1.2 ft.<br>(50 to 37.5 cm) | 1.2 to 1.0 ft.<br>(37.5 to 30 cm) | 1.0 ft. (30 cm)<br>or less |
| Rear corner sensors  | -                                | 2.0 to 1.2 ft.<br>(60 to 37.5 cm) | 1.2 to 0.8 ft.<br>(37.5 to 25 cm) | 0.8 ft. (25 cm)<br>or less |
| Rear center sensors  | 4.9 to 2.0 ft.<br>(150 to 60 cm) | 2.0 to 1.5 ft.<br>(60 to 45 cm)   | 1.5 to 1.1 ft.<br>(45 to 35 cm)   | 1.1 ft. (35 cm) or<br>less |

## Sensors that operate and detection range


The following diagrams show the sensor detection range. Note that sensors may not be able to detect obstacles that are extremely close to the vehicle.

### ■ Sensors that operate


#### ► With advanced parking guidance system



#### ► Without advanced parking guidance system



■ Detection range of the sensors



- 1 Approx. 3.3 ft. (100 cm)
- 2 Approx. 4.9 ft. (150 cm)
- 3 Approx. 1.6 ft. (50 cm)
- 4 Approx. 2.0 ft. (60 cm)

The diagram shows the detection range of the sensors. Note that the sensors may not be able to detect obstacles that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object etc.

## Customization of the intuitive parking assist (with touch screen)

The buzzer volume, display and buzzer timing and display of the graphic on the screen can be customized.

**STEP 1** Press "SETUP" to display the "Setup" screen. (→P. 321)

**STEP 2** Touch "Vehicle" on the "Setup" screen.

**STEP 3** Touch "LEXUS Park Assist" on the "Vehicle Settings" screen.



- 1 Alert volume setting
- 2 Display on/off
- 3 Alert distance setting

### ■ Sensor detection information

● Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect an obstacle. Particular instances where this may occur are listed below.

- There is dirt, snow or ice on a sensor.
- A sensor is frozen.
- A sensor is covered in any way.
- The vehicle is leaning considerably to one side.
- On an extremely bumpy road, on an incline, on gravel, or on grass
- The vicinity of the vehicle is noisy due to vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves.
- There is another vehicle equipped with parking assist sensors in the vicinity.
- A sensor is coated with a sheet of spray or heavy rain.
- The vehicle is equipped with a fender pole or radio antenna.
- Towing eyelets are installed.
- A bumper or sensor receives a strong impact.
- The vehicle is approaching a tall or right-angled curb.
- In harsh sunlight or intense cold weather.
- A non-genuine Lexus suspension (lowered suspension, etc.) is installed.

In addition to the examples above, there are instances in which, because of their shapes, signs and other objects may be judged by a sensor to be closer than they are.

● The shape of the obstacle may prevent a sensor from detecting it. Pay particular attention to the following obstacles:

- Wires, fences, ropes, etc.
- Cotton, snow and other materials that absorb radio waves
- Sharply-angled objects
- Low obstacles
- Tall obstacles with upper sections projecting outwards in the direction of your vehicle

### ■ Touch screen display

If an obstacle is detected while the vehicle is reversing, the warning indicator will appear in the top right of the screen even if the display setting has been set to "Off".

■ **If the display flashes and a message is displayed**

→P. 712

■ **Certification (Canada only)**

This ISM device complies with Canadian ICES-001.

■ **Customization (without touch screen)**

Settings (e.g. buzzer volume) can be changed. (Customizable features →P. 766)

 **CAUTION**

■ **Caution when using the intuitive parking assist**

Observe the following precautions.

Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 6 mph (10 km/h).
- Do not attach any accessories within the sensor range.

 **NOTICE**

■ **Notes when washing the vehicle**

Do not apply intensive bursts of water or steam to the sensor area.  
Doing so may result in the sensor malfunctioning.

## 2-4. Using other driving systems

### LKA (Lane-Keeping Assist)\*

While driving on a freeway or motor highway that has lane markings, this system recognizes the lanes using a camera as a sensor to assist the driver with staying in the lane. The LKA system has two functions.

#### ■ Lane departure warning function

If the system judges that the vehicle may deviate from its lane, it alerts the driver using rapid beeping, indications on the multi-information display, and sensory warning\* via the steering wheel.

\*: A slight steering torque is applied for a short period of time in the direction of the center of the lane.

#### ■ Lane keeping assist function

This function will be active when vehicle-to-vehicle distance control mode of the cruise control (→P. 212) is set with vehicle speed above approximately 45 mph (72 km/h) while the lane departure warning function is active. When the lane keeping assist function is active, a slight steering torque will be applied, to help the driver maintain the vehicle in a central position within the lane.

#### ■ Turning the LKA system on

The lane departure warning function and lane keeping assist function will be activated depending on the recognition condition of lane markings, vehicle speed and the setting of radar cruise control (vehicle-to-vehicle distance control mode).



Press the “LKA” switch to activate the system.

Press the switch again to turn the LKA system off.


\*: If equipped

■ Operating conditions for each function

| LKA system | Cruise control<br>(Vehicle-to-vehicle<br>distance control<br>mode)                                                                                  | Lane depar-<br>ture warning<br>function                                        | Lane keeping<br>assist function                                             |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
|            |                                                                                                                                                     | Vehicle speed is<br>between about<br>30 and 125<br>mph<br>(48 and 200<br>km/h) | Vehicle speed is<br>between about<br>45 and 112 mph<br>(72 and 180<br>km/h) |
| On         | Off                                                                                                                                                 | Available                                                                      | Not Available                                                               |
|            | On<br>While cruising in vehi-<br>cle-to-vehicle distance<br>control mode with the<br>set vehicle speed<br>approximately 44 mph<br>(71 km/h) or less | Available                                                                      | Not Available                                                               |
|            | On<br>While cruising in vehi-<br>cle-to-vehicle distance<br>control mode with the<br>set vehicle speed<br>approximately 45 mph<br>(72 km/h) or more | Available                                                                      | Available                                                                   |

### Indications on the multi-information display

While the LKA system is on, the lane line display and steering wheel display are shown on the multi-information display to inform the driver that the LKA system is on.



#### 1 Steering wheel display

When the steering wheel display is shown:

The lane keeping assist function is active.

#### 2 Dynamic radar cruise control display

#### 3 Lane line display

When outlines of the lane lines are shown:

A lane marking is not recognized by the system, or the LKA system functions are temporarily cancelled. (When the lane keeping assist function is cancelled, the signal will beep twice.)

When solid lane lines are shown:  
The lane departure warning function is active.

### ■ Temporary cancellation of the LKA system functions

If any of the following occurs, the LKA system functions will be temporarily cancelled. The functions will resume after the necessary operating conditions have returned.

- The turn signal lever is operated.
- The steering wheel is turned as far as necessary to cause the vehicle to change lanes.
- The brake pedal is depressed.  
The lane keeping assist function will not resume even after the brake pedal is released because depressing the brake pedal also cancels the dynamic radar cruise control.
- The vehicle speed deviates from the operating range of the LKA system functions.
- While the lane lines cannot be recognized while driving.
- Low speed or high speed wiper operation states.
- The hands-free driving warning activates while the lane keeping assist function is active. (The signal will beep twice.)

### ■ Hands-free driving warning

If the steering wheel is not operated for about 15 seconds on a straight road or about 5 seconds on a curve, the signal will beep twice, indications on the multi-information display will flash, and the lane keeping assist function will be temporarily cancelled. If you drive the vehicle with your hands lightly touching the steering wheel, it may also be detected as hands-free driving.

### ■ When the vehicle has been parked under the scorching sun or when the temperature in the cabin is extremely low

The LKA system functions may not be available for a while after driving of the vehicle has been started. In such cases, turn the LKA system off and turn it on again after normal temperature returns. When the temperature in the cabin decreases or increases, and the temperature around the camera sensor becomes appropriate for its operation, the functions will begin operating. (→P. 238)

### CAUTION

#### ■ Before using the LKA system

Do not rely on the LKA system to remain within a selected lane. The LKA system is not designed to enable inattentive driving. The steering wheel should be operated by the driver to maintain the vehicle in a suitable position within its lane. Always drive carefully.

#### ■ Turn the LKA off while driving in any of the following conditions:

Do not use LKA in any of the following situations. Otherwise, the system may not function correctly and could result in an accident.

- When driving with snow tires, snow chains, a spare tire, or similar equipment.
- When driving with non-standard parts or aftermarket equipment installed. (including modified tires and suspensions, etc.)
- When there are objects or structures along the roadside that might be misinterpreted as lane markers. (such as guardrails, curb, reflector posts, etc.)
- Where there are wheel ruts, icy trademarks, etc. or if snow remains on the road surface.
- When there are shadows on the road running parallel with lane markers, or if a shadow covers the lane markers.
- When there are visible lines on the pavement from road repairs, or if the remains of old lane markers are still visible on the road.
- When driving on slippery roads, such as those covered with rain, ice or snow.
- When driving in a lane other than the driving or passing lanes on a freeway, highway or motorway.
- When driving on a road with lane closures due to maintenance, or when driving in a temporary lane.
- When driving on winding roads or roads that are rough or uneven.

 NOTICE

■ In the following situations, the LKA will not work, or will not perform reliably:

- When lane markers are interrupted or are not present, such as before a tollbooth (tollgate).
- When lane markers are only on one side of the road.
- When driving on a sharp curve.
- When lanes are extremely narrow or extremely wide.
- When the vehicle leans to one side an unusual amount due to a heavy load or improper tire inflation pressure.
- When the following distance between your vehicle and the vehicle ahead is extremely short.
- When the lane markers are broken, “Botts’ dots”, or “Raised pavement marker”.
- When lane markers are obscured or partially obscured by sand, dirt, etc.
- When driving on a particularly bright road surface, such as concrete.
- When driving on a road surface that is bright due to reflected light.
- When driving in a location where the light level changes rapidly, such as the entrance to or exit from a tunnel.
- When sunlight or the headlights of oncoming vehicles are shining directly into the camera lens.
- When driving on roads that are branching or merging.
- When pavement lane markers are difficult to see due to rain, snow, fog, etc.
- When driving on a road surface that is wet due to rain, previous rainfall, standing water, etc.
- When the vehicle experiences strong up-and-down motion such as when driving on an extremely rough road or on a seam in the pavement.
- When headlight brightness is reduced due to dirt on the lenses, or when the headlights are misaligned.
- When driving with a strong crosswind.

### NOTICE

#### ■ Camera sensor



Observe the following to ensure that the LKA system functions correctly.

- Keep the windshield clean at all times.  
LKA performance may deteriorate due to the presence of raindrops, condensation, ice or snow on the windshield.
- Do not attach a sticker or other items to the windshield near the camera sensor.
- When adjusting the rear-view mirror, make sure that it does not block the camera lens.
- When it is cold, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up. This will have a negative effect on the images. In such a case, use the windshield defogger to provide warm, dry air to the windshield.
- Do not place anything on the dashboard.  
The camera sensor may recognize the image reflected on the windshield as lane markers by mistake.
- Do not scratch the camera lens, or let it get dirty.
- Do not change the installation position of the camera sensor or remove it. The direction of the camera sensor is precisely adjusted.
- Do not subject the camera sensor to strong impact or force, and do not disassemble the camera sensor.

### Electronically modulated air suspension\*

The vehicle adjusts the damping of the shock absorbers and maintains vehicle height automatically in response to driving conditions to help provide enhanced driving comfort and vehicle control.

#### ■ Vehicle height adjustment

The vehicle's height is maintained at the selected level regardless of the number of occupants and luggage weight.




Turn the "HEIGHT HIGH" switch on.

The indicator light comes on.

Press the switch once more to cancel the high mode.

#### ■ Damping mode selection

You can select the damping mode of the shock absorbers.



#### 1 Sport

The indicator light comes on.

#### 2 Normal

#### 3 Comfort

The indicator light comes on.

#### ■ Operating sound of the air suspension compressor

When the vehicle height is lowered, such as when entering or loading the vehicle, or high mode is selected, the compressor may operate and a whirring sound may be heard. This does not indicate a malfunction.

\*: If equipped

### CAUTION

■ Be sure to stop the engine in the following situations in order to stop operation of the electronically modulated air suspension:

- The vehicle is parked on a curb.
- Any of the wheels is stuck in a ditch.
- It is necessary to jack up the vehicle.
- It is necessary to tow the vehicle with part of it lifted.

If the "ENGINE START STOP" switch remains in IGNITION ON mode, the vehicle height may change, resulting in an accidental damage.

## 2-4. Using other driving systems

### Rear view monitor system\*


The rear view monitor system assists the driver by displaying an image of the area behind the vehicle. The image is displayed in reverse on the screen. This reversed image is a similar image to the one on the inside rear view mirror.



The rear view image is displayed when the shift lever is in the “R” position.


If the shift lever is shifted out of R, the screen returns to the previous one.

### ■ Displayed area



The area covered by the camera is limited. Objects that are close to either corner of the bumper or under the bumper cannot be seen on the screen.

The area displayed on the screen may vary according to vehicle orientation or road conditions.



### ■ Rear view monitor system camera



In the following cases, it may become difficult to see the images on the screen, even when the system is functioning correctly:

- The vehicle is in a dark area, such as at night.
- The temperature near the lens is extremely high or low.
- Water droplets are on the camera lens or humidity is high, such as when it rains.
- Foreign matter, such as snow or mud, adheres to the camera lens.
- The sun or headlights are shining directly into the camera lens.

### ■ Smear effect



If a bright light, such as sunlight reflected off the vehicle body, is picked up by the camera, a smear effect\* characteristic to the camera may occur.

\*: Smear effect — A phenomenon that occurs when a bright light is picked up by the camera; when transmitted by the camera, the light source appears to have a vertical streak above and below it.

### ⚠ CAUTION

■ When using the rear view monitor system, observe the following precautions to avoid an accident that could result in death or serious injuries:

- Never depend solely on the monitor system when reversing.
- Always check visually and with the mirrors to confirm your intended path is clear.
- Depicted distances between objects and flat surfaces differ from actual distances.
- Do not use the system if the trunk is open.

■ Conditions which may affect the rear view monitor system

- If the back of the vehicle has been hit, the camera's position and mounting angle may have changed. Have the vehicle inspected by your Lexus dealer.
- Rapid temperature changes, such as when hot water is poured on the vehicle in cold weather, may cause the system to function abnormally.
- If the camera lens is dirty, it cannot transmit a clear image. Rinse with water and wipe with a soft cloth. If extremely dirty, wash with a mild cleanser and rinse.
- The displayed image may be darker and moving images may be slightly distorted when the system is cold.

## 2-4. Using other driving systems

### Advanced parking guidance system\*

The advanced parking guidance system supports the driver during reverse parking by displaying a rear-view image and controlling the steering wheel to help the driver reverse the vehicle into a target parking position set on the screen.

The illustrations of the display shown are examples only and may differ from actual images. When parking in a space on the opposite side to that shown in the examples, be sure to substitute left for right and vice versa when operating the steering wheel.



Advanced parking guidance system will activate when the shift lever is in “R” position.

If you move the lever out of “R” position, the advanced parking guidance system will be deactivated.

As the advanced parking guidance system only assists with parking in a set target parking position, there are times when the system will be unable to render this assistance, depending on factors such as road surface or vehicle condition, or the distance to the set target parking position.

The advanced parking guidance system is not an automatic parking system. It is a system to assist back up parking.

\*: If equipped


## About the screen



**1** Parking assist mode button  
Touching this button turns parking assist mode on.  
(→P. 248)

**2** Parallel parking assist mode button  
Touching this button turns parallel parking assist mode on. (→P. 257)


## Perpendicular parking



● Parking assist mode  
(→P. 248)

This mode assists the driver during perpendicular parking by automatically controlling the steering wheel to move the vehicle into the target position set on the screen.

### ■ Parallel parking



### ● Parallel parking assist mode (→P. 257)

This mode assists the driver during parallel parking by automatically controlling the steering wheel to move the vehicle into the target position set on the screen.

### ■ APGS pre-support switch

Use this switch to turn on/off the pre-support function and to switch assist mode between parallel parking assist mode and perpendicular parking assist mode.



Pressing the pre-support switch while assist mode is on, the "ENGINE START STOP" switch is in IGNITION ON mode and the vehicle is traveling below 9 mph (15 km/h) with the shift position in any position other than "P" or "R", will cause the screen to change in the following order:

Pre-support function OFF → Parallel parking assist mode pre-support screen → Perpendicular parking assist mode pre-support screen → Pre-support function OFF

If the pre-support function cannot be used, two beeps will sound (the beeps will not sound if the shift lever is in the "R" position).


## Driving precautions



When the grade behind the vehicle slopes up sharply, objects appear to be farther away than they actually are.



When the grade behind the vehicle slopes down sharply, objects appear to be closer than they actually are.




When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the set target parking position on the screen, and the actual distance/course on the road.

### Parking assist mode (Perpendicular parking)

#### ■ Screen description

Parking assist mode assists the driver with perpendicular parking by automatically controlling the steering wheel when backing up, in order to park in the target position set on the screen.

If a message is displayed while maneuvering (→P. 266)



1 Camera orientation confirmation lines

2 Parking assist mode button


## ■ Parking operation

### ● Pre-support function

Pre-support is useful for parking perpendicular to another vehicle. This function detects the empty parking space beyond the parked vehicle and then guides the driver to the correct starting position for reversing. Chimes are used to inform the driver when it is time to turn the steering wheel and when it is time to start reversing.

### ● Before backing up

#### ► When the pre-support function is in use




With the vehicle stopped or driving at 9 mph (15 km/h) or less, push the pre-support switch twice when your vehicle is positioned slightly before the target parking space. (→P. 246) Check that the screen changes.



Move your vehicle slowly to a position perpendicular to and as close as possible to the target parking space.

Drive slowly enough to be able to turn the steering wheel immediately after the chime sounds.

To discontinue the guidance, push the pre-support switch once to turn the pre-support function off. (→P. 246)



A chime will sound once when the center of the target parking space is visible right beside you. After this chime has sounded, turn the steering wheel about half a turn or more while driving forward.



When the chime sounds twice, stop your vehicle and straighten the steering wheel.


To enter the target parking space more accurately, position your vehicle with a larger heading angle.

► When the pre-support function is not in use



Move your vehicle slowly to a position perpendicular to the parking space, and as close as possible to the parking space.

Positioning the vehicle perpendicular to the parking space allows the angle of the parking position to be identified easily.



Move your vehicle to a position where you can see the center of the parking space right beside you.

To facilitate the setting of the target parking position, the front side sensors detect the vehicles parked at the left and right of the parking space and identify the target parking position.

It is possible to identify the target parking position even if there is only a vehicle parked on one side of the parking space.

If no vehicle or small vehicles are parked on both sides of the desired parking space, stop with the steering wheel straight.

- By stopping the vehicle here, you can mostly identify the parking location, making it easier to set the target parking position.
- Make sure the steering wheel is straight when you stop. If not, the parking location cannot be identified.
- If you do not stop in front of the parking space, the system will refer to the angle of the vehicle relative to the target parking space, and display the target parking position (green or red frame) in the position used last time the parking assist mode was activated.



Position your vehicle so that you can enter the parking space, then stop the vehicle with the steering wheel straight.

To enter the target parking space more accurately, position your vehicle with a larger heading angle.

### ● While backing up

**STEP 1** Place the shift lever in “R” position.

Touch   on the screen (only when the pre-support function is not in use).

**STEP 2**



Use the arrow to align the green frame with the desired parking space, then touch “OK”.

- You can also move the green frame by touching the screen (area other than the arrow).
- There are tricks to align the green frame. (→P. 254)
- Areas in which you are unable to park are displayed in red.
- If the frame is displayed in red, you cannot use the parking assist mode to park in that location. (→P. 271)
- When the green frame is displayed, if you begin backing up without touching “OK”, the message “Parking position has not been set.” appears. If you continue to back up, you will hear a warning tone and the system will be disabled.
- If the frame is red, there will be no guidance even if you begin backing up.
- If the orientation of the frame is opposite to that of the target parking space, touch  .
- There may be times when, due to image distortion, the green frame does not match the parking space lines on the road surface. In this case, attempt an approximate match in an area where the warning flag does not overlap with any parked vehicles or obstacles.
- You may adjust the target parking position even after starting the parking assist mode.

## STEP 3



CLY24AD513

Position yourself as you would when backing up normally, and rest your hands on the steering wheel without applying any pressure. Check your surroundings and behind the vehicle for safety, and slowly back up, using the brake pedal to control the vehicle's speed.

If you touch "X", assistance is canceled.



CLY24AD544

You can change the target parking position by touching . If you are backing up, or have already moved close to the target parking position,  will turn gray, and you will be unable to change the target.

Touch the arrows to move the target parking position, and then touch "OK".



Once the vehicle is mostly within the target parking position, voice guidance will inform you to finish the assist mode.

For safety, voice guidance is given slightly before the target parking position. Furthermore, at that point system control will finish, so grip the steering wheel firmly, and finish parking in the desired position, using the brake to control the vehicle's speed.

Check in front and behind the vehicle visually and check with the mirrors while backing up.

### ■ Tips for setting the target parking position

Useful information for setting the target parking position (green frame)

#### ● The display position of the green frame

The system decides the initial positioning of the green frame by the position of the parking space detected by the front side sensors or the position of the vehicle when it stops, and by detecting the white lines of the parking space in the camera image to identify the parking space location.

The front side sensors identify the parking space location and the white lines near that location are detected.

The front side sensors cannot identify the parking space location, or the parking space location maybe misaligned in the following situations.


- A vehicle is parked at the back of the parking space or the sensors cannot detect a parked vehicle due to vehicle shape etc.
- The sensors cannot detect a pole or wall beside the parking space.
- The sensors detect a pedestrian or object near the parking space.

If the point at which you stop is correctly identified, the green frame will display the parking space accurately. If the white lines of the parking space have not been correctly identified, the green frame will not match the parking space even if you stop in the correct location. In this case, adjust the point at which you stop as needed.

### ● Aligning the green frame


There are two ways to align the green frame with the parking space, either using the arrows on the screen, or by touching the screen at points other than the arrows.

#### ► Using the arrows on the screen:



By touching the arrows displayed on the screen, you can move the green frame.

### ► Directly touching the target point:




Touch the front edge of the place you wish to move.

By touching the point you wish to move the frame to, you can move the green frame.

If you touch the following areas, the green frame will not move:

- The area surrounding the arrows.
- The area near the lower button on the screen.
- Areas too far away to park in the range of 31.2 ft. (9.5 m) or more behind, and/or either left or right from the current position.

### ● If the parking space and the green frame do not match



If the lines of the parking space are wider than the green frame, position the frame so that the difference between the frame and the parking space lines is equal on both sides.

## Parallel parking assist mode

### ■ Screen description

Parallel parking assist mode assists the driver with parallel parking by automatically controlling the steering wheel when backing up, in order to park in the target position set on the screen.

If a message is displayed while maneuvering (→P. 266)



- 1 Camera orientation confirmation lines
- 2 Parallel parking assist mode button


### ■ Parking operation

#### ● Pre-support function

Pre-support is useful for parking between two vehicles that are parked along the shoulder of the road. This function detects the empty parking space between the parked vehicles and then guides the driver to the correct starting position for reversing. Chimes are used to inform the driver when it is time to start reversing.


#### ● Before backing up

► When the pre-support function is in use



With the vehicle stopped or driving at 9 mph (15 km/h) or less, push the pre-support switch once when your vehicle is positioned slightly before the target parking space. (→P. 246) Check that the screen changes.


## STEP 2



Move your vehicle slowly alongside the vehicle parked in front of the target parking space. Your vehicle should move parallel to the road or shoulder and be approximately 3 ft. (1 m) away from the side of the parked vehicle.

To discontinue the guidance, push the pre-support switch twice to turn the pre-support function off. (→P. 246)

## STEP 3




A chime will sound twice when the front edge of the vehicle parked in front of the target parking space is visible right beside you. When this chime sounds twice, stop your vehicle.

## 2-4. Using other driving systems

### ► When the pre-support function is not in use


#### STEP 1



Move your vehicle slowly to a position parallel to the road or shoulder approximately 3 ft. (1 m) away from parked vehicles.

To facilitate the setting of the target parking position, the front side sensors detect the vehicles parked in front of and behind the parking space and identify the target parking position.

#### STEP 2



Stop your vehicle in a position where you can see the front edge of the leading parked vehicle right beside you, with the steering wheel straight.

If there is no leading parked vehicle, the system will display the target parking position (green or red frame) in the position used last time the parallel parking assist mode was activated.

● While backing up

**STEP 1** Place the shift lever in the “R” position.

Touch  on the screen (only when the pre-support function is not in use).

**STEP 2**



Use the arrow to align the green frame with your target parking space, and touch “OK”.

- You can also move the green frame by touching the screen (area other than the arrows).
- There are tricks to align the green frame. (→P. 263)
- If the frame is displayed in red, you cannot use the parallel parking assist mode to park in that location. (→P. 271)
- When the green frame is displayed, if you begin backing up without touching “OK”, the message “Parking position has not been set.” appears. If you continue to back up, you will hear a warning tone and the system will be disabled.
- If the frame is red, there will be no guidance even if you begin backing up.
- If the orientation of the frame is opposite to that of the target parking space, touch .
- There may be times when, due to image distortion, the green frame does not match the parking space lines on the road surface. In this case, use the warning flag and extended green line to set the target parking position.
- You may adjust the target parking position even after starting the parallel parking assist mode.

### STEP 3



CLY24AD511

Position yourself as you would when backing up normally, and rest your hands on the steering wheel without applying any pressure. Check your surroundings and behind the vehicle for safety, and slowly back up, using the brake pedal to control the vehicle's speed.

If you touch "X", assistance is canceled.




CLY24AD530

You can change the target parking position by touching . If you are backing up, or have already moved close to the target parking position,  will turn gray, and you will be unable to change the target.

Touch the arrows to move the target parking position, and then touch "OK".

You can only move the target parking position left or right, and the warning flag will not move even if you adjust the target parking position.



Once the vehicle is mostly within the target parking position, voice guidance will inform you to finish the assist mode.

For safety, voice guidance is given slightly before the target parking position. Furthermore, at that point system control will finish, so grip the steering wheel firmly, and finish parking in the desired position, using the brake to control the vehicle's speed.

Check in front and behind the vehicle visually and check with the mirrors while backing up.


### ■ Tips for setting the target parking position

Useful information for setting the target parking position (green frame)

#### ● Aligning the green frame

There are two ways to align the green frame with the parking space, either using the arrows on the screen, or by touching the screen at points other than the arrows.


### ► Using the arrows on the screen:



By touching the arrows displayed on the screen, you can move the green frame.

Adjusting the left-right alignment first will make subsequent alignment easier.

### ► Directly touching the target point:




By touching the point you wish to move the frame to, you can move the green frame.

Touch the front edge of the place you wish to move.


If you touch the following areas, the green frame will not move:

- The area surrounding the arrows.
- The area near the lower button on the screen.
- Areas too far away to park in the range of 34.4 ft. (10.5 m) or more behind the current position, and/or 16.4 ft. (5.0 m) or more either left or right from the current position.

- If there is a slope in the road



The assisted parking position will move left or right of the set target parking position.



In this case, if you align the warning flag with the rear of the forward parked vehicle, and the extended green line with the lower edge of the parked vehicle's rear wheel when setting the target parking position, the left side of your vehicle will be roughly in line with the left side of the front parked vehicle once assisted parking is complete. If you are parallel parking on the opposite side of the road, left and right will be reversed.

What to do when this sort of message is displayed

| Message                                                 | Cause                                                                                                                                                                                                                                                             | What to do                                                                                                                                              |
|---------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| ! Parking position cannot be set.                       | Not in an area where system use is possible.                                                                                                                                                                                                                      | Change the vehicle's position, referring to the help function.                                                                                          |
| ! Check APGS.<br>Have your vehicle checked by a dealer. | There is a malfunction in the system.                                                                                                                                                                                                                             | Have your vehicle checked by your Lexus dealer.                                                                                                         |
| ! Use on flat surface.                                  | <ul style="list-style-type: none"><li>• The vehicle has rolled forward on a sloped road.</li><li>• The vehicle does not move even if you take your foot off the brake pedal.</li><li>• You have depressed the accelerator pedal during the assist mode.</li></ul> | Do not attempt to use the system in those sorts of conditions. Use the system for flat parking spaces.                                                  |
| ! System cannot guide under current conditions.         | If the message is displayed only when the system is operating, it is likely that the tires are worn, or tire inflation pressure is low.                                                                                                                           | Check tires for wear and pressure.                                                                                                                      |
|                                                         | If the message is displayed constantly, there is most likely a malfunction.                                                                                                                                                                                       | Turn the "ENGINE START STOP" switch to OFF, then to IGNITION ON mode. If the message is still displayed, have the vehicle checked by your Lexus dealer. |
|                                                         | The vehicle has skidded or the tires have been locked.                                                                                                                                                                                                            | Do not attempt to use the system on a slippery road such as snowy road.                                                                                 |

| Message                                                                        | Cause                                                     | What to do                                                                                           |
|--------------------------------------------------------------------------------|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| ! APGS not available now.                                                      | The system has temporarily overheated.                    | Turn the “ENGINE START STOP” switch to OFF, then to IGNITION ON mode. Wait a few minutes before use. |
|                                                                                | The engine speed is 1000 rpm or above.                    | Do not use the system when the engine speed is 1000 rpm or above.                                    |
|                                                                                | There is a malfunction in the voice guidance system.      | Have your vehicle checked by your Lexus dealer.                                                      |
|                                                                                | The engine has not been started.                          | Start the engine.                                                                                    |
| ! Release parking brake.                                                       | The parking brake has been applied.                       | Release the parking brake.                                                                           |
| ! Too much force applied to the steering wheel.                                | You are exerting too much pressure on the steering wheel. | Loosen your grip on the steering wheel.                                                              |
| Steering position is not straight. Turn the steering wheel to LEFT (or RIGHT). | The steering wheel and tires are not straight.            | Turn the steering wheel until tires are straight.                                                    |

| Message                                                 | Cause                                                                                      | What to do                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------|--------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Steer to left (or right) until the frame becomes green. | It is possible to begin to park if you turn the steering wheel in the direction indicated. | Turn the steering wheel in the direction indicated until the frame turns green (the message “Too much force applied to the steering wheel.” is displayed). Turn the wheel slightly more than necessary to overcome tire resistance. Once you have turned the steering wheel, you can no longer change the target parking position. Be sure to align the frame before turning the steering wheel. |
| ! Parking position has not been set.                    | You have begun to back up without touching “OK”.                                           | Stop the vehicle and touch “OK”.                                                                                                                                                                                                                                                                                                                                                                 |
| ! Speed is too fast.                                    | The speed at which you are backing up is too fast.                                         | Using the brake pedal, back up at a speed that does not cause the warning chime to sound. The system will be disabled if you back up too quickly.                                                                                                                                                                                                                                                |
| ! Guidance canceled by user operation.                  | You have turned the steering wheel during the assist mode.                                 | The system has been disabled. You will need to restart from the beginning.                                                                                                                                                                                                                                                                                                                       |
| ! Accelerator pedal has been depressed.                 | You have depressed the accelerator pedal when setting the target parking position.         | Do not depress the accelerator pedal.                                                                                                                                                                                                                                                                                                                                                            |

| Message                    | Cause                                                                     | What to do                                                                                                                                                                        |
|----------------------------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ! Guidance unavailable.    | Some sort of malfunction has occurred within the system.                  | Have your vehicle checked by your Lexus dealer.                                                                                                                                   |
| ! System not ready.        | -                                                                         | Take your vehicle to your Lexus dealer.                                                                                                                                           |
| ! Depress the brake pedal. | "OK" is touched while the brake hold system is on.                        | Depress the brake pedal and touch "OK".                                                                                                                                           |
| ! Clean Park Sonar.        | The sensors may be affected by extreme cold or covered by foreign matter. | Rinse with water and wipe with a soft cloth. Wash with a mild cleanser and rinse if necessary. If the message is still displayed, have your vehicle checked by your Lexus dealer. |

■ Message and voice guidance

In the parking assist function, voice guidance accompanies the following messages displayed during parking position setting and steering wheel control. (Voice guidance may not be given depending on the reason the message was displayed.)

| Message                                              | Voice Guidance (Warning tone) |                                                                    |
|------------------------------------------------------|-------------------------------|--------------------------------------------------------------------|
|                                                      | During setting                | During steering wheel control                                      |
| ! Check APGS. Have your vehicle checked by a dealer. | (One chime)                   | (Two beeps) The guidance has been canceled.                        |
| ! System cannot assist under current conditions.     | -                             | (Two beeps) The guidance has been canceled.                        |
| ! APGS not available now.                            | (One chime)                   | (Two beeps) The guidance has been canceled.                        |
| ! Release parking brake.                             | (One chime)                   | (Two beeps) The guidance has been canceled.                        |
| ! Parking position has not been set.                 | (One chime)                   | -                                                                  |
| ! Speed is too fast.                                 | -                             | (Several beeps and then two beeps) The guidance has been canceled. |
| ! Guidance canceled by user operation.               | -                             | (Two beeps) The guidance has been canceled.                        |

For the adjustment of the volume

- ▶ Without navigation system: →P. 325
- ▶ With navigation system: Refer to the “Navigation System Owner’s Manual”.

### ■ When a red frame is displayed in the parking assist function

If the frame turns red and the message “Adjust the frame to the target.” is displayed while setting the target parking position, you cannot use the parking assist function.

In this situation, move the target parking position, or move the position of the vehicle.

The frame may be displayed in red, depending on the location and angle of the vehicle when “R” position is selected.

Furthermore, even if the frame is displayed in green, if you move the frame to a location unsuitable for parking using the parking assist function, the frame will change to red.

### ● Help function

If you touch “OK”, the reason the frame is displayed in red will be displayed. Move the vehicle appropriately, referring to the screen.

**STEP 1** Touch “OK”.

**STEP 2** Move the vehicle in accordance with the message displayed.

See the following items for information on the messages displayed. If you move the frame to a position acceptable to the assist mode, a chime will sound.

**STEP 3** If you have moved the vehicle forwards, place the shift lever in “R” position.


**STEP 4** Check that the frame is green, and if that position is acceptable, touch “OK”.

● Displayed message and vehicle position for parking assist mode




**1** Too far

If the vehicle is too far from the parking space, the message “Start from a position nearer to the target parking area.” will be displayed.



**1** Angle too small

If the orientation of the vehicle is incorrect, the message “Start with larger vehicle heading angle.” will be displayed.




**1** Near the front of the parking space

**2** Too close

If the vehicle is near the front of the parking space, or too close, the message “Start from a position farther from the target parking area.” will be displayed.

## ● Displayed message and vehicle position for parallel parking assist mode




### 1 Too far

If the vehicle is too far from other parked vehicles, the message “Start from a position nearer to adjacent vehicle.” will be displayed.




### 1 Too close

If the vehicle is too close to other parked vehicles, the message “Start from a position farther from adjacent vehicle.” will be displayed.



### 1 Too far forward


If the vehicle is too far forward, the message “Start after moving slightly backward.” will be displayed.



### 1 Too far back

If the vehicle is too far back, the message “Start after moving slightly forward.” will be displayed.

### Initializing the system



Make sure to initialize the system in the following situations.

- The battery is disconnected and reconnected.
- The system initialization in progress screen is displayed when the shift lever is moved to “R” position (due to low battery etc.).

The help screen appears when “?” is touched. Make a correction using the following method in accordance with the display.

When the vehicle is stopped, turn the steering wheel all the way to the left, then all the way to the right. (It does not matter in which direction — right or left — you turn first.)

When the screen returns to the original display, correction is complete.

If the above screen remains, have the vehicle inspected at your Lexus dealer.

### ■ Disabling the system

Even if the shift lever is in "R" position, if you push any of the switches around the screen, such as "SETUP" or "INFO/PHONE", the screen will switch to that mode.

When in the parking assist mode or parallel parking assist mode, in the following case the voice guidance will say "The guidance has been canceled.", a message will be displayed, and the system will be disabled. (→P. 266)

After the following operations:

- Moving the steering wheel
- Using the accelerator
- Moving the shift lever out of "R" position
- Applying the parking brake
- Switching the screen display

In the following situations:

- If the vehicle slips forward or stops after taking your foot off the brake pedal
- If the backing speed is too fast
- If normal assistance cannot be rendered due to worn tires or low tire inflation pressure
- If the target parking position has not been confirmed on the target parking position setting screen before backing up
- Any warnings displayed on the screen are not acknowledged before backing up
- If there is a system malfunction
- If the system temperature protection function operates
- If a hands-free phone call is received

If the system is disabled while backing up, grip the steering wheel firmly and depress the brake pedal to bring the vehicle to a halt. The system has been completely disabled, so you may either start again from the beginning, or if you wish to finish parking manually, be sure to operate the steering wheel as you would normally.

### ■ Notes for the pre-support function

- If the detected parking space is too small, guidance will not start.
- To allow the pre-support system to activate accurately, move the vehicle as slowly as possible (at a speed that will allow the vehicle to stopped suddenly).
- The function cannot be used if the shift position is in "P" or "R" position, or if the vehicle speed is greater than 9 mph (15 km/h).
- In order to identify parking spaces and detect parked vehicles using the sensors on both sides of the front bumper, guidance cannot be given if a space is not detected.
- Parking space guidance and searching continues until the vehicle speed is greater than 9 mph (15 km/h) or until the function is turned off by pushing the pre-support switch.
- Perpendicular parking: The pre-support function can only be used for perpendicular parking when a vehicle is parked beside the target parking space on the side closest to your vehicle as it approaches.  
Parallel parking: The pre-support function can only be used for parallel parking when vehicles are parked both in front of and behind the target parking space.

### ■ Detecting while lines in parking assist mode (perpendicular parking)

If there are no vehicles parked on either side of the target parking space when your vehicle stops, an approximate parking space location is identified, and the white lines in that location are detected. For this reason, stopping in front of the parking space will make the detection of target parking space's white lines easier.

Successful detection of the parking space's white lines may not be possible, depending on the shape of the line.

In the following circumstances, detection of the parking space lines on the road surface may not be possible:


- The lines are faded or dirty, making them unclear.
- The road surface is of a light color which does not contrast well with the white lines.
- The parking space lines are a color other than white (yellow etc.).
- The area is dark, for example at night or in a covered parking lot.

- During or after rain, when the road surface is wet and reflects light, or puddles have formed.
- The sun is shining directly on the camera, for example early morning or late afternoon.
- The parking space is covered with snow or de-icing agent.
- There are markings or maintenance marks on the road surface.
- The color or brightness of the road surface is not uniform.
- Hot or cold water has splashed on the camera, and the lens is fogged.
- There are dirt or water droplets on the lens.

### ■ Intuitive parking assist


When the Intuitive parking assist are turned on and an obstacle is detected in front of or behind your vehicle, a warning appears on the top right of the screen.  
(→P. 223)

### ■ Area displayed on screen



The area covered by the camera is limited. Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.

The area displayed on the screen may vary according to vehicle orientation or road conditions.



If the edge of the bumper displayed on the screen does not match the camera orientation confirmation lines, the camera may not be aligned correctly. Have the vehicle checked by your Lexus dealer.

### ■ Advanced parking guidance system camera



In the following cases, it may become difficult to see the images on the screen, even when the system is functioning correctly:

- The vehicle is in a dark area, such as at night.
- The temperature near the lens is extremely high or low.
- Water droplets are on the camera lens or humidity is high, such as when it rains.
- Foreign matter, such as snow or mud, adheres to the camera lens.
- The sun or headlights are shining directly into the camera lens.



If a bright light, such as sunlight reflected off the vehicle body, is picked up by the camera, a smear effect\* characteristic to the camera may occur.

\*: Smear effect — A phenomenon that occurs when a bright light is picked up by the camera; when transmitted by the camera, the light source appears to have a vertical streak above and below it.

If you install the antenna of a wireless device close to the camera, the screen image may be affected by the electromagnetic waves, and the system may not function correctly. Install an antenna away from the camera.

The method for adjusting the picture quality of the advanced parking guidance system is the same as that for the screen.

 **CAUTION**
**■ When using the system**

- Be sure to check that the vehicle can actually park in the target space before beginning operation.
- Depending on the circumstances of the vehicle (number of passengers, amount of luggage, etc.), the position of the green frame displayed on the screen may change. Be sure to check visually behind and all around the vehicle before proceeding.
- Never depend on the system entirely when backing up. Always make sure your intended path is clear.  
Use caution, just as you would when backing up any vehicle.
- When using the parking assist mode and parallel parking assist mode
  - When backing up, be sure to check your surroundings and behind the vehicle for safety, and back up slowly, depressing the brake pedal to control vehicle speed.
  - If you seem likely to hit nearby vehicles, obstacles or people, depress the brake pedal to stop the vehicle, and then disable the system by touching "X" on the screen.
  - If there is a problem, stop the vehicle and disable the system by touching "X" on the screen.
  - Keep clothing such as neckties, scarves and long sleeves away from the steering wheel, as they may become entangled. Also, keep children away from the steering wheel.
  - If you have long fingernails, be careful not to injure yourself when the steering wheel moves.

### CAUTION

#### ■ How to use the camera

- Never back up while looking only at the screen. The image on the screen is different from actual conditions. Depicted distances between objects and flat surfaces will differ from actual distances. If you back up while looking only at the screen, you may hit a vehicle, a person or an object. When backing up, be sure to check behind and all around the vehicle visually and with mirrors before proceeding.
- If the back of the vehicle is hit, the position and mounting angle of the camera may change. Be sure to have the camera's position and mounting angle checked by your Lexus dealer.
- If the camera is subjected to a collision, or the camera orientation confirmation lines are not in line with the bumper, it is likely that the camera position or angle of installation has become crooked. Contact your Lexus dealer.
- Use your own eyes to confirm the vehicle's surroundings, as the displayed image may become faint or dark, and moving images will be distorted, or not entirely visible when the outside temperature is low. When backing up, be sure to check behind and all around the vehicle visually and with mirror before proceeding.
- Do not use the system when the trunk is not completely closed.
- If the image may be hard to see due to dirt, direct sunlight, shadow or snow on the camera lens.
- If the camera lens becomes dirty, it cannot transmit a clear image. If water droplets, snow, or mud adhere to the lens, rinse with water and wipe with a soft cloth. If the lens is extremely dirty, wash it with a mild cleanser and rinse.
- If you scrape the camera cover, or scrub it with a hard brush or an abrasive agent, you may scratch the cover, leading to poor picture quality.
- Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
- As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.

 **CAUTION****■ Conditions which may affect the sensor**

- Do not attach any accessories within the detection range of the sensors.
- A sensor may not operate properly in the following situations:
  - There is ice, snow or mud on the sensor. (When it is removed, the normal operation will return.)
  - The sensor is frozen. (When the sensor warms up, it will return to normal.) At low temperatures in particular, sensors that are frozen may not detect a parked vehicle.
  - When the vehicle is tilted.
  - In extreme hot or cold weather.
  - When driving on bumpy roads, slopes, gravelled roads or grass.
  - Devices issuing ultrasonic waves are operated around your vehicle, such as a horn from another vehicle, motorcycle engine, air braking sound from heavy-duty vehicles.
  - When rain or water is splashed over the vehicle.
  - When a radio antenna or fender pole is mounted on your vehicle.
  - The sensor approaches too close to a parked vehicle.

### CAUTION

#### ■ Conditions which may affect the system

- If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
- Do not use the system in the following conditions:
  - Outside of parking areas
  - In unprepared parking area such as gravel or sand
  - On slippery or icy roads, or in snow
  - When using tire chains or emergency tires.
  - On roads that are not flat or straight, such as curves or slopes.
  - If the asphalt is melted due to harsh sunlight
  - If there are a large number of vehicles or pedestrians passing
  - In areas unsuitable for parking (overly small parking space, cliff etc.)
- Tire conditions
  - The tires are extremely worn, or the tire inflation pressure is low
  - Tires have received a strong impact, such as bumping against a curb, resulting in improper wheel alignment
  - Do not use tires other than those installed by the manufacturer, as the system may not function correctly. Furthermore, if you change the tires, there may be errors in the positions of the lines and frames displayed on the screen. If you wish to change your tires, contact your Lexus dealer.

 NOTICE

**■ When using the parallel parking assist mode**

- Be sure to stop the vehicle parallel to the road or shoulder. If the vehicle is not parallel, the assist location will be very near the shoulder. If it looks like the vehicle will hit or mount the shoulder, depress the brake pedal to stop the vehicle, and touch “X” on the screen to deactivate the system.
- Always check that there are no obstacles in the green frame or between your vehicle and the parking space, and that the warning flag and extended green line do not overlap any parked vehicles or walls.
- If there are obstacles in the green frame or between your vehicle and the parking space, or the warning flag or extended green line overlaps a parked vehicle or wall, there is a danger of collision. In this case, do not use the parallel parking assist mode. The same applies if the green frame overlaps the shoulder.
- The warning flag is only a guide. Be sure to directly check your surroundings and behind the vehicle for safety, and back up carefully.
- If the road surface has level variations or a gradient between the starting position and target parking position, it will not be possible to correctly set the location, which may cause the parking position to be misaligned or crooked. In this case, do not use the parallel parking assist mode.
- When the vehicle in front of the empty space is parked on the shoulder or is not parallel with the road, parallel parking assist mode cannot be used.
- If the parked vehicle is narrow, or parked close to the shoulder, the assisted parking position may be quite close to the shoulder. If the vehicle seems likely to hit or mount the shoulder, depress the brake pedal to stop the vehicle, and disable the system by touching “X”.

### NOTICE

#### ■ When using the parking assist mode (perpendicular parking)

- Always check that there are no obstacles in the green frame or between your vehicle and the parking space, and that the warning flag does not overlap any parked vehicles or walls.
- If there are obstacles in the green frame or between your vehicle and the parking space, or the warning flag overlaps a parked vehicle or wall, there is a danger of collision. In this case, do not use the parking assist mode.
- The warning flag is only a guide. Be sure to directly check your surroundings and behind the vehicle for safety, and back up carefully.
- If the road surface has level variations or a gradient between the starting position and target parking position, it will not be possible to correctly set the location, which may cause the parking position to be misaligned or crooked. In this case, do not use the parking assist mode.
- If the red area which denotes an area unsuitable for parking overlaps with the lines of the parking space, you will be unable to park, as the parking space is judged as being an area unsuitable for parking. Progress to a position where the parking space lines do not overlap with such an area.

### Driving assist systems

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

#### ■ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

#### ■ Brake assist

Generates an increased level of braking force after the brake pedal is depressed, when the system detects a panic stop situation

#### ■ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

#### ■ TRAC (Traction Control)

Maintains drive power and prevents any of the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

#### ■ Hill-start assist control

Prevents the vehicle from rolling backwards when starting on an incline or slippery slope

#### ■ EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

#### ■ VGRS (Variable Gear Ratio Steering) (if equipped)

Adjusts the wheel turning angle in accordance with the vehicle speed and steering wheel movement

### ■ VDIM (Vehicle Dynamics Integrated Management)


Provides integrated control of the ABS, brake assist, TRAC, VSC, hill-start assist control, EPS, and VGRS (if equipped) systems

Maintains vehicle stability when swerving on slippery road surfaces by controlling the brakes and engine output, steering assist, and if equipped with VGRS, steering ratio

### ■ Pre-Collision System (if equipped)

→P. 291

## When the VSC/TRAC/hill-start assist control systems are operating



If the vehicle is in danger of slipping, rolling backwards when starting on an incline, or any of the drive wheels spin, the indicator flashes to indicate that the VSC/TRAC/hill-start assist control systems have been engaged.

A buzzer (intermittent) sounds to indicate that VSC is operating.

The stop lights and high mounted stoplight turn on when the hill-start assist control system is operating.

The slip indicator light flashes as well when ABS is operating.

## Disabling TRAC and/or VSC

If the vehicle gets stuck in fresh snow or mud, TRAC and VSC may reduce power from the engine to the wheels. You may need to turn the system off to enable you to rock the vehicle in order to free it.



### ● Turning off TRAC

Quickly press and release the switch to turn off TRAC.

A message will be displayed on the multi-information display showing that TRAC has been disabled.

Press the switch again to turn the system back on.

### ● Turning off TRAC and VSC

Press and hold the switch for more than 3 seconds while the vehicle is stopped to turn off TRAC and VSC.

The VSC off indicator light will come on, and a message will be displayed on the multi-information display showing that TRAC has been disabled.

Press the switch again to turn the system back on.

### ■ Automatic reactivation of TRAC and VSC

Turning the “ENGINE START STOP” switch OFF after turning off the TRAC and VSC systems will automatically re-enable them.

### ■ Automatic TRAC reactivation

If only the TRAC system is turned off, the TRAC system will turn on when vehicle speed increases.

### ■ Automatic TRAC/VSC reactivation

If the TRAC/VSC systems are turned off, the systems will not turn on even when vehicle speed increases.

### ■ Sounds and vibrations caused by the ABS, brake assist, VSC, TRAC, hill-start assist control and VGRS systems

- A sound may be heard from the engine compartment when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
  - Vibrations may be felt through the vehicle body and steering.
  - A motor sound may be heard after the vehicle comes to a stop.
- The steering wheel may be moved slightly or a sound may be heard when the engine is started or stopped. None of these indicate that a malfunction has occurred.

### ■ Hill-start assist control is operational when

- Without paddle shift switches: The shift lever is in the “D” or “S” position.  
With paddle shift switches: The shift lever is in the “D” or “M” position.
- The brake pedal is not depressed.

### ■ EPS operation sound

When the steering wheel operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

### ■ Conditions affecting VGRS operations

In the following situations, the center position of the steering wheel may change. However, the position will return to normal after the conditions are improved.

- When the steering wheel has been operated quickly or operated for an extended period of time while the vehicle is stopped or is moving very slowly
- When the steering wheel has been held fully to the left or right
- When the battery is low or the voltage temporarily drops
- After the engine is started at lower than -22°F (-30°C).

### ■ Reduced effectiveness of EPS

The effectiveness of EPS is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The system should return to normal within 10 minutes.

### ■ If the slip indicator comes on

It may indicate a malfunction in the VSC, TRAC and hill start assist control function. (→P. 703)

## ⚠ CAUTION

### ■ The ABS does not operate effectively when

- The limits of tire gripping performance have been exceeded.
- The vehicle hydroplanes while driving at high speed on a wet or slick road.

### ■ Stopping distance when the ABS is operating will exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or roads with uneven roads

### CAUTION

#### ■ **TRAC may not operate effectively when**

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC system is operating.

Do not drive the vehicle in conditions where stability and power may be lost.

#### ■ **If hill-start assist control does not operate effectively**

Do not overly rely on the hill-start assist control. The hill start assist control may not operate effectively on steep inclines and roads covered in ice.

#### ■ **When the VSC is activated**

The slip indicator light flashes and a warning buzzer sounds. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes and a buzzer sounds.

#### ■ **When TRAC and VSC are off**

Be especially careful and drive at a speed appropriate to the road conditions. As these are systems to ensure vehicle stability and driving force, do not turn off TRAC and VSC unless necessary.

#### ■ **Replacing tires**

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire pressure level.

The ABS and VSC systems will not function correctly if different tires are fitted on the vehicle.

Contact your Lexus dealer for further information when replacing tires or wheels.

#### ■ **Handling of tires and suspension**

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

### Pre-Collision System\*

Safety systems such as the brakes and seat belts are automatically engaged to lessen impact and injuries to occupants as well as vehicle damage when the radar sensor detects an unavoidable frontal collision.

#### ■ Pre-collision seat belts

If the pre-collision sensor detects that a collision is unavoidable, the pre-collision system will retract the seat belt before the collision occurs.

The same will happen if the driver makes an emergency braking or loses control of the vehicle. (→P. 94)

However, the system will not operate in the event of skidding when the TRAC/VSC systems are disabled.

#### ■ Pre-collision brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

#### ■ Pre-collision braking

When there is a high possibility of a frontal collision, the system warns the driver using a warning light, warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to help reduce the collision speed. Pre-collision braking can be disabled using the pre-collision braking off switch. (→P. 292)

#### ■ Suspension control (If equipped)

When the system determines that a collision is unavoidable, the suspension switches to "SPORT" mode to help prevent the front of the vehicle from dropping when the brakes are applied suddenly.

### ■ Driver monitor system (if equipped)

When the system determines that there is a possibility of a collision, and that the driver is not facing forward, PCS warnings are given in advance to warn the driver. If the situation does not improve, pre-collision alert braking will be applied.

(→P. 293)

### ■ Steering gear control (VGRS) (with driver monitor system)

When the system determines that a collision is unavoidable, the steering gear ratio is changed to help improve the response to steering input.

### ■ Pre-collision alert braking (with driver monitor system)

When the system determines that the driver is not facing forward, and that the possibility of a collision persists, the brakes will be applied briefly to give the driver a sensory warning and encourage them to take preventive measures. Pre-collision alert braking can also be disabled using the pre-collision braking off switch.

## Disabling pre-collision braking



- 1 Pre-collision braking and pre-collision alert braking (if equipped) disabled
- 2 Pre-collision braking and pre-collision alert braking (if equipped) enabled

The "PCS" warning light turns on when pre-collision braking is disabled.

### Radar sensor



Detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.

### Camera sensor (with driver monitor system)



Detects pedestrians and other three-dimensional objects on or near the road ahead together with the radar sensor while the vehicle is moving. When the headlights are on, near-infrared rays are projected to ensure proper detection performance in the night time.

- 1 Camera sensors
- 2 Near-infrared ray transmitters

### Driver monitor sensor (with driver monitor system)



Detects the direction the driver is facing. The system determines whether the driver is facing forward.

### ■ Obstacles not detected

The sensor cannot detect plastic obstacles such as pylons. There may also be occasions when the radar sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

### ■ The camera sensor cannot detect obstacles in the following situations.

- The camera sensor is directly receiving intense light, such as sunlight.
- Visibility is poor because of the bad weather or other reasons.
- The sensor temperature is extremely high.

### ■ The pre-collision system is operational when

- Pre-collision seat belts (linked to the radar sensor):
  - Vehicle speed is above 3 mph (5 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed at which your vehicle is approaching an obstacle is greater than 18 mph (30 km/h).
  - The front occupants are wearing a seat belt.
- Pre-collision seat belts (linked to brake operation):
  - Vehicle speed exceeds 18 mph (30 km/h).
  - The system detects sudden braking or skidding.
  - The front occupants are wearing a seat belt.
- Pre-collision brake assist:
  - Vehicle speed is above 18 mph (30 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed at which your vehicle is approaching an obstacle is greater than 18 mph (30 km/h).
  - The brake pedal is depressed.
- Pre-collision braking:
  - The pre-collision braking off switch is not pressed.
  - Vehicle speed is above 9 mph (15 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed your vehicle is approaching an obstacle is greater than 12 mph (20 km/h).

- Suspension control (if equipped):
  - Vehicle speed is above 3 mph (5 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed your vehicle is approaching an obstacle is greater than 18 mph (30 km/h).
- Steering gear control (VGRS) (with driver monitor system):
  - Vehicle speed is above 18 mph (30 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed your vehicle is approaching an obstacle is greater than 18 mph (30 km/h).
- Pre-collision alert braking (with driver monitor system):
  - The pre-collision braking off switch is not pressed.
  - The system determines that the driver is not facing forward.
  - Vehicle speed is above 9 mph (15 km/h).
  - The relative speed difference between your vehicle and another vehicle that is forward of your vehicle, or the speed your vehicle is approaching an obstacle is greater than 12 mph (20 km/h).
  - The steering is not being turned.

■ **Conditions that may trigger the system even if there is no danger of collision**

- When there is an object by the roadside at the entrance to a curve
- When passing an oncoming vehicle on a curve
- When driving over a narrow iron bridge
- When there is a metal object on the road surface
- When there is a metal plate in the road in front of the vehicle on a downhill slope
- When there is a metal object such as a sign board in front of the vehicle on an uphill slope
- When driving on an uneven road surface
- When passing an oncoming vehicle on a left-turn
- When your vehicle rapidly closes on the vehicle in front
- When your vehicle is skidding with the TRAC/VSC system off

When the system is activated in the situations described above there is also a possibility that the seat belts will retract quickly and the brakes will be applied with a force greater than normal. When the seat belt is locked in the restricted position, stop the vehicle in a safe place, release the seat belt and refasten.

### ■ When there is a malfunction in the system

Warning light will flash and/or warning messages will turn on. (→P. 703, 712)

### ■ Certification

► For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR004

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

► For vehicles sold in Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## CAUTION

### ■ Handling the radar sensor

Observe the following to ensure the pre-collision system can function effectively.

- Keep the sensor and front grille clean at all times.  
Clean the sensor and front grille with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact.  
If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area it inspected and adjusted by a Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille or surrounding area.
- Do not modify or paint the sensor and grille.

### ■ Handling the driver monitor sensor (with driver monitor system)

Observe the following to ensure the driver monitor sensor can function effectively.

Failure to do so may result in a malfunction or may prevent the system from correctly determining the direction the driver is facing.

- Do not disassemble, damage, lift or pull on the sensor.
- Do not touch the sensor while driving.
- Do not wet or spill water on the sensor.
- Do not drop anything on or allow anything to hit against the sensor. Do not subject the sensor to an impact.
- Make sure that there are no scratches, dirt or stickers on the side of the sensor that faces the driver.
- Do not place any objects in front of the side of the sensor that faces the driver or cover the sensor.

### CAUTION

#### ■ Handling the camera sensor (with driver monitor system)

Observe the following to ensure that the PCS functions correctly:

- Keep the windshield clean at all times.  
PCS effectiveness may be reduced due to the presence of raindrops, condensation, ice or snow on the windshield.
- Do not change the installation position of a camera sensor, or remove and reinstall it. The direction of a camera sensor is precisely adjusted.
- When it is cold, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up. This will have a negative effect on the images. In such a case, use the windshield defogger to provide warm, dry air to the windshield.
- Do not place anything on the dashboard.  
Images reflected on the windshield may reduce the effectiveness of a camera sensor.
- Do not attach a sticker or other items to the windshield near a camera sensor.

#### ■ Determining the direction the driver is facing (with driver monitor system)

The driver monitor function does not operate when the vehicle is stopped.

The direction the driver is facing may not be determined correctly if any of the following conditions exist:

- There is an object between the driver monitor sensor and the driver's face, such as when the sensor is blocked.
- A part of the driver's face is covered.
- The sensor or the driver's face is exposed to intense light such as sunlight.
- The driving posture is improper.

#### ■ Headlights (with driver monitor system)

The near-infrared ray transmitter projects strong energy that is not visible. Although the transmitter normally turns off when the vehicle is stopped, never look into the headlights for your safety.

#### ■ Limitations of the pre-collision system

Do not rely on the pre-collision system. Always drive safely, taking care to observe your surroundings and checking for any obstacles or other road hazards.

 NOTICE**■ Camera sensor (with driver monitor system)**

Observe the following to ensure that the PCS functions correctly:

- Do not subject the camera sensor to strong impact or force, and do not disassemble the camera sensor.
- Do not scratch the camera lens, or let it get dirty.

**■ Headlights (with driver monitor system)**

Observe the following to ensure proper near-infrared ray projection:

- Keep the headlights clean at all times.
- The detection performance may deteriorate if the high beams are misaligned or the high beam is inoperative.

**■ Precautions for cleaning the driver monitor sensor (with driver monitor system)**

- Gently wipe the sensor with a soft cloth to prevent damage.
- Wipe any excess dirt with a cloth dampened with neutral detergent, all liquids having been wringed out of the cloth. After that, wipe again with a dry cloth.
- Do not use benzene, thinner, glass cleaners, wax, etc.

### Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load.

- Stow cargo and luggage in the trunk whenever possible. Be sure all items are secured in place.
- Be careful to keep the vehicle level. Placing the weight as far forward as possible helps maintain vehicle balance.
- For better fuel economy, do not carry unnecessary weight.

#### Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

$(\text{Cargo capacity}) = (\text{Total load capacity}) - (\text{Total weight of occupants})$


#### Steps for Determining Correct Load Limit—

- (1) Locate the statement “The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs.” on your vehicle’s placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.  
For example, if the “XXX” amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 - 750 (5 \times 150) = 650 \text{ lbs.})$
- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

Lexus does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

### Example based on your vehicle



- 1 Cargo capacity
- 2 Total load capacity

When 2 people with the combined weight of 366 lb. (166 kg) are riding in your vehicle, which has a total load capacity of 825 lb. (370 kg), the available amount of cargo and luggage load capacity will be as follows:

$$825 \text{ lb.} - 366 \text{ lb.} = 459 \text{ lb.} \quad (370 \text{ kg} - 166 \text{ kg} = 204 \text{ kg})$$

In this condition, if 3 more passengers with the combined weight of 388 lb. (176 kg) get on, the available cargo and luggage load will be reduced as follows:

$$459 \text{ lb.} - 388 \text{ lb.} = 71 \text{ lb.} \quad (204 \text{ kg} - 176 \text{ kg} = 28 \text{ kg})$$

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

### CAUTION

#### ■ Things that must not be carried in the trunk

The following things may cause a fire if loaded in the trunk:

- Receptacles containing gasoline
- Aerosol cans

#### ■ Storage precautions

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Do not place cargo or luggage in or on the following locations as the item may get under the brake or accelerator pedal and prevent the pedals from being depressed properly, block the driver's vision, or hit the driver or passengers, causing an accident.
  - Driver's feet
  - Front passenger or rear seats (when stacking items)
  - Package tray
  - Instrument panel
  - Dashboard
- Secure all items in the occupant compartment, as they may shift and injure someone during sudden braking, sudden swerving or an accident.

#### ■ Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

# Vehicle load limits

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

### ■ Total load capacity:

#### ▶ 4-seat models

675 lb. (305 kg)

#### ▶ 5-seat models

825 lb. (375 kg)

Total load capacity means the combined weight of occupants, cargo and luggage.

### ■ Seating capacity:

#### ▶ 4-seat models

4 occupants (Front 2, Rear 2)

#### ▶ 5-seat models

5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

### ■ Towing capacity

Lexus does not recommend towing a trailer with your vehicle.

### ■ Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

---

### ■ Total load capacity and seating capacity

These details are also described on the tire and loading information label.  
(→P. 662)

### CAUTION

#### ■ Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

### Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

#### ■ Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
  - Engine oil
  - Engine coolant
  - Washer fluid
- Have a service technician inspect the level and specific gravity of battery electrolyte.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the rear tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

#### ■ Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Remove any ice that has accumulated on the vehicle chassis.
- Periodically check for and remove any excess ice or snow that may have accumulated in the wheel well or on the brakes.

### ■ When driving the vehicle


Accelerate the vehicle slowly and drive at a reduced speed suitable to road conditions.

### ■ When parking the vehicle

Park the vehicle and move the shift lever to "P" without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

## Selecting snow chains

Use the correct snow chain size when mounting the snow chains. Chain size is regulated for each tire size.



- 1 Side chain  
(0.12 in. [3 mm] in diameter)
- 2 Cross chain  
(0.16 in. [4 mm] in diameter)

## Regulations on the use of snow chains

- Regulations regarding the use of tire chains vary according to location and type of road. Always check local regulations before installing chains.
- Install the chains on the rear tires.
- Retighten the chains after driving 1/4 - 1/2 mile (0.5 - 1.0 km).

### ■ Snow chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the rear tires only. Do not install tire chains on front tires.
- Install the tire chains on rear tires as tightly as possible. Retighten chains after driving 1/4 - 1/2 mile (0.5 - 1.0 km).
- Install tire chains following the instructions provided in the accompanying instructions.

### CAUTION

#### ■ Driving with snow tires

Observe the following precautions to reduce the risk of accidents.

Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the size specified for your vehicle.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.

#### ■ Driving with snow chains

Observe the following precautions to reduce the risk of accidents.

Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden turns and braking, as use of chains may adversely affect vehicle handling.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

### NOTICE

#### ■ **Repairing or replacing snow tires**

Request repairs and obtain replacement of snow tires from Lexus dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire air pressure sensor.

#### ■ **Fitting tire chains**

The tire air pressure sensor may not function correctly when tire chains are fitted.

2-5. Driving information

# Trailer towing

Lexus does not recommend towing a trailer with your vehicle. Lexus also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your Lexus is not designed for trailer towing or for the use of tow hitch mounted carriers.



### Dinghy towing

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.



#### NOTICE

##### To avoid serious damage to your vehicle

Do not tow your vehicle with four wheels on the ground.

### 3-1. Using the touch screen

|                                                            |     |
|------------------------------------------------------------|-----|
| Touch screen .....                                         | 314 |
| Set up screen<br>(without navigation<br>system) .....      | 321 |
| Information screen<br>(without navigation<br>system) ..... | 326 |

### 3-2. Using the air conditioning system and defogger

|                                                                  |     |
|------------------------------------------------------------------|-----|
| Front air conditioning<br>system (without touch<br>screen) ..... | 328 |
| Front air conditioning<br>system (with touch<br>screen) .....    | 337 |
| Rear air conditioning<br>system.....                             | 351 |
| Rear window and<br>outside rear view<br>mirror defoggers.....    | 359 |
| Windshield wiper de-icer.....                                    | 361 |

---

### **3-3. Using the audio system**

|                                                                        |     |
|------------------------------------------------------------------------|-----|
| Audio system                                                           |     |
| (without touch screen).....                                            | 363 |
| Using the radio.....                                                   | 365 |
| Using the CD player .....                                              | 369 |
| Playing back MP3 and<br>WMA discs.....                                 | 375 |
| Optimal use of the audio<br>system .....                               | 381 |
| Using the AUX adapter .....                                            | 383 |
| Using the steering wheel<br>audio switches .....                       | 384 |
| Audio system type<br>(touch screen without<br>navigation system) ..... | 386 |
| Using the radio.....                                                   | 390 |
| Using the CD/DVD<br>player .....                                       | 399 |
| Playing an audio CD and<br>MP3/WMA discs .....                         | 402 |
| Playing DVD video/<br>audio.....                                       | 407 |
| Playing a video CD .....                                               | 420 |
| CD/DVD player and DVD<br>video disc information .....                  | 424 |
| Listening to Bluetooth®<br>audio.....                                  | 434 |
| Listening to a USB<br>memory/iPod® .....                               | 446 |
| Optimal use of the<br>audio/video system.....                          | 456 |
| Using the AUX adapter .....                                            | 458 |
| Using the rear seat<br>audio controls.....                             | 459 |

|                                                 |     |
|-------------------------------------------------|-----|
| Using the steering wheel<br>audio switches..... | 464 |
|-------------------------------------------------|-----|

### **3-4. Using the rear seat entertainment system**

|                                                                                 |     |
|---------------------------------------------------------------------------------|-----|
| Rear seat entertainment<br>system features (without<br>navigation system) ..... | 468 |
| Using the radio .....                                                           | 477 |
| Using the front DVD<br>player .....                                             | 478 |
| Using the rear DVD<br>player .....                                              | 479 |
| Playing an audio CD and<br>MP3/WMA discs.....                                   | 482 |
| Playing a DVD video/<br>audio .....                                             | 483 |
| Playing a video CD.....                                                         | 493 |
| DVD player and DVD<br>video disc information .....                              | 497 |
| Using the video mode.....                                                       | 499 |
| Changing other setting.....                                                     | 501 |

## 3-5. Using the hands-free system (for cellular phone)

|                                                                                  |     |
|----------------------------------------------------------------------------------|-----|
| Hands-free system<br>(for cellular phone)<br>(without navigation<br>system)..... | 503 |
| Using the Bluetooth®<br>phone .....                                              | 509 |
| Setting the hands-free<br>system .....                                           | 523 |

## 3-6. Using the interior lights

|                            |     |
|----------------------------|-----|
| Interior lights list ..... | 552 |
| • Interior lights .....    | 553 |
| • Personal lights .....    | 554 |

## 3-7. Using the storage features

|                                |     |
|--------------------------------|-----|
| List of storage features ..... | 556 |
| • Glove box .....              | 558 |
| • Coin holder .....            | 559 |
| • Door pockets .....           | 559 |
| • Cup holders .....            | 560 |
| • Console box .....            | 562 |
| • Non smokers boxes .....      | 563 |
| • Cool box/auxiliary box ..... | 564 |
| • Auxiliary boxes .....        | 568 |

## 3-8. Other interior features

|                                              |     |
|----------------------------------------------|-----|
| Sun visors .....                             | 570 |
| Vanity mirrors .....                         | 571 |
| Clock .....                                  | 572 |
| Outside temperature<br>display .....         | 574 |
| Ashtrays .....                               | 575 |
| Cigarette lighters .....                     | 576 |
| Power outlets .....                          | 578 |
| Heated steering wheel .....                  | 581 |
| Climate control seats/<br>seat heaters ..... | 583 |
| Armrest (5-seat models) .....                | 587 |
| Retractable table<br>(4-seat models) .....   | 588 |
| Rear sunshade .....                          | 590 |
| Rear door sunshades .....                    | 593 |
| Trunk storage extension .....                | 596 |
| Coat hooks .....                             | 598 |
| Floor mat .....                              | 599 |
| Trunk features .....                         | 600 |
| Garage door opener .....                     | 602 |
| Compass .....                                | 608 |
| Safety Connect .....                         | 612 |

### 3-1. Using the touch screen

## Touch screen

By touching the screen with your finger, you can control the audio system and air conditioning system, and adjust the screen display, etc.

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".



- A** With navigation system
- B** Without navigation system

| Button       | Page                                        |
|--------------|---------------------------------------------|
| "CLIMATE"    | P. 337                                      |
| "AUDIO"      | P. 386/<br>Navigation System Owner's Manual |
| "SETUP"      | P. 321/<br>Navigation System Owner's Manual |
| "DISP"       | P. 316/<br>Navigation System Owner's Manual |
| "MAP/VOICE"  | Navigation System Owner's Manual            |
| "DEST"       | Navigation System Owner's Manual            |
| "INFO/PHONE" | P. 326/<br>Navigation System Owner's Manual |

### The initial screen



If the "ENGINE START STOP" switch is set to ACCESSORY or IGNITION ON mode, the initial screen will be displayed for a few seconds as the system starts up.

Adjusting the display

**STEP 1** Press “DISP”.

**STEP 2** Adjust the display as desired using “-” / “+” / “R” / “G”.

If you do not touch the screen for 20 seconds, the system will return to the previous screen.

► With CD mode



► With DVD mode



|              | “R”     | “G”      |
|--------------|---------|----------|
| “Color”      | Red     | Green    |
|              | “-”     | “+”      |
| “Tone”       | Lighter | Darker   |
| “Contrast”   | Weaker  | Stronger |
| “Brightness” | Darker  | Brighter |

### ■ To avoid damaging the touch screen

- Touch the screen lightly with your finger. If there is no response, remove your finger from the screen and try again.
- Remove any dirt on the screen by wiping with a soft cloth. Do not use detergent.

### ■ When using the touch screen

- If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, adjust the display on the “Display” screen or remove your sunglasses.

### ■ Changing between day mode and night mode



When the head lights are turned on, the screen dims.

However, the screen can be switched to day mode by touching “Day Mode”.

The screen will stay in day mode when the headlights are turned on until “Day Mode” is touched again.

The screen will not be displayed if the instrument panel light control is set to the brightest level.

### ■ To turn off the display

If “Screen Off” is touched, the screen display is turned off, and guidance is by voice only.

### ■ Turning on or off the rear display (if equipped)




Touch “Rear”.

## Inputting letters and numbers/List screen operation

Letters and numbers can be input via the screen.

### ■ To input letters and numbers

#### ▶ Letters and numbers



Enter letters by touching the keys directly.

 : Backspace

 : To display letters and numbers


 : To display symbols

 : Space


 : To enter in lower case

 : To enter in upper case

#### ▶ Symbols



## List screen operation



When a list is displayed, use the appropriate button to scroll through the list.



: To shift to the next or previous page. Touch



or to scroll through the displayed list.



: Shows the displayed screen position.



: If  appears to the right of the item name, the complete name is too long for the display. Touch  to scroll to the end of the name. Touch  to scroll to the beginning of the name.

### ■ If you touch

The display returns to the previous screen.

### ■ Changing the keyboard layout

Keyboard layout can be changed. →P. 323

### ■ Function help

When “?” appears on the screen, touch “?” to display an explanation of the function.

3-1. Using the touch screen

Set up screen (without navigation system)

You can change the touch screen to your desired settings.

Press “SETUP” to display the “Setup” screen.




| Switch    | Page   |
|-----------|--------|
| “General” | P. 322 |
| “Clock”   | P. 572 |
| “Voice”   | P. 325 |
| “Phone”   | P. 523 |
| “Audio”   | P. 436 |
| “Vehicle” | P. 229 |

### General settings

This screen is used for various settings such as language selection and setting operation sounds.

Touch “General” on the “Setup” screen.



- 1 Select language
- 2 Rear seat entertainment system lock (if equipped)
- 3 Beep on/off
- 4 Select keyboard layout
- 5 Delete personal data
- 6 Save the settings

Make sure to save after changing settings.


### Rear system lock setting

The operation lock on the rear seat entertainment system can be turned on or off.

### ■ Keyboard layout setting

The keyboard layout can be changed.

#### ▶ “ABC” type




#### ▶ “QWERTY” type



### ■ Delete personal data

**STEP 1** Touch “Delete Personal Data” on the “General Settings” screen.

**STEP 2**



Touch “Delete”.

Check carefully beforehand, as data cannot be retrieved once deleted.


**STEP 3** A confirmation screen will be displayed. Touch “Yes”.

The following personal data can be deleted or turned to their default settings.

- Phonebook data
- Call history data
- Speed dial data
- Voice tag data
- Bluetooth<sup>®</sup> phone data
- Volume setting
- Details setting

## Voice settings

Touch "Voice" on the "Setup" screen.



- 1 Select the voice guidance volume
- 2 Select the voice recognition talkback
- 3 Automatic recognition on/off without pressing the talk switch more than once
- 4 Select voice guidance projection
- 5 Restore default settings
- 6 Save the settings


Make sure to save after changing settings.

3-1. Using the touch screen

Information screen (without navigation system)

“Information” screen can be used to display the fuel consumption information or operate the hands-free system.

Press “INFO/PHONE” to display the “Information” screen.




| Switch             | Page   |
|--------------------|--------|
| “Phone”            | P. 509 |
| “Fuel Consumption” | P. 327 |

## Fuel consumption

Fuel consumption information from recent resets will be displayed.

Touch "Fuel Consumption" on the "Information" screen.




- 1 Resetting the consumption data
- 2 Previous fuel consumption per minute
- 3 Current fuel consumption per minute
- 4 Cruising range

Average fuel consumption for the past 30 minutes is divided by color into past averages and averages attained since the "ENGINE START STOP" switch was last turned to IGNITION ON mode.

### 3-2. Using the air conditioning system and defogger

## Front air conditioning system (without touch screen)


Air flow and outlets are automatically adjusted according to the temperature setting.



### Using the automatic mode

**STEP 1** Press "AUTO".

➡ The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

**STEP 2** Press  to switch to automatic air intake mode.

➡ The air conditioning system automatically switches between outside air and recirculated air modes.

**STEP 3** Press “^” on “TEMP” or “PASSENGER TEMP” to increase the temperature and “v” to decrease the temperature.

The temperature for the driver and passenger seats can be set separately.

## Adjusting the settings

### ■ Adjusting the temperature setting

Press “^” on “TEMP” or “PASSENGER TEMP” to increase the temperature and “v” to decrease the temperature.

The air conditioning system switches between dual and simultaneous modes each time “DUAL” is pressed.

Dual mode (the indicator on “DUAL” is on): The temperature for the left-hand seat and right-hand seat can be adjusted separately. Operating the passenger’s side temperature control will enter dual mode.

Simultaneous mode (the indicator on “DUAL” is off): Only “^” and “v” on “TEMP” (driver’s side) can be used to adjust the temperature for all seats.

### ■ Adjusting the fan speed

Press “^” (increase) or “v” (decrease) on .

Press  to turn the fan off.

### 3-2. Using the air conditioning system and defogger


#### ■ Changing the air outlets



Press "MODE".

The air outlets switch each time the button is pressed.

Air flows as shown below according to the mode selected.



Upper body



Upper body and feet



Feet



Feet and windshield

### ■ Switching between outside air and recirculated air modes


Press  .

The mode switches between  (recycles air inside the vehicle), "AUTO" and  (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

## 3-2. Using the air conditioning system and defogger


### Defogging the windshield



Press .

The air conditioning system operates automatically.

### Micro dust and pollen filter




Press .

Outside air mode switches to  (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn off automatically after approximately 1 to 3 minutes.

To stop the operation, press  again.

## Adjusting the sensitivity of the air intake control in automatic mode



Press  for 2 or more seconds.



Press “^” (increase) or “v” (decrease) on “TEMP”.


From -3 (low) to 3 (high) can be set.

3

Interior features

## Adjusting the position and opening and closing the air outlets

### ► Front center outlets



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.


## 3-2. Using the air conditioning system and defogger

### ► Front side outlets




- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Rear center outlets



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Rear side outlets



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ■ Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur:

- Immediately after "AUTO" is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

### ■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

### ■ Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting and the inside temperature.

### ■ Window defogger feature

Recirculated air mode may automatically switch to  (outside air) mode in situations where the windows need to be defogged.

### ■ When outside temperature approaches 32°F (0°C)

The air conditioning system may not operate even when "A/C" is pressed.

### ■ Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

### ■ Micro dust and pollen filter

- In order to prevent the windows from fogging up when the outside air is cold, the following may occur:
  - Outside air mode does not switch to .
  - The air conditioning system operates automatically.
  - The operation cancels after 1 minute.
- In rainy weather, the windows may fog up. Press .

### ■ Customization

Settings (e.g. A/C auto switch operation) can be changed.  
(Customizable features→P. 766)

### CAUTION

#### ■ To prevent the windshield from fogging up

Do not use  during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

### NOTICE

#### ■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.


### 3-2. Using the air conditioning system and defogger

## Front air conditioning system (with touch screen)

Air flow and outlets are automatically adjusted according to the temperature setting.

Press “CLIMATE” to display the air conditioning operation screen.

► Without rear air conditioning system




**A** With navigation system

**B** Without navigation system

### 3-2. Using the air conditioning system and defogger

#### ► With rear air conditioning system



**A** With navigation system

**B** Without navigation system


## Using the voice command system (with navigation system)

### ► Without paddle shift switches



Pull  to operate the voice command system. (→ “Navigation System Owner’s Manual”)

### ► With paddle shift switches



Press  to operate the voice command system. (→ “Navigation System Owner’s Manual”)

### Using the automatic mode

**STEP 1** Press "AUTO".

➡ The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

**STEP 2** Press  to switch to automatic air intake mode.

➡ The air conditioning system automatically switches between outside air and recirculated air modes.

**STEP 3** Press "∧" on "TEMP" or "PASSENGER TEMP" to increase the temperature and "∨" to decrease the temperature.

The temperature for the driver and passenger seats can be set separately. (without rear air conditioning system)

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting. (with rear air conditioning system)

### Adjusting the settings

#### ■ Adjusting the temperature setting

##### ► Without rear air conditioning system

Press "∧" on "TEMP" or "PASSENGER TEMP" to increase the temperature and "∨" to decrease the temperature.

The air conditioning system switches between dual and simultaneous modes each time "DUAL" is pressed.

Dual mode (the indicator on "DUAL" is on): The temperature for the left-hand seat and right-hand seat can be adjusted separately. Operating the passenger's side temperature control will enter dual mode.

Simultaneous mode (the indicator on "DUAL" is off): Only "∧" and "∨" on "TEMP" (driver's side) can be used to adjust the temperature for all seats.

► With rear air conditioning system

Press “^” on “TEMP” or “PASSENGER TEMP” to increase the temperature and “v” to decrease the temperature.

The air conditioning system switches between individual and simultaneous modes each time “4-ZONE” is pressed.

Individual mode (the indicator on “4-ZONE” is on): The temperature for the driver’s, front passenger’s and rear seats (→P. 351) can be adjusted separately. Operating the passenger’s side temperature control will enter individual mode.

Simultaneous mode (the indicator on “4-ZONE” is off): Only “^” and “v” on “TEMP” (driver’s side) can be used to adjust the temperature for all seats.

■ Adjusting the fan speed

Touch any switch of  (decrease ↔ increase) on the operation screen.

Press  to turn the fan off.


### ■ Changing the air outlets

#### ► Without rear air conditioning system



Touch any mode on the operation screen.

#### ► With rear air conditioning system




Touch any mode on the operation screen.

**1** L: Left-hand front seat

**2** R: Right-hand front seat

Different air outlets for the left-hand and right-hand front seats can be chosen.

Air flows as shown below according to the mode selected.




Upper body



Upper body and feet



Feet



Feet and windshield

### ■ Switching between outside air and recirculated air modes

Press .

The mode switches between  (recycles air inside the vehicle), “AUTO” and  (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

### Turning the air purifier off (with rear air conditioning system)

Touch “Air Purifier” on the operation screen.


The air purifier will turn off when the indicator on the switch goes off. Air will not flow from the roof vents.

To turn the air purifier on, touch “Air Purifier” again.

### Operating the rear air conditioning system on the operation screen (with rear air conditioning system)

#### ■ Using the automatic mode

**STEP 1** Touch  on the operation screen.



Touch “REAR AUTO”.

➡ The air conditioning system and air purifier will operate, and air outlets and fan speed will be set automatically.

**STEP 3** Touch “^” on “TEMP” to increase the temperature and “v” to decrease the temperature.

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

### ■ Adjusting the temperature setting

**STEP 1** Touch  on the operation screen.

**STEP 2**



Touch “^” (increase) or “v” (decrease) on the operation screen. Operating the switch will enter individual mode.

**1** L: Left-hand rear seat

**2** R: Right-hand rear seat

The air conditioning system switches between individual and simultaneous modes each time “4-ZONE” is pressed.

### ■ Adjusting the fan speed (air purifier and cooler from the roof vents)


**STEP 1** Touch  on the operation screen.

**STEP 2** Touch any switch of  (decrease ↔ increase) on the operation screen.

According to the air outlets currently selected, the fan speed of either the cool air from the roof vents or air purifier will be adjusted. (→P. 354)

Touch  on the operation screen to turn the fan off.

## Defogging the windshield



Press .

The air conditioning system operates automatically.

### Micro dust and pollen filter



Press .

Outside air mode switches to  (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.

Usually the system will turn off automatically after approximately 1 to 3 minutes.

To stop the operation, press  again.


### Adjusting the sensitivity of the air intake control in automatic mode

#### ► Touch screen with navigation system

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".

#### ► Touch screen without navigation system

**STEP 1** Press  until the "Adjust Exhaust Gas Sensor" screen appears while the vehicle is stopped.




Touch any switch of



(lower sensitivity ↔ higher sensitivity) on the operation screen.

## Adjusting the position and opening and closing the air outlets

### ► Front center outlets




- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Front side outlets



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.


### ► Rear center outlets (without rear console display)



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

## 3-2. Using the air conditioning system and defogger

### ► Rear center outlets (with rear console display)




- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Rear side outlets



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Roof side outlets (with rear air conditioning system)



- 1 Direct air flow to the left or right, up or down.

### ■ Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur:

- Immediately after “AUTO” is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

### ■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

### ■ Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting and the inside temperature.

### ■ Window defogger feature

Recirculated air mode may automatically switch to  (outside air) mode in situations where the windows need to be defogged.

### ■ When outside temperature approaches 32°F (0°C)

The air conditioning system may not operate even when “A/C” is touched.

### ■ Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the air conditioning is off, and the fan is operating, turning the “AUTO” mode on will activate the air conditioning system.

### ■ Micro dust and pollen filter

- In order to prevent the windows from fogging up when the outside air is cold, the following may occur:
  - Outside air mode does not switch to .
  - The air conditioning system operates automatically.
  - The operation cancels after 1 minute.
- In rainy weather, the windows may fog up. Press .

## 3-2. Using the air conditioning system and defogger

### ■ Air purifier (with rear air conditioning system)

The air purifier will turn on when turning the rear air conditioning system on.

### ■ Customization

Settings (e.g. A/C auto switch operation) can be changed.

(Customizable features→P. 766)

### CAUTION

#### ■ To prevent the windshield from fogging up

Do not use  during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

### NOTICE

#### ■ To prevent battery discharge


Do not leave the air conditioning system on longer than necessary when the engine is off.

3-2. Using the air conditioning system and defogger

Rear air conditioning system\*


Air flow and outlets are automatically adjusted according to the temperature setting.

► 5-seat models



## 3-2. Using the air conditioning system and defogger

### ► 4-seat models



### Using the automatic mode

**STEP 1** Press "AUTO".

➡ The air conditioning system and air purifier will operate, and air outlets and fan speed will be set automatically.

"AUTO" will be displayed on the control panel.

**STEP 2** Press "▲" on "TEMP" to increase the temperature and "▼" to decrease the temperature.

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

## Adjusting the settings

### ■ Adjusting the temperature setting

Press “^” on “TEMP” to increase the temperature and “v” to decrease the temperature.

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.


### ■ Changing the air outlets

Press .

The air outlets change as follows each time  is pressed.

Different air outlets for the right-hand and left-hand rear seats can be chosen.

Air flows as shown below according to the mode selected.



#### Upper body

When the indicator on “A/C” (on the front operation screen) is on



#### Upper body

When the indicator on “A/C” (on the front operation screen) is off

3-2. Using the air conditioning system and defogger



Upper body and feet



Feet

■ Adjusting the air volume

The volume of cool air or air from the air purifier can be adjusted according to the mode selected.

Press “^” (increase) or “v” (decrease) on .



Cool air flows from roof vents.




Air purifier operation (air flows from the rear package tray.)

Press "OFF" to turn the fan off.


## Adjusting the position and opening and closing the air outlets

### ► Rear center outlets (without rear console display)



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

### ► Rear center outlets (with rear console display)



- 1 Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.


## 3-2. Using the air conditioning system and defogger

### ► Rear side outlets



- 1** Direct air flow to the left or right, up or down.
- 2** Turn the knob to open or close the vent.

### ► Roof side outlets



Direct air flow to the left or right, up or down.

## ■ Button lock function

### ► 5-seat models



To prevent inadvertent operation, the buttons on the rear armrest can be locked. Press "MODE" until you hear a beep to lock the buttons. Pressing "MODE" again until you hear a beep will release the lock.

The indicator appears on the display when the buttons are locked.

### ► 4-seat models



## 3-2. Using the air conditioning system and defogger

### ■ Rear control panel illumination off function

#### ► 5-seat models



Control panel illumination on the rear armrest can be turned off. Press "2" until you hear a beep to turn the illumination off. Pressing "2" again until you hear a beep will turn the illumination on.

#### ► 4-seat models



### ■ Replacing the rear air conditioning filter

Replacing the air conditioning filter when using rear air conditioning or air purifier reduces air flow or deodorizing performance. (→P. 668).

#### ⚠ NOTICE

#### ■ To prevent battery discharge


Do not leave the air conditioning system on longer than necessary when the engine is off.

### 3-2. Using the air conditioning system and defogger

## Rear window and outside rear view mirror defoggers

These features are used to defog the rear window, and to remove rain-drops, dew and frost from the outside rear view mirrors.

#### ► Without touch screen



#### On/off

Press  to turn on the rear window and outside rear view mirror defoggers. The defoggers will automatically turn off after 15 minutes. The operation time changes according to the ambient temperature and vehicle speed. Pressing the button again also turns the defoggers off.

#### ► With touch screen



#### On/off

Press  to turn on the rear window and outside rear view mirror defoggers. The defoggers will automatically turn off after 15 minutes. The operation time changes according to the ambient temperature and vehicle speed. Pressing the button again also turns the defoggers off.

#### ■ The defogger can be operated when

The "ENGINE START STOP" switch is in IGNITION ON mode.

#### CAUTION

##### ■ When the outside rear view mirror defoggers are on

Do not touch the outside surface of the rear view mirrors, as they can become very hot and burn you.

### 3-2. Using the air conditioning system and defogger

## Windshield wiper de-icer\*

This feature is used to prevent ice from building up on the windshield and wiper blades.


► Without touch screen



#### On/off


Press the button to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Pressing the button again also turns the de-icer off.

► With touch screen (without navigation system)



Press "CLIMATE" to display the air conditioning operation screen.

► With touch screen (with navigation system)



Press "CLIMATE" to display the air conditioning operation screen.

\*: If equipped

3-2. Using the air conditioning system and defogger

STEP 2

Climate

L

R

LO

M

HI

A/C

Air Purifier

Touch  to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Touching the switch again also turns the de-icer off.

- The windshield wiper de-icer can be operated when  
The “ENGINE START STOP” switch is in IGNITION ON mode.

 CAUTION

- When the windshield wiper de-icer is on  
Do not touch the glass at the lower part of the windshield or to the side of the front pillars as the surfaces can become very hot and burn you.

3-3. Using the audio system

Audio system (without touch screen)

CD player with changer and AM/FM radio



| Title                                   | Page   |
|-----------------------------------------|--------|
| Using the radio                         | P. 365 |
| Using the CD player                     | P. 369 |
| Playing back MP3 and WMA discs          | P. 375 |
| Optimal use of the audio system         | P. 381 |
| Using the AUX adapter                   | P. 383 |
| Using the steering wheel audio switches | P. 384 |

■ Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.

#### CAUTION

##### ■ For vehicles sold in the U.S.A. and Canada

##### ● Part 15 of the FCC Rules

##### FCC Warning:

Any unauthorized changes or modifications to this equipment will void the user's authority to operate this device.

##### ● Laser products

- Do not take this unit apart or attempt to make any changes by yourself.

This is an intricate unit that uses a laser pickup to retrieve information from the surface of compact discs. The laser is carefully shielded so that its rays remain inside the cabinet. Therefore, never try to disassemble the player or alter any of its parts since you may be exposed to laser rays and dangerous voltages.

- This product utilizes a laser.

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

#### NOTICE

##### ■ To prevent battery discharge


Do not leave the audio system on longer than necessary when the engine is off.

##### ■ To avoid damaging the audio system

Take care not to spill drinks or other fluids on the audio system.

3-3. Using the audio system

Using the radio



#### Setting station presets

**STEP 1** Search for desired stations by turning  or pressing “^” or “v” on “SEEK•TRACK”.

**STEP 2** Press and hold the button (from “1” to “6”) the station is to be set to, and you will hear a beep.

#### Scanning radio stations

##### ■ Scanning the preset radio stations

**STEP 1** Press and hold “SCAN” until you hear a beep.

Preset stations will be played for 5 seconds each.

**STEP 2** Press “SCAN” once again, when the desired station is reached.

##### ■ Scanning all radio stations within range

**STEP 1** Press “SCAN”.

All stations with reception will be played for 5 seconds each.

**STEP 2** Press “SCAN” once again, when the desired station is reached.

## RDS (Radio Data System)

This feature allows your radio to receive station identification information and program information (classical, jazz, etc.) from radio stations which broadcast this information.

### ■ Receiving RDS broadcasts

**STEP 1** Press “^” or “v” on “TYPE FOLDER” during FM reception.

The type of program changes each time the button is pressed.

- “ROCK”
- “EASYLIS” (Easy listening)
- “CLS/JAZZ” (Classical music and Jazz)
- “R & B” (Rhythm and Blues)
- “INFORM” (Information)
- “RELIGION”
- “MISC” (Miscellaneous)
- “ALERT” (Emergency messages)

If the system receives no RDS stations, “NO PTY” appears on the display.

**STEP 2** Press “SCAN”, or “^” or “v” on “SEEK•TRACK”.

The radio seeks or scans for stations by the relevant program type.

#### ■ Displaying radio station names

Press "TEXT".

#### ■ Displaying radio text messages

Press "TEXT" twice.

If "MSG" shows in the display, a text message will be displayed.

If the text continues past the end of the display, ► is displayed. Press and hold "TEXT" until you hear a beep.

---


#### ■ When the battery is disconnected

All preset stations are erased.

#### ■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

## Using the CD player



### Loading discs

#### ■ Loading a disc

**STEP 1** Press "LOAD".

"WAIT" is shown on the display.

**STEP 2** Insert a disc when the indicator on the slot turns from amber to green.

The display changes from "WAIT" to "LOAD".

#### ■ Loading multiple discs

**STEP 1** Press and hold "LOAD" until you hear a beep.

"WAIT" is shown on the display.

**STEP 2** Insert a disc when the indicator on the slot turns from amber to green.

The display changes from "WAIT" to "LOAD".

The indicator on the slot turns to amber when the disc is inserted.

**STEP 3** Insert the next disc when the indicator on the slot turns from amber to green again.

Repeat the procedure for the remaining discs.

To stop the operation, press "CD•AUX".

## Ejecting discs

### Ejecting a disc



To select the disc to be ejected, press "∧" or "∨" on "CH•DISC".

The number of the disc selected is shown on the display.

**STEP 2** Press  and remove the disc.

### Ejecting all discs

Press and hold  until you hear a beep, then remove the disc.

## Selecting, fast forwarding, and scanning tracks

### Selecting a track

Press "∧" or "∨" on "SEEK•TRACK" to select the desired track number.

To fast forward or rewind, press and hold "∧" or "∨" on "SEEK•TRACK".

### ■ Scanning a disc

**STEP 1** Press "SCAN".

The first 10 seconds of each track will be played.

**STEP 2** Press the switch once again when the desired track is reached.

## Selecting a disc

### ■ Selecting a disc to play

To select the desired disc, press "∧" or "∨" on "CH•DISC".

### ■ Scanning loaded discs

**STEP 1** Press and hold "SCAN" until you hear a beep.

The first 10 seconds of the first track on each disc will be played.

**STEP 2** Press the switch once again when the desired disc is reached.

## Random playback

### ■ Current disc

Press "1" (RAND).

Tracks are played in random order.

### ■ All discs

Press and hold "1" (RAND) until you hear a beep.

Tracks on all loaded discs are played in random order.

## Repeating a track or a disc

### ■ Repeating a Track

Press "2" (RPT).

### ■ Repeating a disc

Press and hold "2" (RPT) until you hear a beep.

#### Switching the display

Press “TEXT”.

Each time the switch is pressed, the display changes in the order of Track no./ Elapsed time → Disc title → Track title.

#### ■ Canceling random, repeat and scan playback

Press “1” (RAND), “2” (RPT) or “SCAN” again.

#### ■ When “LOAD”, “ERROR” or “WAIT” is shown on the display

“LOAD”: This indicates that the CD player has completed loading the disc.

“ERROR”: Make sure the label of the displayed disc is facing up, and then reinsert it in the player.

“WAIT”: Operation has stopped due to a high temperature inside the player. Wait for a while and then press “CD•AUX”. Contact your Lexus dealer if the disc still cannot be played back.

#### ■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.



CDs with copy-protection features may not play correctly.

#### ■ CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

#### ■ If discs are left inside the CD player or in the ejected position for extended periods

Discs may be damaged and may not play properly.

#### ■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.


# NOTICE

## ■ CDs and adapters that cannot be used

Do not use the following types of CDs or 3 in. (8 cm) CD adapters. Doing so may damage the CD player and/or the CD insert/eject function.



- CDs that have a diameter that is not 4.7 in. (12 cm).



- Low-quality or deformed CDs.



- CDs with a transparent or translucent recording area.



- CDs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off.

#### NOTICE

##### ■ CD player precautions

Failure to follow the precautions below may result in serious damage to the CDs or the player itself.


- Do not insert anything other than CDs into the CD slot.
- Do not apply oil to the CD player.
- Store CDs away from direct sunlight.
- Never try to disassemble any part of the CD player.



- Do not insert more than one CD at a time.

### 3-3. Using the audio system

## Playing back MP3 and WMA discs



### Loading, ejecting and selecting MP3 and WMA discs

→P. 369, 370

### Selecting a folder

#### ■ Selecting folders one at a time

Press “^” or “v” on “TYPE FOLDER” to select the desired folder.

#### ■ Selecting the desired folder by cueing the first file of each folder

Press and hold “SCAN” until you hear a beep.

Press the switch once again, when the desired folder is reached.

#### ■ Returning to the first folder

Press and hold “v” on “TYPE FOLDER” until you hear a beep.

### Selecting, fast forwarding and scanning files

#### ■ Selecting one file at a time

Turn  or press “^” or “v” on “SEEK•TRACK” to select the desired file.

To fast forward or rewind, press and hold “^” or “v” on “SEEK•TRACK”.

#### ■ Selecting the desired file by cueing the files in the folder

Press “SCAN”.

Press the switch once again, when the desired file is reached.

### Repeat play

#### ■ Repeating a file

Press “2” (RPT).

#### ■ Repeating all of the files in a folder

Press and hold “2” (RPT) until you hear a beep.

### Random playback

#### ■ Playing files from a particular folder in random order

Press “1” (RAND).

#### ■ Playing all the files on a disc in random order

Press and hold “1” (RAND) until you hear a beep.

## Switching the display

Press “TEXT”.

Each time the switch is pressed, the display changes in the order of the Folder no./File no./Elapsed time → Folder name → File name → Album title (MP3 only) → Track title → Artist name.

### ■ Canceling random, repeat and scan playback

Press “1” (RAND), “2” (RPT) or “SCAN” again.

### ■ When “LOAD”, “ERROR” or “WAIT” is shown on the display.

“LOAD”: This indicates that the CD player has completed loading the disc.

“ERROR”: Make sure the label of the displayed disc is facing up, and then reinsert it in the player.

“WAIT”: Operation has stopped due to a high temperature inside the player. Wait for a while and then press “CD•AUX”. Contact your Lexus dealer if the disc still cannot be played back.

“NO MUSIC”: This indicates that MP3 or WMA files are not present on the disc.

### ■ CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected while the CD player is being used.

### ■ If discs are left inside the CD player or in the ejected position for extended periods

Discs may be damaged and may not play properly.

### ■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

#### ■ MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media <sup>TM</sup> Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

##### ● MP3 file compatibility

- Compatible standards  
MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
- Compatible sampling frequencies  
MPEG1 LAYER3: 32, 44.1, 48 (kHz)  
MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
- Compatible bit rates (compatible with VBR)  
MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps)  
MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 144, 160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural

##### ● WMA file compatibility

- Compatible standards  
WMA Ver. 7, 8, 9
- Compatible sampling frequencies  
32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)  
Ver. 7, 8: CBR 48, 64, 80, 96, 128, 160, 192 (kbps)  
Ver. 9: CBR 48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)

##### ● Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

- Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2  
CD-ROM XA Mode 2, Form 1 and Form 2
- File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet)  
MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- Maximum directory hierarchy: 8 levels (including the root)
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255

- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

- Discs containing multi-session recordings

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

- ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### ● MP3 and WMA playback

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3 or WMA format data cannot be played.

#### ● Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

#### ● Playback


- To play MP3 file with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

#### NOTICE

- **CDs and adapters that cannot be used**  
→P.373
- **CD player precautions**  
→P.374

### 3-3. Using the audio system

## Optimal use of the audio system



### Adjusting the Automatic Sound Levelizer (ASL)

Press "ASL".

The ASL switches between on and off modes each time the switch is pressed.

ASL automatically adjusts the volume and tone quality according to the noise level as you drive your vehicle.

### Changing the listening position

The sound feel setting can be changed to produce the best sound for each listening position.

Press "P•SEL" (position selector) to change the setting.

The display changes as follows each time the button is pressed.

| Display  | Listening position                                               |
|----------|------------------------------------------------------------------|
| "DRIVER" | Position best suited to the driver's seat                        |
| "FRONT"  | Position best suited to the driver's and front passenger's seats |
| "REAR"   | Position best suited to the rear seats                           |
| "ALL"    | Position best suited to all seats                                |

**Adjusting sound quality and volume balance**

**■ Changing sound quality modes**

Press "AUDIO CONTROL".  
Pressing the button changes the sound mode in the following order.  
"BAS"→"MID"→"TRE"→"FAd"→"BAL"

**■ Adjusting sound quality**

Press "∧" or "∨" to adjust the level.

| Sound qual-<br>ity mode         | Mode<br>displayed | Level    | Press ∨        | Press ∧         |
|---------------------------------|-------------------|----------|----------------|-----------------|
| Bass*                           | "BAS"             | -5 to 5  | Low            | High            |
| Mid-range*                      | "MID"             | -5 to 5  |                |                 |
| Treble*                         | "TRE"             | -5 to 5  |                |                 |
| Front/rear<br>volume<br>balance | "FAd"             | F7 to R7 | Shifts to rear | Shifts to front |
| Left/right<br>volume<br>balance | "BAL"             | L7 to R7 | Shifts to left | Shifts to right |

\*: The sound quality level is adjusted individually in each AM·FM or CD mode.

### 3-3. Using the audio system

## Using the AUX adapter

This adapter can be used to connect a portable audio device and listen to it through the vehicle's speakers.

#### STEP 1



Open the cover and connect the portable audio device.

#### STEP 2 Press "CD•AUX".

#### ■ Operating portable audio devices connected to the audio system

The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.

#### ■ When using a portable audio device connected to the power outlet

Noise may occur during playback. Use the power source of the portable audio device.

### 3-3. Using the audio system

## Using the steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.



**1** Turns the power on, selects audio source

**2** Volume

**3** Radio mode: Selects radio stations

CD mode: Selects tracks, files (MP3 and WMA) and discs

### Turning on the power

Press "MODE" when the audio system is turned off.

The audio system can be turned off by holding until you hear a beep.

### Changing the audio source

Press "MODE" when the audio system is turned on. The audio source changes as follows each time the switch is pressed. If no discs are inserted in the player, or if the external device is not connected, that mode will be skipped.

FM1→FM2→CD player→AUX→AM

## Adjusting the volume

Pull “+” to increase the volume and “-” to decrease the volume.

Hold up the switch to continue increasing or decreasing the volume.

## Selecting a radio station

**STEP 1** Press “MODE” to select the radio mode.

**STEP 2** Press “^” or “v” on  to select a radio station.

To scan for receivable stations, press and hold “^” or “v” on  until you hear a beep.

## Selecting a track/file

**STEP 1** Press “MODE” to select the CD mode.

**STEP 2** Press “^” or “v” on  to select the desired track/file.

## Selecting a disc

**STEP 1** Press “MODE” to select the CD mode.

**STEP 2** Press and hold “^” or “v” on  until you hear a beep.

## Canceling automatic selection of a radio station

Press the same switch.

## ⚠ CAUTION

### ■ To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

### 3-3. Using the audio system

## Audio system type (touch screen without navigation system)

CD and (optional) DVD player with changer, and AM/FM radio

Press “AUDIO” to display the audio control screen.

Owners of models equipped with a navigation system should refer to the “Navigation System Owner’s Manual”.

► Type A (DVD player with changer, and AM/FM radio)



CLY33AD511U

► Type B (DVD player with changer, and AM/FM radio)



► Type C (CD player with changer, and AM/FM radio)



The audio control screen may differ slightly depending on the types of audio equipped.

CD player: Plays audio CDs, CD text, MP3 discs and WMA discs.

DVD player: Plays audio CDs, CD text, video CDs, MP3 discs, WMA discs, DVD video discs and DVD audio discs.

| Title                                        | Page   |
|----------------------------------------------|--------|
| Using the radio                              | P. 390 |
| Using the CD/DVD player                      | P. 399 |
| Playing an audio CD and MP3/WMA discs        | P. 402 |
| Playing DVD video/audio                      | P. 407 |
| Playing a video CD                           | P. 420 |
| CD/DVD player and DVD video disc information | P. 424 |
| Listening to Bluetooth <sup>®</sup> audio    | P. 434 |
| Listening to a USB memory/iPod <sup>®</sup>  | P. 446 |
| Optimal use of the audio/video system        | P. 456 |
| Using the AUX adapter                        | P. 458 |
| Using the rear seat audio controls           | P. 459 |
| Using the steering wheel audio switches      | P. 464 |

■ Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.

 **CAUTION****■ For vehicles sold in the U.S.A. and Canada****● Part 15 of the FCC Rules**

FCC Warning:

Any unauthorized changes or modifications to this equipment will void the user's authority to operate this device.

**● Laser products**

- Do not take this unit apart or attempt to make any changes by yourself.

This is an intricate unit that uses a laser pickup to retrieve information from the surface of compact discs. The laser is carefully shielded so that its rays remain inside the cabinet. Therefore, never try to disassemble the player or alter any of its parts since you may be exposed to laser rays and dangerous voltages.

- This product utilizes a laser.

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

 **NOTICE****■ To prevent battery discharge**

Do not leave the audio system on longer than necessary when the engine is off.

**■ To avoid damaging the audio system**

Take care not to spill drinks or other fluids on the audio system.


3-3. Using the audio system

Using the radio


Type A and C: Press “AM•FM” or “SAT” and touch each tabs on the audio control screen to choose either an AM, FM band or SAT.

Type B: Press “AM” or “FM” and touch each tabs on the audio control screen to choose either an AM or FM band.

► Type A and C



## ► Type B



The audio control screen may differ slightly depending on the types of audio equipped.

#### Setting station presets

**STEP 1** Search for desired stations by turning  or pressing “^” or “v” on “SEEK•TRACK”.

**STEP 2** Touch and hold one of the preset stations (1 - 6) until you hear a beep.

#### Scanning radio stations (excluding XM<sup>®</sup> Satellite Radio)

##### ■ Scanning the preset radio stations

**STEP 1** Touch “SCAN” on the screen until “P.SCAN” appears.  
Preset stations will be played for a few seconds each.

**STEP 2** Touch “SCAN” once again when the desired station is reached.

##### ■ Scanning all radio stations within range


**STEP 1** Touch “SCAN” on the screen.  
“SCAN” appears on the screen and all stations within range will be played for a few seconds each.

**STEP 2** Touch “SCAN” once again when the desired station is reached.

## RDS (Radio Data System) (type A and C)

This feature allows your radio to receive station identification information and program information (classical, jazz, etc.) from radio stations which broadcast this information.

### ■ Receiving RDS broadcasts



Touch “◀ Type” or “Type ▶” on the screen.

The type of program changes each time the button is pressed.

- “ROCK”
- “EASYLIS” (Easy listening)
- “CLS/JAZZ” (Classical music and Jazz)
- “R & B” (Rhythm and Blues)
- “INFORM” (Information)
- “RELIGION”
- “MISC” (Miscellaneous)
- “ALERT” (Emergency messages)

If the system receives no RDS stations, “NO - PTY” appears on the display.

When a program is set, “Type Seek” appears.

**STEP 2** Touch “Type Seek” on the screen or press “^” or “v” on “SEEK•TRACK”.

The radio seeks or scans for stations by the relevant program type.


If no radio station of that type is found, “Nothing” appears on the screen.

#### ■ Displaying radio text messages

If “Message” appears on the screen, a text message may be displayed. While the vehicle is stopped, touch “Message” to display the text message.

When you touch “Message Off”, the display returns.

#### ■ Traffic announcement



Touch “Traffic” on the screen.

“Traf.Seek” appears on the display, and the radio will start seeking any station broadcasting traffic program information.

If no traffic program station is found, “Nothing” appears on the display.

## XM<sup>®</sup> Satellite Radio (type A and C)

#### ■ Receiving XM<sup>®</sup> Satellite Radio

**STEP 1** Press “SAT” or touch “SAT” tab on the screen.

The screen changes as follows each time “SAT” is pressed or touched.

“SAT1” → “SAT2” → “SAT3”

**STEP 2** Turn  to select the desired channel in the all categories or press “^” or “v” on “SEEK•TRACK” to select the desired channel in the current category.

### ■ Setting XM<sup>®</sup> Satellite Radio channel presets

Select the desired channel. Touch and hold one of the preset stations (1 - 6) until you hear a beep.

### ■ Changing the channel category

Touch “◀Type” or “Type▶” on the screen.

### ■ Scanning XM<sup>®</sup> Satellite Radio channels

#### ● Scanning channels in the current category

**STEP 1** Touch “SCAN” on the screen.

“SCAN” appears on the screen.

**STEP 2** Touch “SCAN” once again when the desired channel is reached.

#### ● Scanning preset channels

**STEP 1** Touch “SCAN” on the screen until “P.SCAN” appears.

**STEP 2** Touch “SCAN” once again when the desired channel is reached.

### ■ Displaying the title and artist name



Touch “Text” on the screen.

The screen will show up to 16 characters.

Touch “Text” once again to return to the previous screen.

#### ■ When the battery is disconnected

All preset stations are erased.

#### ■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

#### ■ XM<sup>®</sup> Satellite Radio

An XM<sup>®</sup> Satellite Radio is a tuner designed exclusively to receive broadcasts provided under a separate subscription. Availability is limited to the 48 contiguous states and 10 Canadian provinces.

##### ● XM<sup>®</sup> subscriptions

For detailed information about XM<sup>®</sup> Satellite Radio or to subscribe:  
U.S.A. —

Visit on the web at [www.xmradio.com](http://www.xmradio.com) or call 1-877-515-3987.

Canada —

Visit on the web at [www.xmradio.ca](http://www.xmradio.ca) or call 1-877-515-3987.

##### ● Radio ID

You will need the radio ID when activating XM<sup>®</sup> service or reporting a prob-

lem. Select “CH000” using , and the receiver's 8-character ID number will appear.

##### ● Satellite tuner

The tuner supports only Audio Services (Music and Talk) and the accompanying Text Information of XM<sup>®</sup> Satellite Radio.

### ■ If the satellite radio does not operate normally

If a problem occurs with the XM<sup>®</sup> tuner, a message will appear on the display. Refer to the table below to identify the problem, and take the suggested corrective action.

|             |                                                                                                                                                                                                                                                                                                  |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "ANTENNA"   | The XM <sup>®</sup> antenna is not connected. Check whether the XM <sup>®</sup> antenna cable is attached securely.                                                                                                                                                                              |
|             | There is a short-circuit in the antenna or the surrounding antenna cable. See a Lexus certified dealer.                                                                                                                                                                                          |
| "UNAUTH"    | You have not subscribed to the XM <sup>®</sup> Satellite Radio. The radio is being updated with the latest encryption code. Contact the XM <sup>®</sup> Satellite Radio for subscription information. When a contract is canceled, you can choose the "CH000" and all free-to-air channels.      |
|             | The premium channel you selected is not authorized. Wait for about 2 seconds until the radio returns to the previous channel or "CH001". If it does not change automatically, select another channel. If you want to listen to the premium channel, contact the XM <sup>®</sup> Satellite Radio. |
| "NO SIGNAL" | The XM <sup>®</sup> signal is too weak at the current location. Wait until your vehicle reaches a location with a stronger signal.                                                                                                                                                               |
| "LOADING"   | The unit is acquiring audio or program information. Wait until the unit has received the information.                                                                                                                                                                                            |
| "OFF AIR"   | The channel you selected is not broadcasting any programming. Select another channel.                                                                                                                                                                                                            |
| "-----"     | There is no song/program title or artist name/feature associated with the channel at that time. No action needed.                                                                                                                                                                                |

"CH UNAVL"

The channel you selected is no longer available. Wait for about 2 seconds until the radio returns to the previous channel or "CH001". If it does not change automatically, select another channel.

Contact the XM<sup>®</sup> Listener Care Center at 1-877-515-3987.

#### ■ Certifications for the radio tuner

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by trying one or more of the following:

- Reorienting or relocate the receiving antenna.
- Increasing the separation between the equipment and receiver.
- Connecting the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consulting the dealer or an experienced radio/TV technician for help.

### 3-3. Using the audio system


## Using the CD/DVD\* player

► Type A and B



\*: If equipped

#### ► Type C



The audio control screen may differ slightly depending on the types of audio equipped.

#### Loading discs

##### ■ Loading a single disc

**STEP 1** Press "LOAD".

**STEP 2** When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

##### ■ Loading multiple discs

**STEP 1** Press and hold "LOAD" until you hear a beep.

**STEP 2** When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

**STEP 3** After inserting a disc, wait until the indicator changes from flashing amber to green, then insert the next disc after the disc slot door has opened.

**STEP 4** Repeat steps 2 and 3 until you have inserted all discs.

To cancel the operation, press the "LOAD", "DISC" or "CD". If you do not insert a disc within 15 seconds, loading will be canceled automatically.

## Ejecting discs

### ■ Ejecting a disc

**STEP 1** Select the disc to be ejected.

**STEP 2** Press  and remove the disc.

### ■ Ejecting all discs

Press and hold  until you hear a beep, then remove the discs.

## Selecting a disc

### ■ To select a disc

Press “^” or “v” on “CH•DISC”.

### ■ Selecting a disc from the disc list

**STEP 1** Touch “Change Discs” on the screen.

**STEP 2**



Touch the desired disc.

### 3-3. Using the audio system

## Playing an audio CD and MP3/WMA discs

Insert a disc or press “DISC” or “CD” or touch “CD/DVD” tab or “CD” tab on the audio control screen with a disc inserted.


#### ■ Control icon screen

##### ► CD mode



- 1 Selecting a track
- 2 Selecting a file
- 3 4 Selecting a folder
- 5 Selecting a disc (→P. 401)
- 6 Repeat play
- 7 Random playback
- 8 Search playback
- 9 Setting the sound (→P. 456)

##### ► MP3/WMA mode



The audio control screen may differ slightly depending on the types of audio equipped.

## Selecting, fast forwarding and scanning tracks

### ■ Selecting a track

Press “^” or “v” on “SEEK•TRACK” to select the desired track number.

To fast forward or rewind, press and hold “^” or “v” on “SEEK•TRACK” until you hear a beep.

### ■ Selecting a track from the track list

**STEP 1** Touch “Select” of “Track” on the screen.

**STEP 2**



Touch the desired track number.



: changes the list by 5  
track groups

This function is available only when  
the vehicle is not moving.

### ■ Scanning a disc

**STEP 1** Touch “SCAN” on the screen.

“SCAN” appears on the screen.

The first 10 seconds of each track will be played.

**STEP 2** Touch “SCAN” once again when the desired track is reached.

### ■ Scanning loaded discs

**STEP 1** Touch and hold “SCAN” on the screen until “D.SCAN” appears.

The first 10 seconds of the first track on each disc will be played.

**STEP 2** Touch “SCAN” once again when the desired disc is reached.

## Selecting a folder

### ■ Selecting a folder

Touch “Folder ” or “” on the screen to select the next/previous folder.

### ■ Selecting a folder from the folder list

**STEP 1** Touch “Select” of “Folder” on the screen.

**STEP 2**



Touch the desired folder number.

 or  : changes the list by 5 folder groups

This function is available only when the vehicle is not moving.

### ■ Selecting the desired folder by cueing the first file of each folder

Touch and hold “SCAN” on the screen until “FLD.SCAN” appears. Touch “SCAN” once again when the desired folder is reached.

## Selecting, fast forwarding and scanning files


### ■ Selecting one file at a time

Turn  or press “^” or “v” on “SEEK•TRACK” to select the desired file.

To fast forward or rewind, press and hold “^” or “v” on “SEEK•TRACK” until you hear a beep.

### ■ Selecting a file from the file list

**STEP 1** Touch “Select” of “File” on the screen.



Touch the desired file number.

 or  : changes the list by 5 file groups

This function is available only when the vehicle is not moving.

### ■ Selecting a desired file by cueing the files in the folder

Touch “SCAN” on the screen.

Touch “SCAN” once again when the desired file is reached.

## Random playback

### ► Audio CD

#### ■ Current disc

Touch “RAND” on the screen.

Tracks are played in random order.

#### ■ All discs

Touch and hold “RAND” on the screen until “D.RAND” appears.

Tracks on all loaded discs are played in random order.

► MP3/WMA disc

■ **Playing files from a particular folder in random order**

Touch "RAND" on the screen.

■ **Playing all the files on a disc in random order**

Touch and hold "RAND" on the screen until "FLD.RAND" appears.

#### Repeating a track or a disc

► Audio CD

■ **Repeating a track**

Touch "RPT" on the screen.

■ **Repeating a disc**

Touch and hold "RPT" on the screen until "D.RPT" appears.

► MP3/WMA disc

■ **Repeating a file**

Touch "RPT" on the screen.

■ **Repeating all of the files in a folder**

Touch and hold "RPT" on the screen until "FLD.RPT" appears.

---

■ **Canceling scan, random and repeat playback**

Touch "SCAN", "RAND", or "RPT" on the screen once again.

■ **Displaying the title and artist name**

If a CD-TEXT disc is inserted, the titles of the disc and track will be displayed. Up to 32 letters can be displayed.

■ **Error messages**

→P. 424

### 3-3. Using the audio system

## Playing DVD video/audio\*

For safety reasons, you can enjoy the visual contents of discs only when the vehicle is completely stopped with the “ENGINE START STOP” switch in ACCESSORY or IGNITION ON mode and the parking brake applied. While you are driving, only audio contents may be played.

When a DVD video disc or DVD audio disc is inserted while driving, the main story will automatically be played. However, some discs may not be played automatically.

Insert a disc or press “DISC” or touch “CD/DVD” tab on the audio control screen with a disc inserted.

\*: If equipped

#### ■ Control icon screen

Touch any part of the screen if no icons are shown while watching a video, and the following screen appears.

##### ▶ DVD video mode



- 1 2 Menu screen appears
- 3 Settings screen appears (→P. 409)
- 4 Selecting a disc (→P. 401)
- 5 Display menu control key (→P. 410)
- 6 Returns to the full screen (only when the vehicle is completely stopped and the parking brake is applied)
- 7 Rewind
- 8 Stop
- 9 Pause  
Touch  to play
- 10 Fast forward
- 11 Setting the sound (→P. 456)

##### ▶ DVD audio mode



If  appears on the screen when you touch an icon, the operation relevant to that control is not permitted.

The audio control screen may differ slightly depending on the types of audio equipped.


### ■ Settings screen

Touch "Settings" on the control icon screen, the following screen appears.

#### ► DVD video mode



#### ► DVD audio mode



- 1 Search by title/group number
- 2 Change audio language/audio format
- 3 Change angle
- 4 Change initial setting
- 5 Display the predetermined scene and start playing from there
- 6 Change subtitle language
- 7 Change screen size
- 8 Returns to the full screen (only when the vehicle is completely stopped and the parking brake is applied)
- 9 Return to previous page
- 10 Select menu number
- 11 Go to next page
- 12 Repeat play
- 13 Random playback
- 14 Search playback

If  appears on the screen when you touch an icon, the operation relevant to that control is not permitted.

#### Fast forwarding/rewinding a disc

Touch and hold  or  on the control icon screen or press and hold “^” or “v” on “SEEK\*TRACK” until you hear a beep.


#### Slow playback

Touch  and then touch  on the control icon screen. Video is played slowly while you are touching .

#### Using the DVD menu

**STEP 1** Touch “Menu” or “Top Menu” on the control icon screen.

Touch  if the menu control key does not appear on the menu screen.



Touch menu item on the screen or touch , ,  or  to select a menu item and then touch “Enter” to select.

Note that specific items or the operating method differs from one DVD to another. Refer to the manual that comes with the DVD disc. (The above image is an example.)

## Searching a desired screen

### ■ Searching by title (DVD video mode)

**STEP 1** Touch "Search" on the "Settings" screen.

**STEP 2** Input the desired title number and then touch "OK".

### ■ Searching by group (DVD audio mode)

**STEP 1** Touch "Search" on the "Settings" screen.

**STEP 2** Input the desired group number and then touch "OK".

### ■ Playing a bonus group (DVD audio mode, if the DVD has bonus options)

**STEP 1** Touch "Search" on the "Settings" screen.

**STEP 2** Input the desired bonus group number and then touch "OK".

### ■ Searching by chapter/track

Press "∧" or "∨" on "SEEK/TRACK" to select the desired chapter/track.

### ■ Selecting a menu number (DVD audio mode)

**STEP 1** Touch "Select Number" on the "Settings" screen.

**STEP 2** Input the desired menu number and then touch "OK".

## Changing the subtitle language

**STEP 1** Touch "Subtitle" on the "Settings" screen.

**STEP 2**



Each time you touch "Change", the next available language is selected.

"Hide": hides the subtitles

**Changing the audio language (DVD video mode)**

**STEP 1** Touch “Audio” on the “Settings” screen.



Each time you touch “Change”, the next available language is selected.

**Changing the audio format (DVD audio mode)**


**STEP 1** Touch “Audio” on the “Settings” screen.



Each time you touch “Change”, the next available audio format is selected.

**Changing the angle (If the angle option is available)**


**STEP 1** Touch “Angle” on the “Settings” screen.



Each time you touch “Change”, the next available angle is selected.

## Changing screen size

**STEP 1** Touch “Wide” on the “Settings” screen.



Touch the desired switch and then touch “Save”.

- 1** Displays a 3 : 4 screen, with either side in black
- 2** Widens the 3 : 4 screen horizontally to fill the screen
- 3** Widens the 3 : 4 screen vertically and horizontally, in the same ratio, to fill the screen

## Changing the page (DVD audio mode)

Touch “Prev. Page” or “Next Page” on the “Settings” screen to change the page.

## Repeating a track (DVD audio mode)

Touch “RPT” on the “Settings” screen.

## Random playback (DVD audio mode)

Touch “RAND” on the “Settings” screen.

Tracks are played in random order.

## Scanning tracks (DVD audio mode)

**STEP 1** Touch “SCAN” on the “Settings” screen.

The first 10 seconds of each track will be played.


**STEP 2** Touch “SCAN” once again when the desired track is reached.

#### Initial DVD setup

##### ■ Displaying “Setup Menu” screen


**STEP 1** Touch “DVD Video Settings” or “DVD Audio Settings” on the “Settings” screen.

**STEP 2**



After you change the initial settings, touch “Save”.

“Default”: restores default settings



##### ■ Setting audio language (DVD video mode)

**STEP 1** Touch “Audio Language” on the “Setup Menu” screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, touch “Other” and input the desired language code. (→P. 416)

##### ■ Setting subtitle language

**STEP 1** Touch “Subtitle Language” on the “Setup Menu” screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, touch “Other” and input the desired language code. (→P. 416)

### ■ Setting menu language

**STEP 1** Touch "DVD Language" on the "Setup Menu" screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, touch "Other" and input the desired language code. (→P. 416)

### ■ Setting angle mark

If the DVD has angle options, you can turn the angle mark on or off.

**STEP 1** Touch "Angle Mark" on the "Setup Menu" screen.

**STEP 2** Select "On" or "Off".

### ■ Setting parental lock (DVD video mode)

**STEP 1** Touch "Parental Lock" on the "Setup Menu" screen.

**STEP 2** Input the 4-digit personal code and then touch "OK".

Touch  10 times to reset the personal code.

**STEP 3** Select a parental level (1 - 8). (→P. 426)

### ■ Setting the auto start

Discs that are inserted while the vehicle is in motion will automatically start playing.

**STEP 1** Touch "Auto Start" on the "Setup Menu" screen.

**STEP 2** Select "On" or "Off".

Certain discs may not play if you set to "On".

### ■ Setting sound dynamic range (DVD video mode)

The difference between the lowest volume and the highest volume can be adjusted.

**STEP 1** Touch "Sound Dynamic Range" on the "Setup Menu" screen.

**STEP 2** Select "MAX", "STD" or "MIN".

### ■ Entering a language code

If you touch “Other” on the “Audio Language” screen, “Subtitle Language” screen or “DVD Language” screen, you can select a language by entering the 4-digit language code if that language is available.

Input the 4-digit language code and then touch “OK”.

### ● Language codes

| Code | Language   | Code | Language  | Code | Language    |
|------|------------|------|-----------|------|-------------|
| 0514 | English    | 0207 | Bulgarian | 0712 | Galician    |
| 0618 | French     | 0208 | Bihari    | 0714 | Guarani     |
| 0405 | German     | 0209 | Bislama   | 0721 | Gujarati    |
| 0920 | Italian    | 0214 | Bengali   | 0801 | Hausa       |
| 0519 | Spanish    | 0215 | Tibetan   | 0809 | Hindi       |
| 2608 | Chinese    | 0218 | Breton    | 0818 | Croatian    |
| 1412 | Dutch      | 0301 | Catalan   | 0821 | Hungarian   |
| 1620 | Portuguese | 0315 | Corsican  | 0825 | Armenian    |
| 1922 | Swedish    | 0319 | Czech     | 0901 | Interlingua |
| 1821 | Russian    | 0325 | Welsh     | 0905 | Interlingue |
| 1115 | Korean     | 0401 | Danish    | 0911 | Inupiak     |
| 0512 | Greek      | 0426 | Bhutani   | 0914 | Indonesian  |
| 0101 | Afar       | 0515 | Esperanto | 0919 | Icelandic   |
| 0102 | Abkhazian  | 0520 | Estonian  | 0923 | Hebrew      |
| 0106 | Afrikaans  | 0521 | Basque    | 1001 | Japanese    |
| 0113 | Amharic    | 0601 | Persian   | 1009 | Yiddish     |
| 0118 | Arabic     | 0609 | Finnish   | 1023 | Javanese    |
| 0119 | Assamese   | 0610 | Fiji      | 1101 | Georgian    |

| Code | Language     | Code | Language           | Code | Language    |
|------|--------------|------|--------------------|------|-------------|
| 0125 | Aymara       | 0615 | Faroese            | 1111 | Kazakh      |
| 0126 | Azerbaijani  | 0625 | Frisian            | 1112 | Greenlandic |
| 0201 | Bashkir      | 0701 | Irish              | 1113 | Cambodian   |
| 0205 | Byelorussian | 0704 | Scots-Gaelic       | 1114 | Kannada     |
| 1119 | Kashmiri     | 1415 | Norwegian          | 1914 | Shona       |
| 1121 | Kurdish      | 1503 | Occitan            | 1915 | Somali      |
| 1125 | Kirghiz      | 1513 | (Afan)<br>Oromo    | 1917 | Albanian    |
| 1201 | Latin        | 1518 | Oriya              | 1918 | Serbian     |
| 1214 | Lingala      | 1601 | Panjabi            | 1919 | Siswati     |
| 1215 | Laothian     | 1612 | Polish             | 1920 | Sesotho     |
| 1220 | Lithuanian   | 1619 | Pashto,<br>Pushto  | 1921 | Sundanese   |
| 1222 | Latvian      | 1721 | Quechua            | 1923 | Swahili     |
| 1307 | Malagasy     | 1813 | Rhaeto-<br>Romance | 2001 | Tamil       |
| 1309 | Maori        | 1814 | Kirundi            | 2005 | Telugu      |
| 1311 | Macedonian   | 1815 | Romanian           | 2007 | Tajik       |
| 1312 | Malayalam    | 1823 | Kinyarwanda        | 2008 | Thai        |
| 1314 | Mongolian    | 1901 | Sanskrit           | 2009 | Tigrinya    |
| 1315 | Moldavian    | 1904 | Sindhi             | 2011 | Turkmen     |
| 1318 | Marathi      | 1907 | Sangho             | 2012 | Tagalog     |

3-3. Using the audio system


| Code | Language  | Code | Language       | Code | Language |
|------|-----------|------|----------------|------|----------|
| 1319 | Malay     | 1908 | Serbo-Croatian | 2014 | Setswana |
| 1320 | Maltese   | 1909 | Sinhalese      | 2015 | Tonga    |
| 1325 | Burmese   | 1911 | Slovak         | 2018 | Turkish  |
| 1401 | Nauru     | 1912 | Slovenian      | 2019 | Tsonga   |
| 1405 | Nepali    | 1913 | Samoa          | 2020 | Tatar    |
| 2023 | Twi       | 2209 | Vietnamese     | 2515 | Yoruba   |
| 2111 | Ukrainian | 2215 | Volapük        | 2621 | Zulu     |
| 2118 | Urdu      | 2315 | Wolof          |      |          |
| 2126 | Uzbek     | 2408 | Xhosa          |      |          |

### ■ When the menu screen is first displayed



This screen appears after the "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.

### ■ When a rear passenger selects "Setup Menu"



To cancel the set up operation from the rear seat, touch "Play".

### ■ Canceling repeat, random and scan playback

Touch "RPT", "RAND" or "SCAN" on the screen once again.

### ■ Rear system lock

→P. 357

### ■ Error messages

If "Region code error" is displayed, check the region code printed on the DVD matches the player's region code.

If a different message is displayed: →P. 424

### 3-3. Using the audio system

## Playing a video CD\*

For safety reasons, you can enjoy the visual contents of discs only when the vehicle is completely stopped with the “ENGINE START STOP” switch in ACCESSORY or IGNITION ON mode and the parking brake applied. While you are driving, only audio contents may be played.

Insert a disc or press “DISC” or touch “CD/DVD” tab on the audio control screen with a disc inserted.

#### ■ Control icon screen

Touch any part of the screen if no icons are shown while watching a video, and the following screen appears.



- 1 Settings screen appears (→P. 421)
- 2 Selecting a disc (→P. 401)
- 3 Returns to the full screen (only when the vehicle is completely stopped and the parking brake is applied)
- 4 Rewind
- 5 Stop
- 6 Pause  
Touch  to play
- 7 Fast forward
- 8 Setting the sound (→P. 456)

If  appears on the screen when you touch an icon, the operation relevant to that control is not permitted.

The audio control screen may differ slightly depending on the types of audio equipped.

\*: If equipped

### ■ Settings screen

Touch "Settings" on the control icon screen, the following screen appears.



- 1 Change sound-multiplex
- 2 Return to previous page
- 3 Select menu number (→P. 411)
- 4 Display the predetermined scene and start playing from there
- 5 Change screen size (→P. 413)
- 6 Go to next page
- 7 Returns to the full screen (only when the vehicle is completely stopped and the parking brake is applied)

If  appears on the screen when you touch an icon, the operation relevant to that control is not permitted.

#### Selecting a track

Press “^” or “v” on “SEEK•TRACK” to select the desired track number.

#### Fast forwarding/rewinding a video CD

Touch and hold  or  on the control icon screen or press and hold “^” or “v” on “SEEK•TRACK” until you hear a beep.

#### Slow playback

Touch  and then touch  on the control icon screen. Video is played slowly while you are touching .

#### Using the video CD menu

Touch “Return” on the “Settings” screen.

Refer to the manual that comes with the video CD for specific menu items.

#### Changing the sound-multiplex mode

Touch “Main/Sub” on the “Settings” screen. The mode cycles through each time “Main/Sub” is touched.

“Main” → “Sub” → “Main/Sub”



## Changing the page

- ▶ Disc menu displaying  
Touch “Prev. Page” or “Next Page” on the “Settings” screen to change the previous/next page.
- ▶ While playing the video  
Touch “Prev. Page” or “Next Page” on the “Settings” screen to change the previous/next track.

---

## ■ Error messages

→P. 424

### 3-3. Using the audio system

## CD/DVD player and DVD video disc information

### ■ Error messages

Refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to your Lexus dealer.

| Message                          | Cause                                                                                                                                                                                 | Correction Procedures                                                                                                                                          |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No disc found.                   | There is no disc in the player.                                                                                                                                                       | Insert a disc.                                                                                                                                                 |
| Check CD X<br>or<br>Check disc X | <ul style="list-style-type: none"><li>• The disc X is dirty or damaged.</li><li>• The disc X is inserted upside down.</li><li>• The disc X is not playable with the player.</li></ul> | <ul style="list-style-type: none"><li>• Clean the disc.</li><li>• Insert the disc correctly.</li><li>• Confirm the disc is playable with the player.</li></ul> |
| CD error<br>or<br>DVD error      | <ul style="list-style-type: none"><li>• There is a malfunction within the system.</li><li>• Operation is stopped due to a high temperature inside the player.</li></ul>               | <ul style="list-style-type: none"><li>• Eject the disc.</li><li>• Eject the disc and allow the player to cool down.</li></ul>                                  |
| No music files found.            | This indicates that no playable data is included in the disc.                                                                                                                         | Eject the disc.                                                                                                                                                |

### ■ DVD video discs

- The DVD player conforms to NTSC color TV formats.
- Region code: Some DVD video discs have a region code indicating the region in which you can use the DVD video disc. If the DVD video disc is not labeled as "ALL" or "1", you cannot use it on this DVD player. If you attempt to play an inappropriate DVD video disc on this player, "Region code error" appears on the screen. Even if the DVD video disc does not have a region code, you may not be able to use it.

■ Symbols shown on DVD video discs

| Symbol                                                                            | Meaning                                                                             |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  | Indicates NTSC format                                                               |
|  | Indicates the number of audio tracks                                                |
|  | Indicates the number of language subtitles                                          |
|  | Indicates the number of angles                                                      |
|  | Indicates the screen display ratios available<br>Wide screen: 16:9<br>Standard: 4:3 |
|  | Indicates the disc's region code<br>ALL: in all countries<br>Number: region code    |

#### ■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.

##### ▶ With CD player



##### ▶ With DVD player



CDs with copy-protection features may not play correctly.

#### ■ CD/DVD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

#### ■ If discs are left inside the CD/DVD player or in the ejected position for extended periods

Discs may be damaged and may not play properly.

#### ■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD/DVD player.

#### ■ DVD video disc information

##### ● DVD video discs

A DVD video disc is a Digital Versatile Disc that holds video. DVD video discs have adopted “MPEG2”, one of the world standards of digital compression technologies. The picture data is compressed by 1/40 on average and stored. Variable rate encoded technology in which the volume of data assigned to the picture is changed depending on the picture format has also been adopted. Audio data is stored using PCM and Dolby digital, which enables higher quality of sound. Furthermore, multi-angle and multi-language features will also help you enjoy the more advanced technology of DVD video.

- Viewer restrictions

This feature limits what can be viewed in conformity with the level of restrictions of the country. The level of restrictions varies depending on the DVD video disc. Some DVD video discs cannot be played at all, or violent scenes are skipped or replaced with other scenes.

Level 1: DVD video discs for children can be played.

Level 2-7: DVD video discs for children and G-rated movies can be played.

Level 8: All types of DVD video discs can be played.

- Multi-angle option

You can enjoy the same scene from different angles.

- Multi-language option

You can select the subtitle and audio languages.

- Region codes

The region codes are provided on DVD players and DVD discs. If the DVD video disc does not have the same region code as the DVD player, you cannot play the disc on the DVD player. (→P. 424)

- Audio

This DVD player can play linear PCM, Dolby Digital and MPEG audio format DVDs. Other decoded types cannot be played.

- Title and chapter

Video and audio programs stored in DVD video discs are divided into parts by title and chapter.

Title: The largest unit of the video and audio programs stored on DVD video discs. Usually, one movie, one album, or one audio program is assigned as a title.

Chapter: A title is comprised of one or more chapters.

#### ■ Sound

##### ● Dolby Digital

Manufactured under license from Dolby Laboratories

“Dolby”, “Pro Logic”, and the double-D symbol are trademarks of Dolby Laboratories.

This product incorporates copyright protection technology that is protected by method claims of certain U. S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation.

Reverse engineering or disassembly is prohibited.

##### ● DTS

“DTS” and “DTS Digital Surround” are registered trademarks of Digital Theater System, Inc.

#### ■ MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media <sup>TM</sup> Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

##### ● MP3 file compatibility

- Compatible standards  
MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
- Compatible sampling frequencies  
MPEG1 LAYER3: 32, 44.1, 48 (kHz)  
MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
- Compatible bit rates (compatible with VBR)  
MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps)  
MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 144, 160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural

- WMA file compatibility

- Compatible standards  
WMA Ver. 7, 8, 9
- Compatible sampling frequencies  
32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)  
Ver. 7, 8: CBR 48, 64, 80, 96, 128, 160, 192 (kbps)  
Ver. 9: CBR 48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)

- Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

- Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2  
CD-ROM XA Mode 2, Form 1 and Form 2
- File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet)  
MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- Maximum directory hierarchy: 8 levels (including the root)
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255

- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

- Discs containing multi-session recordings

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

- ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

- MP3 and WMA playback

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3 or WMA format data cannot be played.

- Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they may be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

### ● Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

### CAUTION

#### ■ DVD video precaution

Conversational speech on some DVDs is recorded at a low volume to emphasize the impact of sound effects. If you adjust the volume assuming that the conversations represent the maximum volume level that the DVD will play, you may be startled by louder sound effects or startled when you change to a different audio source.

Loud sounds may have a significant impact on the human body or pose a driving hazard. Keep this in mind when you adjust the volume.


 NOTICE

**■ Discs and adapters that cannot be used**

Do not use the following types of discs, 3 in. (8 cm) disc adapters or Dual Discs. Doing so may damage the player and/or disc insert/eject function.



- Discs that have a diameter that is not 4.7 in. (12 cm).



- Low-quality or deformed discs.



- Discs with a transparent or translucent recording area.



- Discs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off.

 NOTICE**■ Player precautions**

Failure to follow the precautions below may result in damage to the discs or the player itself.

- Do not insert anything other than discs into the disc slot.
- Do not apply oil to the player.
- Store discs away from direct sunlight.
- Never try to disassemble any part of the player.




- Do not insert more than one disc at a time.

3-3. Using the audio system

# Listening to Bluetooth® audio

The Bluetooth® audio system enables users to enjoy music played on a portable player from the vehicle speaker via wireless communication. This audio system supports Bluetooth®, a wireless data system capable of playing portable audio music without cables. If your portable player does not support Bluetooth®, the Bluetooth® audio system will not function.

Press “AUX•USB” until the “BT” tab appears or touch the “BT” tab on the audio control screen.



The audio control screen may differ slightly depending on the types of audio equipped.

## Status display

You can check such indicators as signal strength and battery charge on the screen.



1 Connection status

2 Battery charge

| Indicators        | Conditions                                   |
|-------------------|----------------------------------------------|
| Connection status | Blue: Good<br>Yellow: Bad<br>: Not connected |
| Battery charge    | Full  ↔  Empty                               |

## Setting up the Bluetooth® audio system

**STEP 1** Press “SETUP”.

**STEP 2**



Touch “Audio” on the “Setup” screen.

- 1** Select portable player
- 2** Setting up Bluetooth® audio

### Select portable player

**STEP 1** Touch “Select Portable Player” on the “Audio Settings” screen.


**STEP 2**



A portable player can be selected for connection.

Where no player is registered, “Empty” is displayed.

When “Portable Player Info” is touched, the following screen is displayed:




“Device Name” and “Connection Method” can be changed.

● Changing the device name

**STEP 1** Touch “Edit” on the “Portable Player Information” screen.

**STEP 2** Enter the desired name.

● Changing the connection method




Touch “From Vehicle” or “From Portable Player”.

“From Vehicle”: Connect the audio system to the portable player.

“From Portable Player”: Connect the portable player to the audio system.

■ Setting up Bluetooth® audio

Touch “Bluetooth\* Audio Settings” on the “Audio Settings” screen.



**1** Register/remove Bluetooth® audio

**2** Automatic connection on/off (→P. 440)

**3** Display passcode

**4** Display device name

**5** Display device address

**6** Restore default settings

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### ● Registering Bluetooth® audio

**STEP 1** Touch “Register” on the “BT Audio Settings” screen.




Enter the passcode into the portable player.

A message is shown if connection has been successful.

If connection fails, a message will be displayed and connection will be re-attempted.

#### ● Removing Bluetooth® audio

**STEP 1** Touch “Remove” on the “BT Audio Settings” screen.



Touch the player to remove.

A confirmation message will be displayed, touch “Yes” to remove the player.

### ● Changing the passcode

**STEP 1** Touch “Edit” of “Passcode” on the “BT Audio Settings” screen.

**STEP 2** Enter the desired passcode.

The passcode can be between 4 and 8 characters in length, and is set to “0000” by default.

### ● Changing the device name

**STEP 1** Touch “Edit” of “Device Name” on the “BT Audio Settings” screen.

**STEP 2** Enter the desired name.

### ● Restoring the default settings

**STEP 1** Touch “Default” on the “BT Audio Settings” screen.

**STEP 2** A confirmation message will be displayed, touch “Yes” to restore the default settings.

### ■ When setting the connection method to “From Portable Player”

- Connection methods differ by audio player. Consult your audio player’s manual.
- Automatic connection cannot be set to “On”.

### ■ When using Bluetooth® audio player

A confirmation message will be displayed if an attempt is made to remove a portable player.

Touch “Yes” to disconnect and remove the player.

#### Connecting Bluetooth® audio player

To use the Bluetooth® audio system, you need to enter your portable player into the system. Once registered, you can enjoy your music on the vehicle's audio system. (→P. 437)

For the operation procedure for the portable player, consult your player's accompanying instruction manual.

#### ■ When the connection method is set to "From Vehicle"

##### ▶ When auto connection is "On"

When the portable player is on standby for the connection, it will be automatically connected whenever the "ENGINE START STOP" switch is in either ACCESSORY or IGNITION ON mode.

##### ▶ When auto connection is "Off"

Manually connect the portable player in accordance with the following procedure.



Touch "Connect".

A message is shown if connection has been successful.

If connection fails, a message will be displayed and connection will be re-attempted.

### ■ When the connection method is set to “From Portable Player”

Operate the portable player and connect it to the Bluetooth® audio system.




Touch “Connect”.

A message is shown if connection has been successful.

If connection fails, a message will be displayed and connection will be re-attempted.

### Playing Bluetooth® audio



Touch  or  to play/pause.

Some titles may not be displayed depending on the type of portable player.

## Selecting a track/album

### Selecting a track

Press “^” or “v” on “SEEK•TRACK” to select the desired track number.

To fast forward or rewind, press and hold “^” or “v” on “SEEK•TRACK” until you hear a beep.

### Selecting an album



Touch “Album ▲” or “▼” to select the desired album.

## Random playback

Touch “RAND” on the screen.

Tracks are played in random order.

## Repeating a track

Touch “RPT” on the screen.

### ■ When using the Bluetooth® audio system

- In the following conditions, the system may not function.
  - If the portable player is turned off
  - If the portable player is not connected
  - If the portable player's battery is low
- There may be a delay if phone connection is carried out during Bluetooth® audio play.
- Depending on the type of portable player that is connected to the system, operation may differ slightly and certain functions may not be available.

### ■ Bluetooth® antenna

The antenna is built in to the instrument panel. If the portable player is behind the seat or in the glove box or console box, or is touching or covered by metal objects, connection status may deteriorate.

### ■ Battery charge/signal status

This display may not correspond exactly with the portable player, and this system does not have a charging function.

### ■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### ■ Compatible models

Portable players must correspond to the specifications.

- Bluetooth® specifications:

Ver. 1.1, or higher (Recommended: Ver. 1.2 or higher)

- Profiles:

- A2DP (Advanced Audio Distribution Profile) Ver. 1.0, or higher (Conformed: Ver. 1.2)
- AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Conformed: Ver. 1.3)

However, please note that some functions may be limited depending on the type of portable player.

Please go to the website at <http://www.lexus.com/> to find approved portable players for this system.

#### ■ Certification

→P. 507

#### ■ Reconnecting the portable player

If the portable player is disconnected with a poor reception when the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode, the system automatically reconnects the portable player.

If you have switched off the portable player yourself, follow the instructions below to reconnect:

- Select the portable player again
- Enter the portable player

#### ■ Canceling random and repeat playback

Touch “RAND” or “RPT” on the screen once again.

#### ■ When transferring ownership of your vehicle

Be sure to remove the registered portable player from the system.

 **CAUTION****■ FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Radio Frequency Radiation Exposure.** This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 7.9 in. (20 cm) and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

**■ While driving**

Do not use the portable player or connect the Bluetooth® system.

 **NOTICE****■ When leaving the vehicle**


Do not leave your portable player in the vehicle. The inside of the vehicle may become hot, causing damage to the portable player.

3-3. Using the audio system

# Listening to a USB memory/iPod®

Connecting a USB memory or iPod® enables you to enjoy music from the vehicle speakers.

Press “AUX+USB” until the “USB” tab appears or touch the “USB” tab on the audio control screen.



The above illustration shows an iPod® screen.

The audio control screen may differ slightly depending on the types of audio equipped.

## Connecting the USB memory/iPod®



Open the cover and connect the player using a cable.

## Playing an iPod®


### ■ Play/pause



Touch  or  to play/pause.

### ■ Selecting a play mode

**STEP 1** Touch "Menu" on the screen.



Select the desired play mode by touching the "Playlists", "Artists", "Albums", "Songs", "Podcasts", "Audiobooks", "Genres" or "Composers" tabs.

## Selecting a folder (USB memory)

### ■ Selecting a folder

Touch “Folder ▲” or “▼” on the screen to select the next/previous folder.

### ■ Selecting a folder from the list

**STEP 1** Touch “Select” of “Folder” on the screen.

**STEP 2**



Touch the desired folder number.

 or  : changes the list by 5 folder groups

This function is available only when the vehicle is not moving.

### ■ Selecting the desired folder by cueing the first file of each folder

Touch and hold “SCAN” on the screen until “FLD.SCAN” appears. Touch “SCAN” once again when the desired folder is reached.

## Selecting a file/track

### ■ Selecting one file/track at a time


Turn  or press “^” or “v” on “SEEK•TRACK” to select the desired file/track.

To fast forward or rewind, press and hold “^” or “v” on “SEEK•TRACK” until you hear a beep.

### ■ Selecting a file/track from the list

**STEP 1** Touch “Select” of “File”/“Track”.

**STEP 2**



Touch the desired file/track number.



or : changes the list by 5 file/track groups

This function is available only when the vehicle is not moving (USB memory).

### ■ Selecting the desired file by cueing the files in the folder (USB memory)

Touch “SCAN” on the screen.

Touch “SCAN” once again when the desired file is reached.

### Random playback

► USB memory

#### ■ Playing files from a particular folder in random order

Touch “RAND” on the screen.

#### ■ Playing the all files from a USB memory in random order

Touch and hold “RAND” on the screen until “FLD.RAND” appears.

► iPod®

#### ■ Playing tracks from one playlist or album in random order

Touch “RAND” on the screen.

#### ■ Playing tracks all the playlists or albums in random order

Touch and hold “RAND” on the screen until “A.RAND” appears.

#### Repeat play

##### ■ Repeating a file/track

Touch “RPT” on the screen.

##### ■ Repeating all of the files in a folder (USB memory)

Touch and hold “RPT” on the screen until “FLD.RPT” appears.

---

##### ■ Canceling scan, repeat and random playback

Touch “SCAN”, “RPT” or “RAND” on the screen once again.

##### ■ About iPod®

- iPod is a registered trademark of Apple, Inc., registered in the U.S.A. and other countries.
- “Made for iPod” means that an electronic accessory has been designed to connect specifically to iPod® and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device on its compliance with safety and regulatory standards.

##### ■ iPod® functions

- When an iPod® is connected and the audio source is changed to iPod® mode, the iPod® will resume play from the same point in which it was last used.
- Depending on the iPod® that is connected to the system, certain functions may not be available. If a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it once again may resolve the problem.
- While connected to the system, the iPod® cannot be operated with its own controls. It is necessary to use the controls of the vehicle's audio system instead.

### ■ USB memory functions

- Depending on the USB memory that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it once again may resolve the problem.
- If the USB memory still does not begin operation after being disconnected and reconnected, format the memory.

### ■ iPod® problems

To resolve most problems encountered when using your iPod®, disconnect your iPod® from the vehicle iPod® connection and reset it. For instructions on how to reset your iPod®, refer to your iPod® Owner's Manual.

### ■ Error messages for iPod®

"Connection error.": This indicates a problem in the iPod® or its connection.

"There are no files available for playback.": This indicates that there is no music data in the iPod®.

"No items available.": This indicates that some available songs are not found in a selected playlist.

### ■ Error messages for USB memory

"Connection error.": This indicates a problem in the USB memory or its connection.

"There are no files available for playback.": This indicates that no MP3/WMA files are included in the USB memory.

### ■ Compatible models for iPod®

- iPod® 5th generation Ver. 1.2 or later
- iPod® nano 3rd generation Ver. 1.0 or later
- iPod® nano 2nd generation Ver. 1.1.2 or later
- iPod® nano Ver. 1.3 or later
- iPod® touch Ver. 1.1 or later
- iPod® classic Ver. 1.0 or later

iPhone®, iPod® mini, iPod® shuffle, iPod® photo and 4th generation and earlier models of iPod® are not compatible with this system.

Items related to standards and limitations are as follows:

- Maximum number of lists in device: 9999
- Maximum number of songs in device: 65535
- Maximum number of songs per list: 65535

#### ■ USB memory

- Compatible devices

USB memory that can be used for MP3 and WMA playback

- Compatible device formats

The following device formats can be used:

- USB communication formats: USB2.0 FS (12 Mbps)
- File formats: FAT16/32 (Windows)
- Correspondence class: Mass storage class

MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 999 (including the root)
- Maximum number of files in a device: 65025
- Maximum number of files per folder: 255

- MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media<sup>TM</sup> Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

- MP3 file compatibility

- Compatible standards  
MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 AUDIO LAYERII, III, MPEG2.5)
- Compatible sampling frequencies  
MPEG1 AUDIO LAYERII, III: 32, 44.1, 48 (kHz)  
MPEG2 AUDIO LAYERII, III: 16, 22.05, 24 (kHz)  
MPEG2.5: 8, 11.025, 12 (kHz)
- Compatible bit rates (compatible with VBR)  
MPEG1 AUDIO LAYERII, III: 32-320 (kbps)  
MPEG2 AUDIO LAYERII, III: 32-160 (kbps)  
MPEG2.5: 32-160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural

- WMA file compatibility

- Compatible standards  
WMA Ver. 9
- Compatible sampling frequencies  
HIGH PROFILE 32, 44.1, 48 (kHz)
- Compatible bit rates  
HIGH PROFILE 32-320 (kbps, VBR)

- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

- ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### ● MP3 and WMA playback

- When a device containing MP3 or WMA files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3 or WMA files or create any unnecessary folders.
- When the USB device is connected and the audio source is changed to USB memory player mode, the USB device will start playing the first file in the first folder. If the same device is removed and reinserted (and the contents have not been changed), the USB device will resume play from the same point in which it was last used.

#### ● Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be skipped (not played).

#### ● Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

#### CAUTION

##### ■ While driving

Do not connect or disconnect an iPod® or USB memory or operate the controls while driving. Doing so may lead to inattention to driving and cause a serious accident.

**NOTICE****■ To prevent damage to the player or its terminal**

- Do not leave your portable player in the vehicle. The temperature inside of the vehicle may become high, resulting in damage to the player.
- Do not push down on or apply unnecessary pressure to the player while it is connected.
- Do not insert foreign objects into the port.


### 3-3. Using the audio system

## Optimal use of the audio/video system



Touch “Sound” to adjust the sound settings.

► “Sound” tab



**1 2 3** Touch “-” and “+” to adjust the treble, mid or bass to a level between -5 to 5.

**4 5** Touch “Front” and “Rear” to adjust the front/rear audio balance to a level between F7 and R7.

**6 7** Touch “L” and “R” to adjust the left/right audio balance to a level between L7 and R7.

## ► “DSP” tab



- 1 Surround on/off (with DVD player)
- 2 Automatic Sound Levelizer (ASL) on/off

#### ■ The sound quality level is adjusted individually

The treble, mid and bass levels can be adjusted for the each audio mode separately.

#### ■ About Automatic Sound Levelizer (ASL)

ASL automatically adjusts the volume and tone quality according to the vehicle speed, wind noise or other noise.

### 3-3. Using the audio system

## Using the AUX adapter

This adapter can be used to connect a portable audio device and listen to it through the vehicle's speakers.

#### STEP 1



Open the cover and connect the portable audio device.

**STEP 2** Press “AUX•USB” or touch “AUX” tab on the audio control screen.

#### ■ Operating portable audio devices connected to the audio system

The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.

#### ■ When using a portable audio device connected to the power outlet


Noise may occur during playback. Use the power source of the portable audio device.

### 3-3. Using the audio system

## Using the rear seat audio controls\*

Some front audio features can be controlled from the rear seats.


#### ► 5-seat models



\*: If equipped

► 4-seat models

Radio: Selecting a station  
Audio CD, DVD audio, Video CD, Bluetooth® audio or iPod®: Selecting a track  
DVD video: Selecting a chapter  
MP3 CD, WMA CD or USB memory: Selecting a file



**Turning the power on/off**

Press “PWR” to turn the front audio system on.

Pressing the button again turns the system off.

### Changing the audio source

Press “MODE” to change the audio source. The audio source changes as follows each time the button is pressed. If no discs are inserted in the player, or if the external device is not connected, that mode will be skipped.

FM1→FM2→DVD player→Bluetooth<sup>®</sup> audio player→VTR→  
AUX→iPod<sup>®</sup> or USB memory→AM

### Adjusting the volume

Press “^” on “VOL” to increase the volume and “v” to decrease the volume.

Press and hold the button to continue increasing or decreasing the volume.

### Selecting a radio station

#### ■ Select a radio station

**STEP 1** Press “MODE” to select a frequency band.

**STEP 2** Press “^” or “v” on “TUNE TRACK” to select a radio station.

To scan for receivable stations, press and hold “TUNE TRACK” until you hear a beep.

#### ■ Select a preset station

**STEP 1** Press “MODE” to select a frequency band.

**STEP 2** Press “1” (CH) to select a preset station.

#### Selecting a track

- ▶ Audio CD, DVD audio or Video CD

**STEP 1** Press “MODE” to select the DVD player.

**STEP 2** Press “1” (DISC) to select a disc.

**STEP 3** Press “^” or “v” on “TUNE TRACK” to select a track.

- ▶ Bluetooth® audio player

**STEP 1** Press “MODE” to select the Bluetooth® audio player.

**STEP 2** Press “2” to select an album.

**STEP 3** Press “^” or “v” on “TUNE TRACK” to select a track.

- ▶ iPod®

**STEP 1** Press “MODE” to select the iPod®.

**STEP 2** Press “^” or “v” on “TUNE TRACK” to select a track.

#### Selecting a chapter (DVD video mode)

**STEP 1** Press “MODE” to select the DVD player.

**STEP 2** Press “1” (DISC) to select a disc.

**STEP 3** Press “^” or “v” on “TUNE TRACK” to select a chapter.

#### Selecting a file

- ▶ MP3 CD or WMA CD

**STEP 1** Press “MODE” to select the DVD player.

**STEP 2** Press “1” (DISC) to select a disc.

**STEP 3** Press “2” (FOLDER) to select a folder.

**STEP 4** Press “^” or “v” on “TUNE TRACK” to select a file.

- ▶ USB memory

**STEP 1** Press “MODE” to select the USB memory.

**STEP 2** Press “2” (FOLDER) to select a folder.

**STEP 3** Press “^” or “v” on “TUNE TRACK” to select a file.

### ■ Fast forwarding or rewinding a track, chapter, or file

Press and hold “^” or “v” on “TUNE TRACK”.

### ■ Button lock function

To prevent inadvertent operation, some buttons on the rear armrest can be locked. (→P. 357)

### ■ Rear control panel illumination off function

Control panel illumination on the rear armrest can be turned off. (→P. 358)

### ■ When “ERROR”, “WAIT” or “NO MUSIC” is shown on the display

Refer to the following and take the appropriate measures. If the problem is not rectified, take the vehicle to your Lexus dealer.

“ERROR”: This indicates a trouble either in the disc or inside the player. The disc may be dirty, damaged, or inserted up-side down.

“WAIT”: Operation is stopped due to a high temperature inside the player. Eject the disc and allow the player to cool down.

“NO MUSIC”: This indicates that an MP3/WMA file is not included in the disc.

### 3-3. Using the audio system

## Using the steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.

#### ► Without paddle shift switches



**1** Turns the power on, selects audio source

**2** Volume

**3** Radio mode: Selects radio stations

CD mode: Selects tracks, files (MP3 and WMA) and discs

DVD mode: Selects tracks, chapters and discs

Bluetooth<sup>®</sup> audio player mode:

Selects tracks and albums

iPod<sup>®</sup> mode: Selects tracks

USB memory mode:  
Selects files and folders

#### ► With paddle shift switches



### Turning on the power

Press “MODE” when the audio system is turned off.

The audio system can be turned off by holding until you hear a beep.

### Changing the audio source

Press “MODE” when the audio system is turned on. The audio source changes as follows each time the switch is pressed. If no discs are inserted in the player, or if the external device is not connected, that mode will be skipped.

With CD player:

FM1→FM2→SAT1→SAT2→SAT3→CD player→  
Bluetooth<sup>®</sup> audio player→AUX→iPod<sup>®</sup> or USB memory→AM

With DVD player:

Type A:  
FM1→FM2→SAT1→SAT2→SAT3→DVD player→  
Bluetooth<sup>®</sup> audio player→VTR→AUX→iPod<sup>®</sup> or USB memory→  
AM

Type B:  
FM1→FM2→DVD player→Bluetooth<sup>®</sup> audio player→VTR→  
AUX→iPod<sup>®</sup> or USB memory→AM

#### Adjusting the volume

► Without paddle shift switches

Pull “+” to increase the volume and “-” to decrease the volume.

Hold the switch in that position to continue increasing or decreasing the volume.

► With paddle shift switches

Press “+” to increase the volume and “-” to decrease the volume.

Hold the switch in that position to continue increasing or decreasing the volume.

#### Selecting a radio station

**STEP 1** Press “MODE” to select the radio mode.

**STEP 2** Press “^” or “v” on  to select a radio station.

To scan for receivable stations, press and hold “^” or “v” on  until you hear a beep.

#### Selecting a track/file or chapter

**STEP 1** Press “MODE” to select the CD, DVD, Bluetooth<sup>®</sup> audio player, iPod<sup>®</sup> or USB memory mode.

**STEP 2** Press “^” or “v” on  to select the desired track/file or chapter.

#### Selecting a disc

**STEP 1** Press “MODE” to select the CD or DVD mode.

**STEP 2** Press and hold “^” or “v” on  until you hear a beep.

### Selecting a folder

**STEP 1** Press “MODE” to select USB memory mode.

**STEP 2** Press and hold “^” or “v” on  until you hear a beep.

### Selecting an album

**STEP 1** Press “MODE” to select Bluetooth® audio player mode.

**STEP 2** Press and hold “^” or “v” on  until you hear a beep.

### ■ Canceling automatic selection of a radio station

Press the same switch.

### CAUTION


#### ■ To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

### Rear seat entertainment system features\* (without navigation system)

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".


► 5-seat models



- 1 Front audio system
- 2 Display
- 3 DVD player
- 4 Headphone volume control dials and headphone jacks
- 5 Rear seat entertainment system controller
- 6 A/V input adapter

468

► 4-seat models



- 1 Front audio system
- 2 Display
- 3 DVD player
- 4 Headphone volume control dials and headphone jacks
- 5 A/V input adapter
- 6 Rear seat entertainment system controller

### 3-4. Using the rear seat entertainment system

#### Rear seat entertainment system controller



To use the buttons under the cover, slide the cover down.

#### Turning on or off the display (5-seat models)



##### ● On

Press "ON", "DVD", "VIDEO", "SOURCE" or .

##### ● Off

Press "OFF".

Turning on or off operations can be performed from the front seat.  
(→P. 317)

## Opening or closing the display (4-seat models)

### ■ Opening or closing the display



#### ● Open

Press **OPEN/CLOSE**, "ON", "DVD", "VIDEO", "SOURCE" or **▶ ||**.

#### ● Close

Press **OPEN/CLOSE** or "OFF".

If the display is closed with an image shown, the image will automatically turn off. (When you press **OPEN/CLOSE**, the sound will not be turned off.)

Opening and closing operations can be performed from the front seat. (→P. 317)

### ■ Tilting the display




The display angles change as follows each time **TILT** is pressed.

**1** → **2** → **3** → **4** → **1**

The display angle is memorized and will be recalled when the "ENGINE START STOP" switch is turned to ACCESSORY or IGNITION ON mode again.

## 3-4. Using the rear seat entertainment system

### ■ Caution screen



This screen appears for a few seconds when the rear display turns on.

During this time, only  can be operated. (4-seat models)

### Headphone jacks

#### ► 5-seat models



To listen to the rear audio, use headphone.

**1** To use the headphone  
Connect it to the jack.

**2** To adjust the volume  
Turn it clockwise to increase the volume. Turn it counterclockwise to decrease the volume.

#### ► 4-seat models



To listen to the rear audio, use headphone.

**1** To use the headphone  
Connect it to the jack.

**2** To adjust the volume  
Turn it clockwise to increase the volume. Turn it counterclockwise to decrease the volume.

## Changing the source

### STEP 1




Press "SOURCE" to display the source screen.

### STEP 2



Select an audio source using "ENT".

## Changing the speaker output



To play the rear audio over the speakers in the vehicle, turn "Speaker Output" on.

### 3-4. Using the rear seat entertainment system

#### ■ The rear seat entertainment system can be used when

The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.

#### ■ Jam protection function (4-seat models)

The display will stop closing and return to its previous position if something gets in the way of it closing.

#### ■ When appears on the screen

It indicates that the selected icon cannot be used at this time.

#### ■ Rear system lock

→P. 322

#### ■ Before using the controller (for new vehicle owners)



An insulating sheet is set to prevent the batteries from being depleted. Remove the insulating sheet before using the remote control.

#### ■ When the controller batteries are fully depleted



Remove the depleted batteries and install new batteries.

#### ■ Headphones

With some headphones generally available in the market, it may be difficult to catch signals properly. Lexus recommends the use of Lexus genuine wireless headphones.

Contact your Lexus dealer for further details.

## ■ Volume

- Adjust the volume when you connect the headphone to the jack. Loud sounds may have a significant impact on the human body.
- Conversational speech on some DVDs is recorded at a low volume to emphasize the impact of sound effects. If you adjust the volume assuming that the conversations represent the maximum volume level that the DVD will play, you may be startled by louder sound effects or when you change to a different audio source. Be sure to adjust the volume with this in mind.

## CAUTION

### ■ When the rear seat entertainment system is not used

Keep the display closed.

In the event of an accident or sudden braking, an occupant may hit the opened display resulting in injury.

### ■ To prevent accidents and electric shock

Do not disassemble or modify the remote control.

### ■ When the remote controller is not used

Stow the remote controller.

Injuries may result in the event of an accident or sudden braking.

### ■ Closing the display (4-seat models)

Never use any part of your body to intentionally activate the jam protection function.

#### NOTICE

##### ■ Cleaning the display

Wipe the display with a dry soft cloth.

If the screen is wiped with a rough cloth, the surface of the screen may be scratched.

##### ■ To prevent damage to the remote control

- Keep the remote control away from direct sunlight, high temperature and high humidity.
- Do not drop or knock the remote control against hard objects.
- Do not sit on or place heavy objects on the remote control.

##### ■ DVD player


Never try to disassemble or oil any part of the DVD player. Do not insert anything other than a disc into the slot.

##### ■ Closing the display (4-seat models)

Do not close the display using your hand. Doing so may result in a malfunction.

### 3-4. Using the rear seat entertainment system

## Using the radio



Select radio mode on the source screen.

### Selecting a preset station

Press “^” or “v” on “CH DISC” until the desired station appears on the screen.


### Tuning the station

Press  or  until the desired station appears on the screen.

Press and hold  or , the stations will be searched automatically.

### 3-4. Using the rear seat entertainment system

## Using the front DVD player



### Selecting a disc



- Audio CD, MP3/WMA discs →P.482
- DVD video/audio →P.483
- Video CD →P.493

### 3-4. Using the rear seat entertainment system

## Using the rear DVD player



Press "DVD" or select "Rr-DVD" on the source screen.

### Loading a disc

#### ► 5-seat models




Insert the disc into the slot with the label side up.

The "DISC" indicator light turns on while the disc is loaded.

The player will play the track or chapter, and will repeat it after it reaches the end.

### 3-4. Using the rear seat entertainment system

#### ► 4-seat models



Open the cover.



Insert the disc into the slot with the label side up.

The "DISC" indicator light turns on while the disc is loaded.

The player will play the track or chapter, and will repeat it after it reaches the end.

**STEP 3** Close the cover.

#### Ejecting a disc


#### ► 5-seat models



Press  and remove the disc.

## ► 4-seat models

STEP 1



Open the cover.

STEP 2

Press  and remove the disc.

STEP 3 Close the cover.

## Playing a disc



- Audio CD, MP3/WMA discs →P.482
- DVD video/audio →P.483
- Video CD →P.493

### 3-4. Using the rear seat entertainment system

## Playing an audio CD and MP3/WMA discs

#### ■ Selecting a track/file




Press  or  until the desired track/file number appears on the screen.

#### ■ Fast forwarding or rewinding a track/file

Press and hold  or .

#### ■ Selecting a folder



Press “^” or “v” on  until the desired folder number appears on the screen.

### 3-4. Using the rear seat entertainment system

## Playing a DVD video/audio

#### ■ Controller




- 1 Turning on the DVD mode
- 2 Inputting the selected icon
- 3 Selecting an icon
- 4 Turning on the title selection screen
- 5 Rewind
- 6 Selecting a chapter/track
- 7 Turning on the control icon screen
- 8 Stop
- 9 Fast forward
- 10 Turning on the menu screen
- 11 Play/pause
- 12 Volume up/down

#### ■ Control icon screen


Press **OPTION** if no icons are shown while watching a DVD video/ audio, and the following screen appears.

##### ► DVD video mode



- 1 Hide the buttons
- 2 Settings screen appears (→P. 485)
- 3 Fast forward
- 4 Play/pause
- 5 Stop
- 6 Rewind
- 7 8 Menu screen appears
- 9 Change audio format

##### ► DVD audio mode




If  appears on the screen when you select an icon, the operation relevant to that control is not permitted.


### ■ Settings screen

Select "Settings" on the control icon screen, the following screen appears.

#### ► DVD video mode



#### ► DVD audio mode



- 1 Change initial setting
- 2 Select menu number
- 3 Return to previous screen
- 4 Change angle
- 5 Change subtitle language
- 6 Change audio language/audio format
- 7 Go to next page
- 8 Return to previous page
- 9 Display the predetermined scene and start playing from there
- 10 Search by title/group number

#### Turning on or off the control icons

Press  to turn on the control icons.

Press  once again or select "Hide Buttons" on the control icon screen to turn off the control icon.

#### Turning on the title selection screen

Press  or select "Top Menu" on the control icon screen to turn on the title selection screen. For the operation of the title selection screen, see the separate manual for the DVD disc.

#### Turning on the menu screen (DVD video mode)

Press  or select "Menu" on the control icon screen to turn on the menu screen. For the operation of the menu screen, see the separate manual for the DVD disc.

#### Fast forwarding/rewinding a disc

Perform either of the following:

- Select  or  on the control icon screen by pressing and holding "ENT".
- Press and hold  or .

## Slow playback

Perform either of the following:

- Select  and then select . Video is played slowly when you select  by pressing and holding "ENT".
- Press  and then press and hold . Video is played slowly while  is being pressed.

## Searching a desired screen

### ■ Searching by title (DVD video mode)

**STEP 1** Select "Search" on the settings screen.

**STEP 2** Input the desired title number and then select "OK".

### ■ Searching by group (DVD audio mode)

**STEP 1** Select "Search" on the settings screen.

**STEP 2** Input the desired group number and then select "OK".

### ■ Playing a bonus group (DVD audio mode, if the DVD has bonus options)

**STEP 1** Select "Search" on the settings screen.

**STEP 2** Input the desired bonus group number and select "OK".

### ■ Searching by chapter/track

Press  or  to select the desired chapter/track.

### ■ Selecting a menu number (DVD audio mode)

**STEP 1** Select "Select Number" on the settings screen.

**STEP 2** Input the desired menu number and select "OK".

### Changing the subtitle language

**STEP 1** Select "Subtitle" on the settings screen.

**STEP 2**



Select "Subtitle".

Each time you press "ENT", the next available language is selected.

"Hide": hide the subtitle

### Changing the audio language (DVD video mode)

**STEP 1** Select "Audio" on the settings screen.

**STEP 2**



Select "Audio".

Each time you press "ENT", the next available language is selected.

### Changing the audio format (DVD audio mode)

**STEP 1** Select "Audio" on the control icon screen.



Select "Audio".

Each time you press "ENT", the next available audio format is selected.

### Changing the angle (If the angle option is available)

**STEP 1** Select "Angle" on the settings screen.



Select "Angle".

Each time you press "ENT", the next available angle is selected.

### Changing the page (DVD audio mode)

Select "Prev. Page" or "Next Page" on the settings screen to change the page.

#### Initial DVD setup

##### ■ Displaying “Setup Menu” screen

**STEP 1** Select “Setup” on the settings screen.



After you change the initial settings, select “OK”.

“Default”: restores default settings

“Page 2→”: goes to Page 2



##### ■ Setting audio language (DVD video mode)

**STEP 1** Select “Audio Language” on the “Setup Menu 1” screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, select “Other” and input the desired language code. (→P. 491)

##### ■ Setting subtitle language

**STEP 1** Select “Subtitle Language” on the “Setup Menu 1” screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, select “Other” and input the desired language code. (→P. 491)

### ■ Setting menu language

**STEP 1** Select "DVD language" on the "Setup Menu 1" screen.

**STEP 2** Select the desired language.

If you cannot find the desired language, select "Other" and input the desired language code. (→P. 491)

### ■ Setting angle mark

If the DVD has angle options, you can turn the angle mark on or off.

**STEP 1** Select "Angle Mark" on the "Setup Menu 1" screen.

**STEP 2** Select "ON" or "OFF".

### ■ Setting parental lock (DVD video mode)

**STEP 1** Select "Parental Lock" on the "Setup Menu 1" screen.

**STEP 2** Input the 4-digit personal code and then select "OK".

Select  10 times to reset the personal code.

**STEP 3** Select a parental level (1 - 8). (→P. 426)

### ■ Setting sound dynamic range (DVD video mode)

The difference between the lowest volume and the highest volume can be adjusted.

**STEP 1** Select "Sound Dynamic Range" on the "Setup Menu 2" screen.

**STEP 2** Select "MAX", "STD" or "MIN".

### ■ Entering a language code

If you select "Other" on the "Audio Language" screen, "Subtitle Language" screen or "DVD Language" screen, you can select a language by entering the 4-digit language code (→P. 416) if that language is available.

Input the 4-digit language code and then select "OK".

### ■ When a front passenger selects “Setup Menu”



To cancel the set up operation from the front seat, select “Play”.

### ■ Rear system lock

→P. 322

### ■ Error messages

If “Region code error” is displayed, check the region code printed on the DVD matches the player's region code.

If a different message is displayed: →P. 424

### 3-4. Using the rear seat entertainment system

## Playing a video CD


#### ■ Controller



- 1 Selecting an icon
- 2 Inputting the selected icon
- 3 Rewind
- 4 Selecting a track
- 5 Turning on the control icon screen
- 6 Stop
- 7 Fast forward
- 8 Play/pause
- 9 Volume up/down

#### ■ Control icon screen

Press **OPTION** if no icons are shown while watching a video CD, and the following screen appears.




- 1 Hide the buttons
- 2 Settings screen appears
- 3 Fast forward
- 4 Play/pause
- 5 Stop
- 6 Rewind

If  appears on the screen when you select an icon, the operation relevant to that control is not permitted.

#### ■ Settings screen

Select "Settings" on the control icon screen, and the following screen appears.



- 1 Select menu number
- 2 Return to previous screen
- 3 Change sound-multiplex
- 4 Go to next page
- 5 Return to previous page
- 6 Display the predetermined scene and start playing from there

### Turning on or off the control icons

Press  to turn on the control icons.

Press  once again or select “Hide Buttons” on the control icon screen to turn off the control icon.

### Fast forwarding/rewinding the video CD

Perform either of the following:

- Select  or  on the control icon screen by pressing and holding “ENT”.
- Press and hold  or .

### Slow playback

Perform either of the following:

- Select  and then select . Video is played slowly while you select  by pressing and holding “ENT”.
- Press  and then press and hold . Video is played slowly while  is being pressed.

### Using the video CD menu

Select “Return” on the settings screen.

Refer to the manual that comes with the video CD for specific menu items.

#### Selecting a desired screen

##### ■ Selecting a menu number

**STEP 1** Select "Select Number" on the settings screen.

**STEP 2** Input the desired menu number on the screen and select "OK".

##### ■ Searching manually

Select "Prev. Page" or "Next Page" on the settings screen, or press



until the desired screen appears.

#### Changing the sound-multiplex mode

Select "MAIN/SUB" on the settings screen. The mode cycles through each time "ENT" is pressed.

"Main" → "Sub" → "Main/Sub"



## DVD player and DVD video disc information

#### ■ Error messages

→P. 424

#### ■ DVD video discs

→P. 424

---

#### ■ Symbols shown on DVD video discs

→P. 425

#### ■ Discs that can be used

→P. 426

#### ■ DVD player protection feature

→P. 426

#### ■ If discs are left inside the DVD player or in the ejected position for extended periods

→P. 426

#### ■ Lens cleaners

→P. 426

#### ■ DVD video disc information

→P. 426

#### ■ Sound

→P. 428

#### ■ MP3 and WMA files

→P. 428

#### CAUTION

##### ■ DVD video precaution

→P. 431

#### NOTICE

##### ■ Discs and adapters that cannot be used

→P. 432

##### ■ Player precautions

→P. 433

### 3-4. Using the rear seat entertainment system

## Using the video mode



Press "VIDEO" to select the video mode.

Before switching to the video mode, connect the audio-video equipment to the A/V input adapter.

### Using the adapter

#### ► 5-seat models



Open the cover.

The A/V input adapter is composed of 3 input adapters.

Yellow: Image input adapter

White: Left channel audio input adapter

Red: Right channel audio input adapter

#### ► 4-seat models



Open the cover.

The A/V input adapter is composed of 3 input adapters.

Yellow: Image input adapter


White: Left channel audio input adapter

Red: Right channel audio input adapter

#### Changing the PAL format



Press **DISPLAY**.



If the video does not appear, turn "PAL VIDEO" on.

#### ■ A/V input adapter

The rear seat entertainment system plays videos and sound when audio-video equipment is connected to the A/V input adapter. For details, refer to the manufacturer's instructions.

#### ■ Power outlet

The power outlet is used to connect the audio-video equipment. (→P. 578)

#### NOTICE

##### ■ When the A/V input adapter is not in use

Keep the A/V input adapter cover closed.

Inserting anything other than an appropriate plug may cause electrical failure or a short circuit.

3-4. Using the rear seat entertainment system

# Changing other setting

## Setting the display mode



Pressing **SIZE** changes the display modes sequentially as follows:

Normal→Wide 1→Wide 2



## Adjusting the screen



Press **DISPLAY**.

Select the brightness, contrast, tone or color, and make adjustments.

Press **DISPLAY** or select "OK".

|              | "R"     | "G"      |
|--------------|---------|----------|
| "Color"      | Red     | Green    |
|              | "-"     | "+"      |
| "Tone"       | Lighter | Darker   |
| "Contrast"   | Weaker  | Stronger |
| "Brightness" | Darker  | Brighter |

**Automatic closing of the rear display (4-seat models)**



Press .

If “Auto Close” is on, the display will automatically close when the “ENGINE START STOP” switch is turned OFF.

The display will automatically open when the “ENGINE START STOP” switch is turned to ACCESSORY or IGNITION ON mode.

### 3-5. Using the hands-free system (for cellular phone)


#### Hands-free system (for cellular phone)\* (without navigation system)

The hands-free system is a function that allows you to use your mobile phone without touching it.

This system supports Bluetooth® mobile phones. Bluetooth® is a wireless data system that allows the mobile phone to wirelessly connect to the hands-free system and outgoing/incoming calls.

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".

#### ■ Telephone switch



- 1 Sending/Receiving/  
"Phone" screen display
- 2 End call/Refuse call

#### ■ Microphone



The person you are speaking to can be heard from the driver's side speaker.

To use the hands-free system, you must register a Bluetooth® phone in the system. (→P. 510)


\*: If equipped

Status display

You can check such indicators as signal strength and battery charge on the “Phone” screen.



- 1 Connection status
- 2 Battery charge
- 3 Call area
- 4 Signal strength

| Indicators        | Conditions                                                                                                                                                                                                                                                                    |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Connection status | Blue: Good<br>Yellow: Bad<br><b>PT</b> : Not connected                                                                                                                                                                                                                        |
| Battery charge    | Full   Empty               |
| Call area         | "Rm": Roaming area<br>"Hm": Home area                                                                                                                                                                                                                                         |
| Signal strength   | Excellent   Too bad  |

**■ When using the hands-free system**

- The audio system and voice guidance are muted when making a call.
- If both parties speak at the same time, it may be difficult to hear.
- If the incoming call volume is overly loud, an echo may be heard.
- Try to face the microphone as much as possible when speaking.
- In the following circumstances, it may be difficult to hear the other party:
  - When driving on unpaved roads
  - When driving at high speeds
  - If a window is open
  - If the air-conditioning is blowing directly on the microphone
  - If the air-conditioning is set to high
  - There is an effect from the network of the cellular phone

**■ Conditions under which the system will not operate**

- If using a mobile phone that does not support Bluetooth®
- If the mobile phone is turned off
- If you are outside service range
- If the mobile phone is not connected
- If the mobile phone's battery is low

**■ Bluetooth® antenna**

The antenna is built into the instrument panel. If the mobile phone is behind the seat or in the console box, or touching or covered by metal objects, connection status may deteriorate.

**■ Battery charge/Signal status**

This display may not correspond exactly with the mobile phone itself.

**■ When using Bluetooth® audio and hands-free system at the same time**

The following problems may occur.

- The Bluetooth® connection may be cut.
- Noise may be heard on the Bluetooth® audio playback.

## 3-5. Using the hands-free system (for cellular phone)

### ■ About the phonebook in this system

The following data is stored for every registered phone. When another phone is connecting, you cannot read the registered data.

- Phonebook data
- Voice tag
- All of call history
- Speed dial

When you delete the phone, the above-mentioned data is also deleted.

### ■ When you release your car

Be sure to initialize your data. (→P. 324)

### ■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

### ■ Compatible models

This system supports the following service.

- Bluetooth® Specification:  
Ver. 1.1 or higher (Recommended: Ver. 1.2 or higher)
- Profiles:
  - HFP (Hands Free Profile) Ver. 1.0 or higher (Conformed: Ver. 1.5)
  - OPP (Object Push Profile) Ver. 1.1
  - PBAP (Phone Book Access Profile) Ver. 1.0

If your cellular phone does not support HFP, you cannot enter the Bluetooth® phone, and take OPP or PBAP service individually.

#### ■ Certification

FCC ID: AJDK021  
IC ID: 775E-K021  
MADE IN JAPAN

This device complies with Part 15 of the FCC Rules and RSS-Gen and RSS-210 of IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

#### CAUTION

##### ■ FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Radio Frequency Radiation Exposure.** This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 7.9 in. (20 cm) and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

##### ■ While driving

Do not use the mobile phone or connect the Bluetooth<sup>®</sup> system.

#### NOTICE

##### ■ When leaving the vehicle

Do not leave your mobile phone in the vehicle. The inside of the vehicle may become hot, causing damage to the phone.

### 3-5. Using the hands-free system (for cellular phone)

## Using the Bluetooth<sup>®</sup> phone



- 1 Device name
- 2 Bluetooth<sup>®</sup> connection status
- 3 Character deletion
- 4 Make a call

To display the screen shown above, press “INFO/PHONE”, and touch




on the “Information” screen.

### Registering a Bluetooth® phone

You can register up to 4 phones in the system.

**STEP 1** Display the “Phone” screen. (→P. 509)

**STEP 2**



Touch “Yes”.

**STEP 3**



Input the passcode displayed on the screen into your phone.

For the operation of the phone, see the manual that comes with your cellular phone.

If you want to cancel it, select “Cancel”.

If a completion message is displayed, registration is complete.

If an error message is displayed, follow the guidance on the screen to try again.

## Connecting a Bluetooth® phone

There are two connection methods available-automatic and manual.

### ► Automatic



When you register your phone, auto connection will be activated. Always set it to this mode and leave the Bluetooth® phone on the place where connection can be established.

When the “ENGINE START STOP” switch is turned to ACCESSORY or IGNITION ON mode, the system will search for a nearby cellular phone you have registered. Next, the system automatically connects with the most recent of the phones connected to in the past. Then, the connection result is displayed.

3-5. Using the hands-free system (for cellular phone)

► Manual

When the auto connection has failed or “Handsfree Power” is turned off, you must connect Bluetooth® manually.

**STEP 1** Display the “Phone” screen. (→P. 509)



Touch “Connect Phone”.



Touch “Handsfree Power”, or touch the phone to connect.



The “Connect Bluetooth\*” screen is displayed.

If a completion message is displayed, connection is complete.

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

---

#### ■ Reconnecting to the Bluetooth® phone

If the system cannot connect due to poor signal strength with the “ENGINE START STOP” switch in ACCESSORY or IGNITION ON mode, the system will automatically attempt to reconnect.

If the phone is turned off, the system will not attempt to reconnect. In this case, connection must be made manually, or the phone must be re-selected or re-entered.

#### ■ Connecting the phone while Bluetooth® audio is playing


- Bluetooth® audio will stop temporarily.
- It may take time to be connect.

## Making a call

Once the Bluetooth<sup>®</sup> phone is registered, you can make a call using the following procedure:

### ■ Dialing

**STEP 1** Display the “Phone” screen. (→P. 509)



Input the phone number.

To delete the inputted phone number, touch .

To dial the last inputted phone number, touch “Redial”.

**STEP 3** Touch  or press  on the steering wheel.

### ■ Dialing from the phone book

You can dial a number from the phonebook data imported from your mobile phone. The system has one phonebook for each telephone. Up to 1000 entries may be stored in total for phonebooks. (→P. 530)

**STEP 1** Display the “Phone” screen. (→P. 509)

**STEP 2** Touch “Contacts” on the “Phone” screen.



Choose the desired data to call from the list.

If the phonebook is empty, a message will be displayed.

If you want to transfer new contacts from a cellular phone, touch "Yes".




Choose the number and then touch  or press  on the steering wheel.

### ■ Calling using speed dial

You can make a call using numbers registered from the phone book. (→P. 538)

**STEP 1** Display the "Phone" screen. (→P. 509)

**STEP 2** Touch "Speed Dials" on the "Phone" screen.



Select the desired tab and choose the desired number to make a call.

#### ■ Dialing from history

You can use the call history which has 4 functions below.

“All”: all the numbers below which were memorized

“Missed”: calls which you missed


“Incoming”: calls which you received

“Outgoing”: numbers which you called


You can call using the 5 most recently called numbers shown by “All” while driving.

**STEP 1** Display the “Phone” screen. (→P. 509)

**STEP 2** Touch “Call History” on the “Phone” screen.



Select the desired tab and choose the desired data from the list.



Touch  or press  on the steering wheel.


### ■ Calling using voice recognition

Voice commands can also be used for "Dial by number", "Dial by name", "Redial", "Call back" and "Connect Phone". The procedure below shows "Dial by name". Follow similar procedures for the other four operations.

#### ● Dial by name


You can call by giving a voice tag registered in the phonebook.  
(→P. 544)

#### ► Without paddle shift switches



Pull .

#### ► With paddle shift switches



Press .

**STEP 2** Following the system guidance, wait for the beep, and then say "Dial by name".

**STEP 3** Following the system guidance, wait for the beep, and then say the desired name.

**STEP 4** Following the system guidance, wait for the beep, and then say the desired number.

**STEP 5** Following the system guidance, wait for the beep and then say “Dial” or press  on the steering wheel.

---

#### ■ Call history list

- If you make a call to or receive a call from a number registered in the phone book, the name is displayed in the call history.
- If you make multiple calls to the same number, only the last call made is displayed in the dialled history.
- Calls where the number is unavailable, such as public telephones, are not stored in the call history.

#### ■ When driving

The functions “Dialing”, “Dialing from the phonebook”, and “Dialing from history” (except for call using the 5 most recently called numbers shown by “All” tab) are unavailable.

#### ■ International calls

You may not be able to make international calls, depending on the mobile phone in use.

#### ■ Calling by using the latest call history item

**STEP 1** Press  on the steering wheel to display the “Phone” screen.

**STEP 2** Press  on the steering wheel to display the “Call History” screen.

**STEP 3** Press  on the steering wheel to select the most recent number in the history.

**STEP 4** Touch  or press  on the steering wheel.

#### ■ To cancel voice recognition


- Pull and hold  or press and hold .
- Press  on the steering wheel.
- Touch or say “Cancel”.

### ■ When using voice recognition

- Commands operable by a voice command are marked with . Say the command displayed on the screen.
- Speak clearly when using the voice recognition, otherwise the system may not correctly recognize your voice. Wind or other noises may also cause the system not to recognize your voice.

## Receiving a call

When a call is received, the following screen is displayed together with a sound.



Touch  or press  on the steering wheel.

3

Interior features

### ■ To refuse a call

Touch  or press  on the steering wheel.

### ■ To adjust the ring tone volume

Touch “-” or “+”. You can also adjust the volume using the steering switches.

### ■ International calls

Received international calls may not be displayed correctly, depending on the mobile phone in use.

## Speaking on the phone

The following screen is displayed when speaking on the phone.



### ■ To adjust the receiver volume

Touch “-” or “+”. You can also adjust the volume using the steering switches.


### ■ To prevent the other party from hearing your voice

Touch “Mute”.

### ■ Inputting tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the phone book.

**STEP 1** Touch “0-9”.



Input the number.

If repeated tone symbols\* are stored in the phone book, “Send” and “Exit” are displayed on the right side of the screen.

\*: Repeated tone symbols are symbols or numbers displayed as p or w, that come after the phone number.  
(e.g. 056133w0123p#1\*)

**STEP 3** Confirm the number displayed on the screen, and touch “Send”.  
If you touch “Exit”, this function will end.

### ■ To transfer a call

Touch “Call Transfer”.

### ■ To hang up

Touch  or press  on the steering wheel.

### ■ Call waiting

When a call is interrupted by a third party while talking, the receiving call message will be displayed.

● To talk with the other party: Touch  or press  on the steering wheel.

● To refuse the call: Touch  or press  on the steering wheel.

Every time you touch  or press  on the steering wheel during call waiting, you will be switched to the other party.

If your cellular phone is not compliant with HFP Ver. 1.5, this function cannot be used.

#### ■ Transferring calls

- It is not possible to transfer from hands-free to the mobile phone while driving.
- If you transfer from the mobile phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- Transfer method and operation may vary according to the mobile phone used.
- For operation of the mobile phone in use, see the phone's manual.

#### ■ Call waiting operation

Call waiting operation may differ depending on your phone company and cellular phone.

#### ■ While driving

Key input is unavailable.

### 3-5. Using the hands-free system (for cellular phone)

## Setting the hands-free system

You can set the hands-free system to your desired settings.



- 1** Setting the volume
- 2** Managing the phone
- 3** Phonebook settings
- 4** Bluetooth® settings
- 5** Details settings

To display the screen shown above, press "SETUP", touch "Phone" on the "Setup" screen.

## Setting the volume

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Volume” on the “Phone Settings” screen.

**STEP 3**



Choose the volume setting switch.

“Voice Volume”: changes the  
speaker volume

“Ring Volume”: changes the ring  
volume

**STEP 4**



Touch “-” or “+” to lower or raise  
the volume, and then “OK”.

**STEP 5** When you complete all settings, touch “Save”.

### Adaptive volume control

When traveling at 50 mph (80 km/h) or more, the system automatically raises the volume one level.

If the vehicle speed drops to 43 mph (70 km/h), the volume will return to its original level.

### To return to the default volume settings

Touch “Default”, and then “Yes”.


## Managing the phone

### ■ Registering a Bluetooth® phone

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Manage Phone” on the “Phone Settings” screen.

**STEP 3**



Touch “(add new)” to register your cellular phone to the system.

**STEP 4**



Input the passcode displayed on the screen into your phone.

For the operation of the phone, see the manual that comes with your cellular phone.

If you want to cancel it, select “Cancel”.

If a completion message is displayed, registration is complete.

If an error message is displayed, follow the guidance on the screen to try again.

#### ■ Selecting a Bluetooth® phone

If multiple Bluetooth® phones are registered, follow the procedure below to select the Bluetooth® phone to be used. You may only use one phone at a time.

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Manage Phone” on the “Phone Settings” screen.



Select the phone to be use.

The Bluetooth® mark is displayed when you connect the phone.

If a completion message is displayed, connection is complete.

#### ■ Editing a Bluetooth® phone

You can see the information of the Bluetooth® phone on the system or edit.


**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Manage Phone” on the “Phone Settings” screen.

**STEP 3** Touch “Options” on the “Connect Phone” screen.



Touch “Edit Phones”.

**STEP 5**

Select a phone to edit.

**STEP 6**

Touch "Edit".

**STEP 7**

Input the device name, and touch "OK".

**STEP 8**

Confirm the device name, and touch "OK".


#### ■ Removing a Bluetooth® phone

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Manage Phone” on the “Phone Settings” screen.

**STEP 3** Touch “Options” on the “Connect Phone” screen.

**STEP 4** Touch “Remove Phones” on the “Phones” screen.



Select the desired phone. If you want to remove all phones, touch “Select All”.

**STEP 6** Touch “Delete”. A confirmation message will be displayed. If everything is correct, touch “Yes”.

---

#### ■ Registering a Bluetooth® phone in a different way

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Manage Phone” on the “Phone Settings” screen.

**STEP 3** Touch “Options” on the “Connect Phone” screen.

**STEP 4** Touch “New Phone” on the “Phones” screen.

**STEP 5** Touch “(empty)” on the “Phone Position” screen.

**STEP 6** Follow the steps for “Registering a Bluetooth® phone” from “STEP4”. (→P. 525)

### ■ When another Bluetooth® device is connected during registering or selecting a phone

When another Bluetooth® device is connected, a confirmation message will be displayed. If you want to disconnect it, touch “Yes”.

### ■ When Bluetooth® audio is connected while registering a phone

When you register your phone, Bluetooth® audio will disconnect. It will reconnect automatically when you finish registration. It will not be reconnected depending on the phone you are using.

### ■ Connecting the phone while Bluetooth® audio is playing

Bluetooth® audio will disconnect. It will reconnect automatically when you finish connecting the phone. It will not be reconnected depending on the phone you are using.

### ■ Setting the “Handsfree Power”

The state changes between on and off every time you select “Handsfree Power” on the “Connect Phone” screen. When “Handsfree Power” is on, the Bluetooth® phone is automatically connected when you turn the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode.

### ■ Editing the “Device Name”

If you change a device name, the name registered in your cellular phone is not changed.

### ■ About “Device Address”


The address peculiar to the system. You cannot be changed. If you have registered two Bluetooth® phones with the same device name and you cannot distinguish one from the other, refer to this address.

### ■ When you delete a Bluetooth® phone

The phonebook data will be deleted at the same time.

#### Phonebook settings

The phonebook manages a maximum of 4 phonebooks in total. Up to 1000 person's data (up to 3 numbers a person) can be registered in total for phonebooks.



- 1 Setting the phonebook
- 2 Speed dials setting
- 3 Deleting the call history
- 4 Setting the voice tag

To display the screen above, follow the steps below.

**STEP 1** Display the "Phone Settings" screen. (→P. 523)

**STEP 2** Touch "Phonebook" on the "Phone Settings" screen.

## ■ Setting the phonebook


### ● Transferring a phone number

You can transfer the phone numbers in your Bluetooth® phone to the system.

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Contacts” on the “Phonebook Settings” screen.


**STEP 3** Touch “Transfer Contacts”.



Select “Replace Contacts” or “Add Contacts”.

In the case that the phonebook contains phonebook data, this screen is displayed.

### 3-5. Using the hands-free system (for cellular phone)



Transfer the phonebook data to the system using the Bluetooth<sup>®</sup> phone.

If you wish to cancel the transfer before it finishes, touch "Cancel".

If the transferring is interrupted midway through the process, the phonebook data transferred until then can be memorized in the system.

**STEP 6** In the case that you have selected "Add Contacts", a message is displayed.

If you want to transfer another phonebook, touch "Yes".


#### ● Registering the phonebook data

You can register the phonebook data. Up to 3 numbers per person can be registered.


**STEP 1** Display the "Phonebook Settings" screen. (→P. 530)

**STEP 2** Touch "Manage Contacts" on the "Phonebook Settings" screen.

**STEP 3** Touch "New Contact" on the "Contacts" screen.



Input the name, and touch "OK".



Input the phone number, and touch "OK".

If you want to use the tone signal after the phone number, input the tone signal too.



Touch the desired phone type.

**STEP 7** When two or less numbers in total are registered to this contact, a message is displayed. When you want to add a number to this contact, touch "Yes".

3-5. Using the hands-free system (for cellular phone)

● Editing the phonebook data

You can register the phone number separately.

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)


**STEP 2** Touch “Manage Contacts” on the “Phonebook Settings” screen.

**STEP 3** Touch “Edit Contacts” on the “Contacts” screen.

**STEP 4** Choose the data to edit.



**STEP 5** Choose “Edit” for the desired name or number.



**STEP 6** Edit the name or number. After editing, touch “Save”.

### ● Deleting the phonebook data

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Contacts” on the “Phonebook Settings” screen.

**STEP 3** Touch “Delete Contacts” on the “Contacts” screen.



Choose the data to delete.

You can select multiple data and delete them at the same time.

To delete all data, touch “Select All”.

**STEP 5** Touch “Delete”. A confirmation message will be displayed. If everything is correct, touch “Yes”.

### ■ Phonebook data

Phonebook data is managed for every registered phone. When another phone is connecting, you cannot read the registered data.

### ■ Setting the phonebook in a different way (To display the “Contacts” screen)

**STEP 1** Display the “Phone” screen. (→P. 509)

**STEP 2** Touch “Contacts” on the “Phone” screen.

**STEP 3** Touch “Options” on the “Contacts” screen.

**STEP 4** Touch “Manage Contacts” on the “Contacts” screen.

#### ■ When transferring a phone number

Transfer the phone number while engine is running.

#### ■ When you have selected “Replace Contacts” to transfer the phone number

- If your cellular phone does not support PBAP or OPP service, you cannot use this function.
- If your phone supports PBAP service, you can transfer the phonebook data without operating your phone.
- If your phone does not support PBAP service, you must transfer the phonebook data by operating your phone.

#### ■ When you have selected “Add Contacts” to transfer the phone number

If your cellular phone does not support OPP service, you cannot use this function. You can transfer the phonebook data only by operating your phone.

#### ■ When another Bluetooth® device is connected during transferring a phonebook

When another Bluetooth® device is connected, a confirmation message will be displayed. If you want to disconnect it, touch “Yes”.

#### ■ Transferring the phone number while Bluetooth® audio is playing

Bluetooth® audio will disconnect. It will reconnect automatically when data transfer finishes. It will not be reconnected depending on the phone you are using.

#### ■ Editing the phonebook data in a different way (From “Contact Data” screen)

**STEP 1** Display the “Phone” screen. (→P. 509)

**STEP 2** Touch “Contacts” on the “Phone” screen.

**STEP 3** Choose the desired data from the list.

**STEP 4** Touch “Options” on the “Contact Data” screen.

**STEP 5** Touch “Edit Contact” on the “Contact Data” screen.

**STEP 6** Follow the steps “Editing the phonebook data” from “STEP5”. (→P. 534)

**■ Editing the phonebook data in a different way (From “Call History” screen)**

- STEP 1** Display the “Phone” screen. (→P. 509)
- STEP 2** Touch “Call History” on the “Phone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Add Contact” or “Update Contact”.
- STEP 5** If you touch “Add Contact”, follow the steps “Editing the phonebook data” from “STEP5”. (→P. 534)  
If you touch “Update Contact”, follow the steps “Editing the phonebook data” from “STEP4”. (→P. 534)

**■ Deleting the phonebook data in a different way**

- STEP 1** Display the “Phone” screen. (→P. 509)
- STEP 2** Touch “Contacts” on the “Phone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Options” on the “Contact Data” screen.
- STEP 5** Touch “Delete Contact” on the “Contact Data” screen.
- STEP 6** A confirmation message will be displayed. If everything is correct, touch “Yes”.

#### ■ Speed dials setting

##### ● Registering the speed dial

You can register the desired phone number from phonebook. Up to 18 numbers per phone can be registered.

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Speed Dials” on the “Phonebook Settings” screen.




Touch “New Speed Dial”.




Choose the data to register.

**STEP 5**



Touch the desired phone number.

**STEP 6**



Touch the switch you want to register the number in.

**STEP 7**

If you select a switch you registered before, a confirmation message will be displayed. If you want to replace it, touch "Yes".

### 3-5. Using the hands-free system (for cellular phone)

#### ● Editing the speed dial


**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Speed Dials” on the “Phonebook Settings” screen.

**STEP 3** Touch “Edit Speed Dials” on the “Speed Dials” screen.



Choose the data to edit.



Touch “Edit”.

**STEP 6** Edit the name. After editing, touch “OK” and then “Save”.

### ● Deleting the speed dial

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Speed Dials” on the “Phonebook Settings” screen.

**STEP 3** Touch “Delete Speed Dials” on the “Speed Dials” screen.



Choose the data to delete.

You can select multiple data and delete them at the same time.

To delete all data, touch “Select All”.

**STEP 5** Touch “Delete”. A confirmation message will be displayed. If everything is correct, touch “Yes”.

#### ■ Setting the speed dials in a different way (To display the “Speed Dial” screen)

- STEP 1** Display the “Phone” screen. (→P. 509)
- STEP 2** Touch “Speed Dials” on the “Phone” screen.
- STEP 3** Touch “Options” on the “Speed Dial” screen.

#### ■ Registering the speed dial in a different way (From “Speed Dial” screen)

- STEP 1** Display the “Phone” screen. (→P. 509)
- STEP 2** Touch “Speed Dials” on the “Phone” screen.
- STEP 3** Touch “(add new)” on the “Speed Dial” screen.
- STEP 4** Touch “Yes” to set new speed dial.
- STEP 5** Choose the desired data from the list.
- STEP 6** Touch the desired phone number.
- STEP 7** Follow the steps “Registering the speed dial” from “STEP6”. (→P. 538)


#### ■ Registering the speed dial in a different way (From “Contact Data” screen)

- STEP 1** Display the “Phone” screen. (→P. 509)
- STEP 2** Touch “Contacts” on the “Phone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Options” on the “Contact Data” screen.
- STEP 5** Touch “Set Speed Dial” on the “Contact Data” screen.
- STEP 6** Touch the desired phone number.
- STEP 7** Follow the steps “Registering the speed dial” from “STEP6”. (→P. 538)

## ■ Deleting call history

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Delete Call History” on the “Phonebook Settings” screen.



Choose the desired history to delete.



Choose the data to delete.

You can select multiple data and delete them at the same time.

To delete all data, touch “Select All”.

**STEP 5** Touch “Delete”. A confirmation message will be displayed. If everything is correct, touch “Yes”.

■ Deleting call history in a different way

- STEP 1 Display the "Phone" screen. (→P. 509)
- STEP 2 Touch "Call History" on the "Phone" screen.
- STEP 3 Touch "Delete" on the "Call History" screen.
- STEP 4 Follow the steps "Deleting call history" from "STEP4". (→P. 543)

■ Setting the voice tag

- Registering the voice tag  
You can register a voice tag. Up to 20 numbers can be registered.

- STEP 1 Display the "Phonebook Settings" screen. (→P. 530)
- STEP 2 Touch "Manage Voice Tags" on the "Phonebook Settings" screen.
- STEP 3 Touch "New Voice Tag".





Touch “● REC”, and record a voice tag.

To play the voice tag, touch “▶ Play”.

**STEP 6** When you complete the voice tag registration, touch “OK”.

### ● Editing the voice tag

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Voice Tags” on the “Phonebook Settings” screen.

**STEP 3** Touch “Edit Voice Tags” on the “Voice Tags” screen.



Choose the data to edit.

**STEP 5** Edit the voice tag. After editing, touch “OK”.

### ● Deleting the voice tag

**STEP 1** Display the “Phonebook Settings” screen. (→P. 530)

**STEP 2** Touch “Manage Voice Tags” on the “Phonebook Settings” screen.

**STEP 3** Touch “Delete Voice Tags” on the “Voice Tags” screen.



Choose the data to delete.

You can select multiple data and delete them at the same time.

To delete all data, touch "Select All".

**STEP 5** Touch "Delete". A confirmation message will be displayed. If everything is correct, touch "Yes".

---

#### ■ Setting the voice tag in a different way (To display the "Voice Tags" screen)

**STEP 1** Display the "Phone" screen. (→P. 509)

**STEP 2** Touch "Contacts" on the "Phone" screen.

**STEP 3** Touch "Options" on the "Contacts" screen.

**STEP 4** Touch "Manage Voice Tags" on the "Contacts" screen.

#### ■ When using the voice tag

Do not change the language setting from the language setting used when registering. If they are different, the voice recognition cannot recognize the voice tag that you have registered.

#### ■ When recording a voice tag

Do so in a quiet environment.

#### ■ Registering the voice tag in a different way

**STEP 1** Display the "Phone" screen. (→P. 509)

**STEP 2** Touch "Contacts" on the "Phone" screen.

**STEP 3** Choose the desired data from the list.

**STEP 4** Touch "Options" on the "Contact Data" screen.

**STEP 5** Touch "Set Voice Tag" on the "Contact Data" screen.

**STEP 6** Follow the steps "Registering the voice tag" from "STEP5". (→P. 544)

## Bluetooth® settings

You can confirm and change the Bluetooth® settings.



- 1 Changing the handsfree connection status
- 2 Changing the name in the Bluetooth® network
- 3 Changing the passcode that you register your cellular phone in the system
- 4 The address peculiar to the system

You cannot change this address. If the same device name is displayed on the screen of your phone, refer to it.

To display the screen above, follow the steps below.

**STEP 1** Display the “Phone Settings” screen. (→P. 523)

**STEP 2** Touch “Bluetooth\*” on the “Phone Settings” screen.


\*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

#### ■ Changing the handsfree power

The Bluetooth<sup>®</sup> phone is automatically connected when you turn the “ENGINE START STOP” switch to ACCESSORY or IGNITION ON mode. You can change this state to “On” or “Off”.

**STEP 1** Display the “Bluetooth\* Information” screen. (→P. 547)

**STEP 2** Touch “Handsfree Power” on the “Bluetooth\* Information” screen.



Touch “On” or “Off”, and then “Save”.

\*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

#### ■ Editing the device name

**STEP 1** Display the “Bluetooth\* Information” screen. (→P. 547)

**STEP 2** Touch “Edit” of “Device Name” on the “Bluetooth\* Information” screen.

**STEP 3** Input the device name, and touch “OK”.


**STEP 4** Touch “Save” on the “Bluetooth\* Information” screen.

\*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

### ■ Editing the passcode

**STEP 1** Display the “Bluetooth\* Information” screen. (→P. 547)

**STEP 2** Touch “Edit” of “Passcode” on the “Bluetooth\* Information” screen.



Input a passcode, and touch “OK”.

**STEP 4** Touch “Save” on the “Bluetooth\* Information” screen.

\*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

### ■ While driving

You cannot change the state of “Handsfree Power” from “On” to “Off” while driving.

### ■ About “Device Name”

The device names are common Bluetooth® audio and Bluetooth® phone.

If you change the device name of the phone, the device name of the audio will change at same time. However, passcodes can be set separately.

### ■ To return to the default Bluetooth® settings

Touch “Default”, and then “Yes”.

If the state of “Handsfree Power” is changed from “Off” to “On”, Bluetooth® connection will begin.

## Details settings



**1** Changing the incoming call display mode

**2** Changing the display phone status

To display the screen above, follow the steps below.

**STEP 1** Display the "Phone Settings" screen. (→P. 523)


**STEP 2** Touch "Details" on the "Phone Settings" screen.

### ■ Changing the incoming call display mode

You can select the method of the incoming call display.

**STEP 1** Display the “Detailed Phone Settings” screen. (→P. 550)

**STEP 2** Touch “Incoming Call Display Mode” on the “Detailed Phone Settings” screen.



Touch “Full Screen” or “Drop Down”, and touch “Save”.

“Full Screen”:

The hands-free screen is displayed when a call is received, and you can operate the system from that screen.

“Drop Down”:

A message is displayed at the top of the screen, and you can only operate the system with the steering switches.

### ■ Changing the display Phone status

You can set the system to show the status confirmation display when connecting.

**STEP 1** Display the “Detailed Phone Settings” screen. (→P. 550)

**STEP 2** Touch “Display Phone Status” on the “Detailed Phone Settings” screen.

**STEP 3** Touch “On” or “Off”, and then “Save”.


### ■ To return to the default detailed Phone settings

Touch “Default”, and then “Yes”.

### 3-6. Using the interior lights

## Interior lights list

Your Lexus is equipped with the illuminated entry system to assist in entering the vehicle. Owing to the function of the system, the lights shown in the following illustration automatically turn on/off according to the presence of the electronic key, whether the doors are locked/unlocked, whether the doors are opened/closed, and the “ENGINE START STOP” switch mode.



- 1 Front personal lights (→P. 554)
- 2 Front interior lights (→P. 553)
- 3 Inside door handle lighting
- 4 Rear personal lights (→ P. 554)
- 5 Rear interior light (→ P. 553)
- 6 Door courtesy lighting
- 7 Shift lever lighting (when the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode)

- 8 Seat belt buckle lighting
- 9 "ENGINE START STOP" switch lighting
- 10 Footwell lighting
- 11 Outer foot lights

## Interior lights

### ► Front



- 1 "OFF"
- 2 Door position on/off
- 3 "ON"

### ► Rear



### On/off

If door position on is selected for the front interior light, the rear interior light is also turned on/off by the opening and closing of a door.

Personal lights

► Front




On/off

► Rear (without rear seat entertainment system)



On/off

► Rear (with rear seat entertainment system)



- 1 On/off
- 2 Press the knob to release it, and turn the knob to the desired brightness.
- 3 Darker
- 4 Brighter

---

**■ To prevent the battery from being discharged**

If the interior lights remain on when the door is not fully closed and the front interior light switch (door position on/ off) is on, the lights will go off automatically after 20 minutes.


**■ Customization**

Settings (e.g. The time elapsed before lights turn off) can be changed.  
(Customizable features →P. 766)

### 3-7. Using the storage features


## List of storage features

#### ► 5-seat models




- 1 Glove box
- 2 Auxiliary boxes (if equipped)
- 3 Non smokers boxes (if equipped)
- 4 Door pockets
- 5 Cool box/auxiliary box (if equipped)
- 6 Cup holders
- 7 Console box
- 8 Coin holder

## ► 4-seat models



- 1 Glove box
- 2 Auxiliary boxes
- 3 Non smokers boxes (if equipped)
- 4 Door pockets
- 5 Cool box/auxiliary box
- 6 Cup holders
- 7 Console box
- 8 Coin holder

**Glove box**

- 1** Open (push button)
- 2** Lock with the mechanical key
- 3** Unlock with the mechanical key

**Trunk opener main switch**

The trunk opener main switch is located in the glove box. (→ P. 58)

**! CAUTION****■ Caution while driving**

Keep the glove box closed.

Injuries may result in the event of an accident or sudden braking.

## Coin holder



Press in the button.

### CAUTION

#### Caution while driving

Keep the coin holder closed.  
Injuries may result in the event of an accident or sudden braking.

## Door pockets (front)



The front door pockets can be opened and closed.

### CAUTION

#### Caution while driving

Keep the door pockets closed.  
Injuries may result in the event of an accident or sudden braking.

## Cup holders

### ► Front




Press down and release the right side of the cup holder lid.

### ► Rear (5-seat models without auxiliary box)



Pull up the cup holder lid.

### ► Rear (5-seat models with auxiliary box)



Press in and release the cup holder.

## ► Rear (4-seat models)



Press in and release the button.

**⚠ CAUTION****■ Items unsuitable for the cup holder**

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

**■ When not in use**

Keep the cup holders closed.  
Injuries may result in the event of an accident or sudden braking.

Console box

► Without rear console display



- 1 Slide the armrest while pressing the button.
- 2 Lift the armrest.

► With rear console display



- 1 Press the button.
- 2 Lift the armrest.

■ Tray in the console box (without rear console display)



The tray can be raised backward.

■ Opening and closing assist function (without rear console display)

When the console box is opened or closed partway, this function will apply force in the appropriate direction, helping open or close the console box.

## ⚠ CAUTION

### ■ Caution while driving

Keep the console box closed.  
Injuries may result in the event of an accident or sudden braking.

## ⚠ NOTICE

### ■ Tray

Do not insert items exceeding the height of the tray. Doing so may prevent opening and closing of the lid.

## Non smokers boxes (if equipped)

### ► Front



Press in the lid.

### ► Rear



Open the lid.

**■ Removing the non smokers box (front)**

Holding the left edge of the non smokers box, pull upward.

**! CAUTION****■ Using the non smokers box**

Do not use the non smokers boxes as an ashtray.

**■ Caution while driving**


Keep the non smokers boxes closed.

Injuries may result in the event of an accident or sudden braking.


**Cool box/auxiliary box (if equipped)****► 5-seat models**

**STEP 1** Pull down the armrest. (→P. 587)

**STEP 2**




Pull the lever.




Open the cool air intake lid.

► 4-seat models



Pull up the lever to release the lock and lift the lid.



Open the cool air intake lid.

### ■ Cool box operating conditions

#### ► 5-seat models



- The rear air conditioning system is on.
-  is displayed on the rear control panel.

#### ► 4-seat models



- The rear air conditioning system is on.
-  is displayed on the rear control panel.

### ■ Items unsuitable for the cool box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor

### ■ Using a cool box as an auxiliary box

#### ► 5-seat models



Close the cool air intake lid to turn off the cool box system.

#### ► 4-seat models



Close the cool air intake lid to turn off the cool box system.

### ⚠ CAUTION

#### ■ Caution while driving

Always keep the cool box/auxiliary box closed to reduce the chance of injury in case of an accident or sudden stop.

## Auxiliary boxes

### ► Overhead



Press in the button.

This box is useful for temporarily storing sunglasses and similar small items.

### ► Rear console (with rear console display)



Press in the lid.

### ► Rear seat (if equipped on 5-seat models)

**STEP 1** Pull down the armrest. (→P. 587)



**1** Press the button.

**2** Lift the lid.

The lid cannot be lifted while it is slid back. (→P. 587)

► Rear seat (4-seat models)



Press in the lid.

This box is useful for storing DVD discs and headphones.

■ Tray in the rear console



The tray can be removed.

**! CAUTION**

■ **Items that should not be left in the auxiliary box (overhead type)**

Do not leave glasses or lighters in the box.


If the interior of the vehicle becomes hot, lighters may explode and glasses may warp or crack.

■ **Caution while driving**

Do not leave the auxiliary box open while driving.

Items may fall out and cause death or serious injury in case of an accident or sudden stop.

## Sun visors



- 1** Forward position:  
Flip down.
- 2** Side position:  
Flip down, unhook, and swing to the side.
- 3** Side extender:  
Place in side position, then slide backward.

# Vanity mirrors

► Front



Slide the cover to open.

The light turns on when the cover is opened.

► Rear



Press the button to open.

The vanity light turns on.

 NOTICE

■ **When not in use**

Keep the rear vanity mirror closed.

■ **To prevent the battery from being discharged**

Do not leave the vanity lights on for extended periods while the engine is stopped.

## 3-8. Other interior features

### Clock

The clock is displayed when the “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode. Perform the following steps to adjust the clock.

Owners of models equipped with a navigation system should refer to the “Navigation System Owner’s Manual”.

#### ► Without touch screen





- 1 Adjusts the hour
- 2 Adjusts the minutes
- 3 Rounds to the nearest hour\*

\*: e.g. 1:00 to 1:29 → 1:00

1:30 to 1:59 → 2:00


#### ► With touch screen





Press "SETUP".

**STEP 2** Touch "Clock" on the "Setup" screen.



- 1** Turns daylight saving time on/off
  - 2** Adjusts the hour
  - 3** Adjusts the minutes
  - 4** Rounds to the nearest hour\*
- After setting, touch "SAVE".

\*: e.g. 1:00 to 1:29 → 1:00  
1:30 to 1:59 → 2:00

#### ■ When the battery is disconnected

The time display will automatically be set to 1:00.

### 3-8. Other interior features

## Outside temperature display

The displayed temperature ranges from -40°F (-40°C) up to 122°F (50°C) when the “ENGINE START STOP” switch is in IGNITION ON mode.

#### ► Without touch screen



#### ► With touch screen



#### ■ When “—” or “E” is displayed

The system may be malfunctioning. Take your vehicle to your Lexus dealer.

#### ■ Display


In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

### 3-8. Other interior features

## Ashtrays\*

#### ► Front



Push the front part of the lid to open. Push the lid again to close.

To remove, pull the ashtray upwards.

#### ► Rear



Open the ashtray lid.

To remove, pull the ashtray upwards.

### ⚠ CAUTION

#### ■ When not in use

Keep the ashtray closed.

Injuries may result in the event of sudden braking, sudden swerving or an accident.

#### ■ To prevent fire

- Fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.

\*: If equipped

### 3-8. Other interior features

## Cigarette lighters\*

#### ► Front



Push the front part of the lid to open, and push the cigarette lighter down.

The cigarette lighter will pop up when it is ready for use.


#### ► Rear (5-seat models without rear console display)



Push the cigarette lighter.

The cigarette lighter will pop out when it is ready for use.

#### ► Rear (4-seat models)



Open the auxiliary box and push the cigarette lighter.

The cigarette lighter will pop out when it is ready for use.

\*: If equipped

---

■ **The cigarette lighter can be used when**

The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.

 **CAUTION**

■ **To avoid burns or fires**

- Do not touch the metal parts of the cigarette lighter.
- Do not hold the cigarette lighter down. It could overheat and cause a fire.
- Do not insert anything other than the cigarette lighter into the outlet.

■ **When not in use**

Keep the ashtray closed.

Injuries may result in the event of an accident or sudden braking.

3-8. Other interior features

Power outlets

The power outlet can be used for a following component.

12 V: Accessories that run on less than 10 A.

115 VAC: Accessories that use less than 100 W.

■ 12 V

► Front



► Rear (5-seat models without rear console display)\*



► Rear (5-seat models with rear console display)\*



► Rear (4-seat models)\*



■ 115 VAC

► Without rear console display\*



► With rear console display\*



\*: If equipped

### ■ The power outlet can be used when

#### ▶ 12 V

The “ENGINE START STOP” switch is in ACCESSORY or IGNITION ON mode.

#### ▶ 115 VAC

The “ENGINE START STOP” switch is in IGNITION ON mode.

### NOTICE

#### ■ To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may cause a short circuit.

#### ■ To prevent the fuse from being blown

#### ▶ 12 V

Do not use an accessory that uses more than 12 V 10 A.

#### ▶ 115 VAC

Do not use a 115 VAC appliance that requires more than 100 W.

If a 115 VAC appliance that consumes more than 100 W is used, the protection circuit will cut the power supply.

#### ■ To prevent the battery from being discharged

Do not use the power outlet longer than necessary when the engine is not running.

#### ■ Appliances that may not operate properly (115 VAC)

The following 115 VAC appliances may not operate properly even if their power consumption is under 100 W.

- Appliances with high initial peak wattage
- Measuring devices that process precise data
- Other appliances that require an extremely stable power supply

## Heated steering wheel\*

The heated steering wheel can be used to heat the leather portion of the steering wheel.



### On/off

The indicator light comes on when the heater is operating.

#### ■ Operating condition

The "ENGINE START STOP" switch is in IGNITION ON mode.

#### ■ Timer

The heated steering wheel will automatically turn off after about 30 minutes.

#### ■ If the indicator light flashes

Press the button to turn the heated steering wheel off and then press the button again. If the indicator light still flashes, a malfunction may be occurring. Turn the heated steering wheel off and have the vehicle inspected by your Lexus dealer.

### CAUTION

#### ■ Burns

Only appropriately qualified and capable non-impaired persons should operate the vehicle. However, care should be taken to prevent injury if anyone in the following categories comes into contact with the steering wheel when the heated steering wheel is on:

- Babies, small children, the elderly, the sick and the disabled
- Persons with sensitive skin
- Persons who are fatigued
- Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)

### NOTICE


#### ■ To prevent the battery from being discharged

Turn the switch off when the engine is not running.

## Climate control seats/seat heaters\*

The temperature of the seats can be adjusted individually.

### ■ Front climate control seats



**1** Press the knob to release it, and turn the knob to the desired temperature setting.

**2** Off

Press the knob to lock it when not in use.

**3** Ventilation

**4** Cool air

**5** Warm air


\*: If equipped

#### ■ Rear climate control seats

##### ► 5-seat models

**STEP 1** Slide the armrest lid. (→P. 587)

**STEP 2**



**1** Press the knob to turn the system on, and turn the knob to the desired temperature setting.


Press the knob again to turn the system off.

**2** Ventilation

**3** Cool air

**4** Warm air

##### ► 4-seat models



**1** Press the knob to turn the system on, and turn the knob to the desired temperature setting.

Press the knob again to turn the system off.

**2** Ventilation

**3** Cool air

**4** Warm air



The rear climate control seats can also be turned on and off from the front seats.

### ■ Rear seat heaters

**STEP 1** Slide the armrest lid. (→P. 587)



Press the knob to turn the system on, and turn the knob to the desired temperature setting.

The further you turn the knob clockwise, the warmer the seat temperature becomes. Press the knob again to turn the system off.



The rear seat heaters can also be turned on and off from the front seats.

### ■ Operating condition

The "ENGINE START STOP" switch is in IGNITION ON mode.

### ■ Replacing the air filters

Filters are installed in the climate control seats. For replacement of the filters, contact your Lexus dealer.

### CAUTION

#### ■ Burns/excessive cooling

- Use caution when seating the following persons in a seat to avoid the possibility of burns or excessive cooling:
  - Babies, small children, elderly persons, sick persons and persons with a physical disability
  - Persons who have sensitive skin
  - Persons who are fatigued
  - Persons who have taken alcohol or drugs which induce sleep, such as sleeping drugs and cold remedies
- Do not cover the seat with anything when using the climate control seat or seat heater. Using the climate control seat or seat heater with a blanket or cushion may increase or decrease the temperature of the seat, resulting in overheating or overcooling.
- Do not use the climate control seat or seat heater more than necessary. Doing so may cool the occupants excessively or may cause minor burns or overheating.

### NOTICE

#### ■ To prevent damage to the climate control seat and seat heater

Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects, such as needles and nails, into the seat.

#### ■ To prevent the battery from being discharged

Do not leave the system on longer than necessary when the engine is off.

## Armrest (5-seat models)



Pull the armrest down for use.

### ■ When operating the switches in the armrest (with auxiliary box)



Press the button to release the lock, and slide the lid back.

Press the button again for returning the lid.


### NOTICE

#### ■ To prevent damage to the armrest

Do not place too much strain on the armrest.

### 3-8. Other interior features

## Retractable table (4-seat models)



Slide the lever to raise the table.



Pull the table up and pull down the table.



The position of the table can be changed. Before using the table, make sure that the table is securely locked.

When the table is in use, the front seats will stop if they are going to contact the table.  
(→P. 68, 86)



When returning the table, pull it up while pulling the lock release lever.

 **CAUTION****■ When not in use**

To avoid injury, return the table.

**■ Caution while driving**

Keep the table stowed properly in its place. In the event of an accident, contact with the table may result in death or serious injury.

**■ When using the table**

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the table is securely locked.
- Do not lean on the table.
- Do not put anything heavier than 22 lb. (10 kg) on the table.

 **NOTICE****■ To prevent damage to the table**

Do not place too much strain on the table.

### 3-8. Other interior features

## Rear sunshade\*

The rear sunshade can be raised and lowered by operating any of the buttons shown below.

- From front seat (without rear console display)



Extend/retract


- From front seat (with rear console display)



Extend/retract

- From rear seat (5-seat models)


**STEP 1** Slide the armrest lid. (→P. 587)



Extend/retract

\*: If equipped

## ► From rear seat (4-seat models)



Extend/retract

3

Interior features

## ■ The rear sunshade can be used when

The “ENGINE START STOP” switch is in IGNITION ON mode.

## ■ Operating the rear sunshade after turning the “ENGINE START STOP” switch OFF

The rear sunshade can be operated for approximately 60 seconds even after the “ENGINE START STOP” switch is switched to ACCESSORY mode or turned OFF.

## ■ Reverse operation feature

To ensure adequate rear visibility, the rear sunshade automatically lowers when the shift lever is shifted to “R”.

However, the rear sunshade is raised again if any of the following occurs:

- The button is pressed again.
- The shift lever is shifted to “P”.
- The shift lever is shifted out of “P” and “R”, and the vehicle reaches a speed of 9 mph (15 km/h).

If the engine is turned off when the rear sunshade has been lowered due to the reverse operation feature, it will not be raised even when the engine is turned on again and the vehicle reaches a speed of 9 mph (15 km/h). To raise the sunshade again, press the button.

### ■ Button lock function

To prevent inadvertent operation, some buttons on the rear armrest can be locked.  
(→P. 357)

### CAUTION

#### ■ When the rear sunshade is being raised or lowered

Do not place fingers or other objects in the shade mechanism or in the opening as injury may result.

### NOTICE

#### ■ To prevent the battery from being discharged

Do not operate the rear sunshade when the engine is not running.

#### ■ To ensure normal operation of the sunshade

Observe the following precautions:

- Do not place excessive load on the motor or other components.
- Do not place objects where they may hinder opening and closing operations.
- Do not attach items to the rear sunshade.
- Keep the opening clean and clear of obstructions.
- Do not operate the rear sunshade continuously for long periods of time.

### 3-8. Other interior features

## Rear door sunshades\*

The rear door sunshades can be extended and retracted by operating any of the buttons shown below.

- From front seat (without rear console display)



Extend/retract

The rear door sunshades can be extended only when both of left and right rear door sunshades are retracted. Pressing the button with either side retracted will cause both sides to be retracted.

- From front seat (with rear console display)




Extend/retract

The rear door sunshades can be extended only when both of left and right rear door sunshades are retracted. Pressing the button with either side retracted will cause both sides to be retracted.

- From rear seat (5-seat models)

**STEP 1** Slide the armrest lid. (→P. 587)



Extend/retract

\*: If equipped

### ► From rear seat (4-seat models)



Extend/retract

#### ■ Operating conditions

- The “ENGINE START STOP” switch is in IGNITION ON mode.
- The rear windows are fully closed.  
The rear door sunshades automatically retract when the rear windows are opened.

#### ■ Operating the rear door sunshades after turning the “ENGINE START STOP” switch OFF

The rear door sunshades can be operated for approximately 60 seconds even after the “ENGINE START STOP” switch is switched to ACCESSORY mode or turned OFF.

#### ■ Jam protection function

If an object becomes caught between a rear door sunshade and the window frame, the jam protection function will cause the sunshade to detach from its drive mechanism and retract.

#### ► If the jam protection function operates when extending the rear door sunshades

Pressing the button will reconnect the sunshade.

Pressing the button again will allow the sunshades to be operated.

If the sunshade does not operate after the button is pressed, press the button again.

#### ► If the jam protection function operates when retracting the rear door sunshades

Press and hold the button to re-extend the rear door sunshades, and continue pressing for more than 5 seconds after the sunshades have fully extended and stopped.

### ■ Button lock function

To prevent inadvertent operation, some buttons on the rear armrest can be locked.  
(→P. 357)

### ■ When reconnecting the battery

The rear door sunshades will always be retracted the first time the button is pressed.

## CAUTION

### ■ When the rear door sunshades are being extended or retracted

Do not place fingers or other objects in the shade mechanism or in the opening as injury may result.

### ■ Jam protection function

Never use any part of your body to intentionally activate the jam protection function.

## NOTICE

### ■ To prevent the battery from being discharged

Do not operate the rear door sunshades when the engine is not running.

### ■ To ensure normal operation of the sunshades

Observe the following precautions:

- Do not place excessive load on the motor or other components.
- Do not place objects where they may hinder opening and closing operations.
- Do not attach items to the rear door sunshades.
- Keep the opening clean and clear of obstructions.
- Do not operate the rear door sunshades continuously for long periods of time.


### 3-8. Other interior features

## Trunk storage extension\*

Long objects can be loaded in the vehicle by utilizing the trunk space and rear seat area.

**STEP 1** Pull down the armrest. (→P. 587)

**STEP 2**



Open the armrest door.

The armrest door can be locked and unlocked using the mechanical key.

**1** Lock

**2** Unlock

► Opening from the cabin


**STEP 3**



Open the inside trunk door from the cabin, and load baggage or other items.

► Opening from the trunk

**STEP 3**



Open the inside trunk door from the trunk, and load baggage or other items.

\*: If equipped

 **CAUTION****■ When not in use**


Ensure that the inside trunk door is closed.

In the event of sudden braking, items stored in the trunk may be thrown forward into the cabin, resulting in injury.

### 3-8. Other interior features


## Coat hooks

#### ► Without rear air conditioning system



To use the coat hook, push it on.

#### ► With rear air conditioning system



To use the coat hook, push it on.

### ⚠ CAUTION

#### ■ Items that must not be hung on the hook

Do not hang a coat hanger or other hard or sharp object on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles that cause death or serious injury.

## Floor mat

Securely place a mat that matches the size of the space on the carpet.



Secure the floor mat using the hooks provided.

### ⚠ CAUTION

#### ■ When inserting the floor mat

Observe the following precautions.

Failure to do so may result in the floor mat slipping and interfering with the movement of the pedals during driving, resulting in an accident.

- Make sure the floor mat is properly placed on the vehicle carpet and the correct side faces upward.
- Do not place floor mats on top of existing mats.

### 3-8. Other interior features

## Trunk features

#### ■ Cargo net




The cargo net is provided for securing loose items on the floor or items inside the trunk.


Raise the cargo hooks on the floor. Hook the net on the cargo hooks.



#### ■ Shopping bag hooks



### ■ First-aid kit storage belt



1 Loosen

2 Tighten

### ⚠ CAUTION

#### ■ When the cargo net is not in use

To avoid injury, always return the cargo hooks on the floor to their stowed positions.

### 3-8. Other interior features

## Garage door opener

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

The garage door opener (HomeLink<sup>®</sup> Universal Transceiver) is manufactured under license from HomeLink<sup>®</sup>.

### Programming the HomeLink<sup>®</sup>

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.



1 Indicator

2 Buttons

### ■ Programming the HomeLink<sup>®</sup> (for U.S.A. owners)



Point the remote control transmitter for the device 1 to 3 in. (25 to 75 mm) from the HomeLink<sup>®</sup> control buttons.

Keep the HomeLink<sup>®</sup> indicator light in view while programming.



Press and hold one of the HomeLink® buttons and the transmitter button. When the HomeLink® indicator light changes from a slow to a rapid flash, you can release both buttons.

If the HomeLink® indicator light comes on but does not flash, flashes rapidly for 2 seconds and remains lit, the HomeLink® button is already programmed. Use the other buttons or follow the "Reprogramming a HomeLink® button" instructions. (→P.605)



Test the HomeLink® operation by pressing the newly programmed button.

If a HomeLink® button has been programmed for a garage door, check to see if the garage door opens and closes. If the garage door does not operate, see if your remote control transmitter is of the rolling code type. Press and hold the programmed HomeLink® button. The remote control transmitter is of the rolling code type if the HomeLink® indicator light flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the rolling code type, proceed to the heading "Programming a rolling code system".

**STEP 4** Repeat the steps above to program another device for each of the remaining HomeLink® buttons.

### ■ Programming a Rolling Code system (for U.S.A. owners)

If your device is Rolling Code equipped, follow the steps under the heading “Programming the HomeLink<sup>®</sup>” before proceeding with the steps listed below.

**STEP 1** Locate the learn button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener motor.

Refer to the operation manual supplied with the garage door opener for the location of the learn button.

**STEP 2** Press the learn button.

Following this step, you have 30 seconds in which to initiate step 3 below.

**STEP 3** Press and hold the vehicle’s programmed HomeLink<sup>®</sup> button for 2 seconds and release it. Repeat this step once again. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink<sup>®</sup> signal and operate the garage door.

**STEP 4** Repeat the steps above to program another rolling code system for any of the remaining HomeLink<sup>®</sup> buttons.

### ■ Programming an entry gate (for U.S.A. owners)/Programming all devices in the Canadian market

**STEP 1** Place your transmitter 1 to 3 in. (25 to 75 mm) away from the surface of the HomeLink<sup>®</sup>.

Keep the HomeLink<sup>®</sup> indicator light in view while programming.

**STEP 2** Press and hold the selected HomeLink<sup>®</sup> button.

**STEP 3** Repeatedly press and release (cycle) the device’s remote control button for two seconds each until step 4 is completed.

**STEP 4** When the indicator light on the HomeLink<sup>®</sup> compatible transceiver starts to flash rapidly, release the buttons.

**STEP 5** Test the operation of the HomeLink<sup>®</sup> by pressing the newly programmed button. Check to see if the gate/device operates correctly.

**STEP 6** Repeat the steps above to program another device for each of the remaining HomeLink<sup>®</sup> buttons.

### ■ Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your authorized Lexus dealer for assistance.

### ■ Reprogramming a button

The individual HomeLink<sup>®</sup> buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the “Reprogramming a HomeLink<sup>®</sup> button” instructions.

## Operating HomeLink<sup>®</sup>

Press the appropriate HomeLink<sup>®</sup> button. The HomeLink<sup>®</sup> indicator light should turn on.

The HomeLink<sup>®</sup> compatible transceiver in your vehicle continues to send a signal for up to 20 seconds as long as the button is pressed.

## Reprogramming a HomeLink<sup>®</sup> button

Press and hold the desired HomeLink<sup>®</sup> button. After 20 seconds, the HomeLink<sup>®</sup> indicator light will start flashing slowly. Next, while still pressing and holding the HomeLink<sup>®</sup> button, press and hold the button on the transmitter until the HomeLink<sup>®</sup> indicator light changes from a slow to a rapid flash.

### Erasing the entire HomeLink<sup>®</sup> memory (all three programs)



Press and hold the 2 outside buttons for 10 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the HomeLink<sup>®</sup> memory.

#### ■ Before programming

- Install a new battery in the remote control transmitter.
- The battery side of the remote control transmitter must be pointed away from the HomeLink<sup>®</sup> button.

#### ■ Certification for the garage door opener

- For vehicles sold in the U.S.A.

FCC ID: CB2070NHL4

##### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

##### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- For vehicles sold in Canada

##### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### ■ When support is necessary

Visit on the web at [www.homelink.com](http://www.homelink.com) or call 1-800-355-3515.

 **CAUTION****■ When programming a garage door or other remote control device**

The garage door on other device may operate, so ensure people and objects are out of danger to prevent potential harm.

**■ Conforming to federal safety standards**

Do not use the HomeLink<sup>®</sup> compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an obstruction object. A door or device without these features increases the risk of death or serious injury.

3-8. Other interior features

Compass\*

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

■ Operation




To turn the compass on or off, press and hold “AUTO” for more than 3 seconds.

■ Displays and directions

| Display | Direction |
|---------|-----------|
| N       | North     |
| NE      | Northeast |
| E       | East      |
| SE      | Southeast |
| S       | South     |
| SW      | Southwest |
| W       | West      |
| NW      | Northwest |

\*: If equipped

## Calibrating the compass




The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.

If you cross over a map boundary shown in illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to the following.

### ■ Deviation calibration

**STEP 1** Stop the vehicle.



Press and hold "AUTO" for 6 seconds.


A number (1 to 15) appears on the compass display.

**STEP 3** Press "AUTO", and referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.

### ■ Circling calibration

**STEP 1** Stop the vehicle where it is safe to drive in a circle.



Press and hold "AUTO" for 12 seconds.

"C" appears on the compass display.



Drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until the direction is displayed.

### ■ Conditions unfavorable to correct operation

The compass may not show the correct direction in the following conditions:

- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized.  
(There is a magnet or metal object near the inside rear view mirror.)
- The battery has been disconnected.
- A door is open.

### ■ If “C” appears on the display

**STEP 1** Stop the vehicle where it is safe to drive in a circle.

**STEP 2** Drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until the direction is displayed.

### CAUTION

#### ■ While driving the vehicle

Do not adjust the display. Be sure to adjust the display only when the vehicle is stopped.

#### ■ When doing the circling calibration

Be sure to secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.

### NOTICE

#### ■ To avoid the compass malfunctions

Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause a malfunction of the compass sensor.

#### ■ To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.

### 3-8. Other interior features

## Safety Connect\*

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at [Lexus.com](http://Lexus.com). All use of the Safety Connect service is subject to such then-applicable Terms and Conditions.

#### ■ System components



- 1 Microphone
- 2 LED light indicators
- 3 "SOS" button

\*: If equipped

## ■ Services

Subscribers have the following Safety Connect services available:

- Automatic Collision Notification\*

Helps drivers receive necessary response from emergency service providers. (→P. 615)

\*: U.S. Patent No. 7,508,298 B2

- Stolen Vehicle Location

Helps drivers in the event of vehicle theft. (→P. 616)

- Emergency Assistance Button (SOS)

Connects drivers to response-center support. (→P. 616)

- Enhanced Roadside Assistance

Provides drivers various on-road assistance. (→P. 616)

## ■ Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987) or push the "SOS" button in your vehicle for further subscription details.

### ■ Safety Connect Services Information

- Phone calls using the vehicle's Bluetooth® technology will not be possible during Safety Connect.
- Safety Connect is available beginning Fall 2009 on select Lexus models. Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or receive emergency service support. Enrollment and Telematics Subscription Service Agreement required. A variety of subscription terms is available; charges vary by subscription term selected.
- Safety Connect services will function in the United States, including Hawaii and Alaska, and in Canada. The services will not function outside of the United States in countries other than Canada. For details about the service, contact your Lexus dealer.
- Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

### ■ Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English and Spanish. Please indicate your language of choice when enrolling.

### ■ When contacting the response center

You may be unable to contact the response center if the network is busy.

## Safety Connect LED light Indicators

When the “ENGINE START STOP” switch is turned to IGNITION ON mode, the red indicator light comes on for 2 seconds then turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

- Green indicator light on = Active service
- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Lexus dealer)
- No indicator light (off) = Safety Connect service not active

## Safety Connect services

### ■ Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

### ■ Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at [Lexus.com](http://Lexus.com).

### ■ Emergency Assistance Button (“SOS”)

In the event of an emergency on the road, push the “SOS” button to reach the Safety Connect response center. The answering agent will determine your vehicle’s location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the “SOS” button, tell the response-center agent that you are not experiencing an emergency.

### ■ Enhanced Roadside Assistance

Enhanced Roadside Assistance adds GPS data to the already included warranty-based Lexus roadside service.

Subscribers can press the “SOS” button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Enhanced Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at [Lexus.com](http://Lexus.com).

## Safety information for Safety Connect

Important! Read this information before using Safety Connect.

### ■ Exposure to radio frequency signals

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement) Report 86 [1986]
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

■ License

Licensed by QUALCOMM Incorporated under one or more of the following United States Patents and/or their counterparts in other nations:

4,901,307 5,490,165 5,056,109 5,504,773 5,101,501  
5,506,865 5,109,390 5,511,073 5,228,054 5,535,239  
5,267,261 5,544,196 5,267,262 5,568,483 5,337,338  
5,600,754 5,414,796 5,657,420 5,416,797 5,659,569  
5,710,784 5,778,338

■ Certification for Lexus Enform with Safety Connect

FCC ID: O9EGTM1

FCC ID: O6Y-CDMRF101

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**4-1. Maintenance and care**

Cleaning and protecting  
the vehicle exterior ..... 620

Cleaning and protecting  
the vehicle interior ..... 623

**4-2. Maintenance**

Maintenance  
requirements ..... 626

General maintenance ..... 628

Emission inspection and  
maintenance (I/M)  
programs..... 631

**4-3. Do-it-yourself  
maintenance**

Do-it-yourself service  
precautions ..... 632

Hood..... 635

Positioning a floor jack ..... 636

Engine compartment ..... 638

Tires..... 654

Tire inflation pressure..... 662

Wheels..... 666

Air conditioning filter ..... 668

Electronic key battery..... 671

Checking and replacing  
fuses ..... 673

Headlight aim ..... 678

Light bulbs..... 680

# Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

---

### ■ Automatic car washes

- Fold the mirrors back before washing the vehicle.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

### ■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before car wash, check that the fuel filler door on your vehicle is closed properly.

### ■ Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners. Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

### ■ Bumpers and side moldings

Do not scrub with abrasive cleaners.

### CAUTION

#### ■ Caution about the exhaust pipes and rear bumper diffusers

Exhaust gasses cause the exhaust pipes and rear bumper diffusers to become quite hot.

When washing the vehicle, be careful not to touch the pipes and diffusers until they have cooled sufficiently, as touching a hot exhaust pipes and rear bumper diffusers can cause burns.

### NOTICE

#### ■ To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
  - After driving near the sea coast
  - After driving on salted roads
  - If you see coal tar or tree sap on the paint surface
  - If you see dead insects, insect droppings or bird droppings on the paint
  - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
  - If the vehicle becomes heavily soiled in dust or mud
  - If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

#### ■ Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax on the surfaces of the lights. Wax may cause damage to the lenses.

#### ■ When using an automatic car wash



Set the wiper switch to off position.  
If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

# Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

### ■ Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

### ■ Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.  
Use a diluted water solution of approximately 5% neutral wool detergent.
- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

### ■ Synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

### ■ Caring for leather areas

Lexus recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

### ■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not apply water. Excellent results are obtained by keeping the carpet as dry as possible.

### ■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

### CAUTION

#### ■ Water in the vehicle

- Do not splash or spill liquid in the vehicle.

Doing so may cause electrical components etc. to malfunction or catch fire.

- Do not get any of the SRS components or wiring in the vehicle interior wet.  
(→P. 121)

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or severe injury.

#### ■ Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

 NOTICE**■ Cleaning detergents**

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
  - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, or bleach
  - Seats: Acidic solutions, such as thinner, benzene, or alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

**■ Preventing damage to leather surfaces**

Observe the following precautions to avoid damage to and deterioration of leather surfaces.

- Remove any dust or dirt on leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or that contain wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

**■ Water on the floor**

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components under the floor of the vehicle, and may also cause the body to rust.

**■ Cleaning the inside of the rear window**

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

# Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance is essential. It is the owner's responsibility to perform regular checks. Lexus recommends the following maintenance.

### ■ General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Lexus dealer.

### ■ Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Warranty and Service Guide/Owner's Manual Supplement/Scheduled Maintenance".

### ■ Do-it-yourself maintenance

You can perform some maintenance procedures yourself.

Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Lexus Repair Manuals is recommended.

For details about warranty coverage, see the separate "Owner's Guide", "Warranty and Service Guide", "Owner's Manual Supplement" or "Warranty Booklet".

---

### ■ Repair and replacement

It is recommended that genuine Lexus parts be used for repair to ensure performance of each system. If non-Lexus parts are used in replacement or if a repair shop other than a Lexus dealer performs repairs, confirm the warranty coverage.

### ■ Allow inspection and repairs to be performed by a Lexus dealer

- Lexus technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Lexus dealer will promptly take care of it.

### CAUTION

#### ■ If your vehicle is not properly maintained

It could result in serious damage to the vehicle and possible serious injury or death.

#### ■ Warning in handling of battery

- Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P. 650)

4-2. Maintenance

General maintenance

Listed below are the general maintenance items that should be performed at the intervals specified in the “Warranty and Service Guide” or “Owner’s Manual Supplement”. It is recommended that any problem you notice should be brought to the attention of your Lexus dealer or qualified service shop for advice.

Engine compartment

| Items                    | Check points                               |
|--------------------------|--------------------------------------------|
| Battery                  | Maintenance-free? (→P. 650)                |
| Brake fluid              | At the correct level? (→P. 648)            |
| Engine coolant           | At the correct level? (→P. 646)            |
| Engine oil               | At the correct level? (→P. 642)            |
| Exhaust system           | No fumes or strange sounds?                |
| Radiator/condenser/hoses | Not blocked with foreign matter? (→P. 648) |
| Washer fluid             | At the correct level? (→P. 653)            |

## Vehicle interior

| Items                                   | Check points                                                                                                                                                                                                 |
|-----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Accelerator pedal                       | <ul style="list-style-type: none"> <li>• Moves smoothly (without uneven pedal effort or catching)?</li> </ul>                                                                                                |
| Automatic transmission “Park” mechanism | <ul style="list-style-type: none"> <li>• Can the vehicle be held securely on an incline with the shift lever in P?</li> </ul>                                                                                |
| Brake pedal                             | <ul style="list-style-type: none"> <li>• Moves smoothly?</li> <li>• Does it have appropriate clearance and correct amount of free play?</li> </ul>                                                           |
| Brakes                                  | <ul style="list-style-type: none"> <li>• Not pull to one side when applied?</li> <li>• Loss of brake effectiveness?</li> <li>• Spongy feeling brake pedal?</li> <li>• Pedal almost touches floor?</li> </ul> |
| Head restraints                         | <ul style="list-style-type: none"> <li>• Move smoothly and lock securely?</li> </ul>                                                                                                                         |
| Indicators/buzzers                      | <ul style="list-style-type: none"> <li>• Function properly?</li> </ul>                                                                                                                                       |
| Lights                                  | <ul style="list-style-type: none"> <li>• Do all the lights come on?</li> <li>• Headlights aimed correctly? (→P. 678)</li> </ul>                                                                              |
| Parking brake                           | <ul style="list-style-type: none"> <li>• Moves smoothly?</li> <li>• Can hold the vehicle securely on an incline?</li> </ul>                                                                                  |
| Seat belts                              | <ul style="list-style-type: none"> <li>• Does the seat belt system operate smoothly?</li> <li>• Are the belts undamaged?</li> </ul>                                                                          |
| Seats                                   | <ul style="list-style-type: none"> <li>• Do the seat controls operate properly?</li> </ul>                                                                                                                   |

| Items          | Check points                                                                                                                    |
|----------------|---------------------------------------------------------------------------------------------------------------------------------|
| Steering wheel | <ul style="list-style-type: none"><li>• Moves smoothly?</li><li>• Has correct free play?</li><li>• No strange noises?</li></ul> |

Vehicle exterior

| Items       | Check points                                                                                                                                                                                                                     |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Door/trunk  | <ul style="list-style-type: none"><li>• Operate smoothly?</li></ul>                                                                                                                                                              |
| Engine hood | <ul style="list-style-type: none"><li>• The lock system works properly?</li></ul>                                                                                                                                                |
| Fluid leaks | <ul style="list-style-type: none"><li>• Is there any leakage after parking?</li></ul>                                                                                                                                            |
| Tire        | <ul style="list-style-type: none"><li>• Inflation pressure is correct?</li><li>• Tire surfaces not worn or damaged?</li><li>• Tires rotated according to the maintenance schedule?</li><li>• Wheel nuts are not loose?</li></ul> |

 CAUTION

 If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks.

# Emission inspection and maintenance (I/M) programs

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

### ■ If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Lexus dealer to service the vehicle.

### ■ Your vehicle may not pass the I/M test:

- When the battery is disconnected or discharged

Readiness codes that are set during ordinary driving are erased. Also, depending on your driving habits, the readiness codes may not be completely set.

- When the fuel tank cap is loose

The malfunction indicator lamp comes on as a temporary malfunction and your vehicle may not pass the I/M test.

### ■ When the malfunction indicator lamp goes off after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

### ■ If your vehicle does not pass the I/M test

Contact your Lexus dealer to prepare the vehicle for re-testing.

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions

If you perform maintenance yourself, be sure to follow the correct procedure as given in these sections.

| Items                          | Parts and tools                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Battery condition (→P. 650)    | <ul style="list-style-type: none"><li>• Warm water</li><li>• Baking soda</li><li>• Grease</li><li>• Conventional wrench (for terminal clamp bolts)</li></ul>                                                                                                                                                                                                                                                                                                                                                                   |
| Brake fluid level (→P. 648)    | <ul style="list-style-type: none"><li>• FMVSS No.116 DOT 3 or SAE J1703 brake fluid</li><li>• Rag or paper towel</li><li>• Funnel (used only for adding brake fluid)</li></ul>                                                                                                                                                                                                                                                                                                                                                 |
| Engine coolant level (→P. 646) | <ul style="list-style-type: none"><li>• “Toyota Super Long Life Coolant” or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology.<br/>For the U.S.A.:<br/>“Toyota Super Long Life Coolant” is pre-mixed with 50% coolant and 50% deionized water.<br/>For Canada:<br/>“Toyota Super Long Life Coolant” is pre-mixed with 55% coolant and 45% deionized water.</li><li>• Funnel (used only for adding engine coolant)</li></ul> |

| Items                             | Parts and tools                                                                                                                                                                            |
|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine oil level (→P. 642)        | <ul style="list-style-type: none"><li>• “Toyota Genuine Motor Oil” or equivalent</li><li>• Rag or paper towel, funnel (used only for adding engine oil)</li></ul>                          |
| Fuses (→P. 673)                   | <ul style="list-style-type: none"><li>• Fuse with same amperage rating as original</li></ul>                                                                                               |
| Headlight aim (→P. 678)           | <ul style="list-style-type: none"><li>• Phillips-head screwdriver</li></ul>                                                                                                                |
| Light bulbs (→P. 680)             | <ul style="list-style-type: none"><li>• Bulb with same number and wattage rating as original</li><li>• Phillips-head screwdriver</li><li>• Flathead screwdriver</li><li>• Wrench</li></ul> |
| Radiator and condenser (→P. 648)  | —                                                                                                                                                                                          |
| Tire inflation pressure (→P. 662) | <ul style="list-style-type: none"><li>• Tire pressure gauge</li><li>• Compressed air source</li></ul>                                                                                      |
| Washer fluid (→P. 653)            | <ul style="list-style-type: none"><li>• Water washer fluid containing anti-freeze (for winter use)</li><li>• Funnel</li></ul>                                                              |

### CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions:

#### ■ When working on the engine compartment

- Keep hands, clothing, and tools away from the moving fans and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.

#### ■ When working near the electric cooling fan or radiator grille

Be sure the "ENGINE START STOP" switch is OFF.

With the "ENGINE START STOP" switch in IGNITION ON mode, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. (→P. 648)

#### ■ Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in the eyes.

### NOTICE

#### ■ If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air. Also a backfire could cause a fire in the engine compartment.

4-3. Do-it-yourself maintenance

# Hood

Release the lock from the inside of the vehicle to open the hood.

STEP 1



Pull the hood release lever.  
The hood will pop up slightly.

STEP 2



Lift the auxiliary catch lever and lift the hood.

**! CAUTION**

**■ Pre-driving check**

Check that the hood is fully closed and locked.  
If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.


4-3. Do-it-yourself maintenance

# Positioning a floor jack

When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

■ Front


► 2WD models



► AWD models



■ Rear



## ⚠ CAUTION

### ■ When raising your vehicle

Make sure to observe the following to reduce the possibility of death or serious injury:




- Lift up the vehicle using a floor jack such as the one shown in the illustration.

- When using a floor jack, follow the instructions of the manual provided with the jack.
- Do not use the jack that was supplied with your vehicle.
- Do not put any part of your body or get underneath the vehicle supported only by the floor jack.  
Always use automotive jack stands on a solid, flat, level surface.
- Do not start the engine while the vehicle is supported by the floor jack.
- Stop the vehicle on level firm ground, firmly set the parking brake and put the shift lever in "P".
- Make sure to set the floor jack properly at the jack point.  
Raising the vehicle with an improperly positioned floor jack will damage the vehicle and may cause the vehicle to fall off the floor jack.
- Do not raise the vehicle while someone is in the vehicle.
- When raising the vehicle, do not place any objects on top of or underneath the floor jack.
- With electronically modulated air suspension:  
Be sure to turn off the height control and stop the engine. Otherwise, the vehicle height may change in the automatic leveling function. (→P. 239)

## 4-3. Do-it-yourself maintenance

### Engine compartment


#### ► 2WD models



CLY43AD329

- |                                    |           |                                   |
|------------------------------------|-----------|-----------------------------------|
| <b>1</b> Battery                   | (→P. 650) | <b>6</b> Electric cooling fans    |
| <b>2</b> Engine oil level dipstick | (→P. 642) | <b>7</b> Condenser                |
|                                    |           | (→P. 648)                         |
| <b>3</b> Engine oil filler cap     | (→P. 642) | <b>8</b> Radiator                 |
|                                    |           | (→P. 648)                         |
| <b>4</b> Brake fluid reservoir     | (→P. 648) | <b>9</b> Engine coolant reservoir |
|                                    |           | (→P. 646)                         |
| <b>5</b> Washer fluid tank         | (→P. 653) | <b>10</b> Fuse boxes              |
|                                    |           | (→P. 673)                         |

## ► AWD models




- |                                    |           |                                   |           |
|------------------------------------|-----------|-----------------------------------|-----------|
| <b>1</b> Battery                   | (→P. 650) | <b>6</b> Electric cooling fans    |           |
| <b>2</b> Engine oil level dipstick | (→P. 642) | <b>7</b> Condenser                | (→P. 648) |
| <b>3</b> Engine oil filler cap     | (→P. 642) | <b>8</b> Radiator                 | (→P. 648) |
| <b>4</b> Brake fluid reservoir     | (→P. 648) | <b>9</b> Engine coolant reservoir | (→P. 646) |
| <b>5</b> Washer fluid tank         | (→P. 653) | <b>10</b> Fuse boxes              | (→P. 673) |

Engine compartment cover

■ Removing the engine compartment covers


► Outside



► Front



■ Installing the clips




## Battery cover

### ■ Removing the battery cover



### ■ Installing the clips



### ⚠ NOTICE

#### ■ When installing the battery cover

Securely install the cover over the battery. Failure to do so may cause water to enter the engine compartment when it rains or the vehicle is washed, resulting in a malfunction.

### Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.

#### ■ Checking the engine oil

**STEP 1** Park the vehicle on level ground. After turning off the engine, wait more than five minutes for the oil to drain back into the bottom of the engine.

**STEP 2** Hold a rag under the end and pull the dipstick out.

► 2WD models



► AWD models




**STEP 3** Wipe the dipstick clean.

**STEP 4** Reinsert the dipstick fully.

**STEP 5** Holding a rag under the end, pull the dipstick out and check the oil level.

**STEP 6** Wipe the dipstick and reinsert it fully.



- 1 Low
- 2 Full

### ■ Adding engine oil



If the oil level is below or near the low level mark, add engine oil of the same type as already in the engine.

Make sure to check the oil type and prepare the items needed before adding oil.

|                           |                               |
|---------------------------|-------------------------------|
| Engine oil selection      | →P. 744                       |
| Oil quantity (Low → Full) | 1.6 qt. (1.5 L, 1.3 Imp. qt.) |
| Items                     | Clean funnel                  |

**STEP 1** Remove the oil filler cap by turning it counterclockwise.

**STEP 2** Add engine oil slowly, checking the dipstick.

**STEP 3** Install the oil filler cap by turning it clockwise.

---

### ■ Engine oil consumption

- The amount of engine oil consumed depends on the oil viscosity, the quality of the oil and the way the vehicle is driven.
- More oil is consumed under driving conditions such as high speeds, frequent acceleration and deceleration.
- A new engine consumes more oil.
- When judging the amount of oil consumption, keep in mind that the oil may have become diluted, making it difficult to judge the true level accurately.
- Oil consumption: Max. 1.1 qt./600 miles, 0.9 Imp. qt./600 miles (1.0 L per 1000 km)
- If your vehicle consumes more than 1.1 qt. (1.0 L, 0.9 Imp. qt.) every 600 miles (1000 km), contact your Lexus dealer.

### ■ After changing the engine oil (U.S.A.)

The oil change system should be reset. Perform the following procedures:

- STEP 1** Switch the display to the trip meter "A" when the engine is running.  
(→P. 183)
- STEP 2** Turn the "ENGINE START STOP" switch OFF.
- STEP 3** While pressing the trip meter reset button, set the "ENGINE START STOP" switch to IGNITION ON mode (but do not start the engine because otherwise the reset mode will be cancelled). Press and hold the button until the multi-information display indicates that the reset is complete.

### CAUTION

#### ■ Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Lexus dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

### NOTICE

#### ■ To prevent serious engine damage


Check the oil level on a regular basis.

#### ■ When replacing the engine oil

- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

### Engine coolant

The coolant level is satisfactory if it is between the “FULL” and “LOW” lines on the reservoir when the engine is cold.



**1** Reservoir cap

**2** “FULL”

**3** “LOW”

If the level is on or below the “LOW” line, add coolant up to the “FULL” line. (→P.735)

#### ■ If the coolant level drops within a short time after replenishing

Visually check the radiator, hoses, coolant reservoir cap, drain cock and water pump.

If you cannot find a leak, have your Lexus dealer test the cap and check for leaks in the cooling systems.

■ **Coolant selection**

Only use “Toyota Super Long Life Coolant” or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

U.S.A.: “Toyota Super Long Life Coolant” is a mixture of 50% coolant and 50% deionized water. (Enabled: -31°F [-35°C])

Canada: “Toyota Super Long Life Coolant” is a mixture of 55% coolant and 45% deionized water. (Enabled: -44°F [-42°C])

For more details about engine coolant, contact your Lexus dealer.

 **CAUTION**

■ **When the engine is hot**

Do not remove the coolant reservoir cap.  
The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing burns or other injuries.

 **NOTICE**

■ **When adding engine coolant**

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

■ **If you spill coolant**

Be sure to wash it off with water to prevent damage to parts or paint.

**Radiator and condenser**

Check the radiator and condenser, and clear any foreign objects.  
If either of the above parts are extremely dirty or you are not sure of their condition, have your vehicle checked by your Lexus dealer.

**! CAUTION**

- **When the engine is hot**  
Do not touch the radiator or condenser, as they may be hot and you may be burned.

**Brake fluid**

■ **Checking fluid level**



The brake fluid level should be between the “MAX” and “MIN” lines on the tank.

■ **Adding fluid**

Make sure to check the fluid type and prepare the necessary items.

|            |                                             |
|------------|---------------------------------------------|
| Fluid type | FMVSS No.116 DOT 3 or SAE J1703 brake fluid |
| Items      | Clean funnel                                |

### ■ Brake fluid can absorb moisture from the air

Excess moisture in the fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.

## CAUTION

### ■ When filling the reservoir

Take care because brake fluid can harm your hands or eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.

## NOTICE

### ■ If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.

### Battery

Check the battery as follows.

#### Battery exterior


Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- 1 Terminals
- 2 Hold-down clamp

#### Checking battery condition (vehicles with the battery indicator)

Check the battery condition using the indicator color.



- 1 Blue: Good condition
- 2 White: Charging is necessary.  
Have the vehicle inspected by your Lexus dealer.
- 3 Red: Not working properly.  
Have the battery checked by your Lexus dealer.

### ■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

### CAUTION

#### ■ Chemicals in the battery

A battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

#### ■ Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is not sufficient ventilation.

#### ■ How to recharge the battery

Only perform a slow charge (5 A or less). The battery may explode if charged at a quicker rate.

### CAUTION

#### ■ Emergency measures regarding electrolyte

- If electrolyte gets in your eyes  
Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin  
Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes  
It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte  
Drink a large quantity of water or milk. Follow with milk of magnesia, beaten raw egg or vegetable oil. Get emergency medical attention immediately.

### NOTICE

#### ■ When recharging the battery

Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

#### ■ When replacing the battery

Replace the battery with a battery of the same size.

Installing a battery of a different size will prevent the cover from being properly installed over the battery. This may cause water to enter the engine compartment when it rains or the vehicle is washed, resulting in a malfunction.

For more information about replacing the battery, contact your Lexus dealer.

## Washer fluid



If any washer does not work or the warning message appears on the multi-information display, the washer tank may be empty. Add washer fluid.

### CAUTION

#### ■ When refilling the washer fluid

Do not refill the washer fluid when the engine is hot or running, as the washer fluid contains alcohol and may catch fire if spilled on the engine etc.

### NOTICE

#### ■ Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

#### ■ Diluting washer fluid

Dilute washer fluid with water as necessary.  
Refer to the freezing temperatures listed on the washer fluid tank.

## 4-3. Do-it-yourself maintenance

### Tires

Replace or rotate tires in accordance with maintenance schedules and treadwear.

#### ■ Checking tires




- 1 New tread
- 2 Treadwear indicator
- 3 Worn tread

The location of treadwear indicators is shown by the “TWI” or “Δ” marks, etc., molded on the sidewall of each tire.

Check spare tire condition and pressure if not rotated.

#### ■ Tire rotation



Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Lexus recommends that tire rotation is carried out at the same interval as tire inspection.

#### ■ The tire pressure warning system

Your Lexus is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise. (→P. 706, 712)

### Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new tire pressure warning valve and transmitter ID codes must be registered in the tire pressure warning computer and tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by your Lexus dealer. (→P. 656)

### Initializing the tire pressure warning system

- The tire pressure warning system must be initialized when the tire inflation pressure is changed (such as when changing traveling speed.)

When the tire pressure warning system is initialized, the current tire pressure is set as the pressure benchmark.

#### ■ How to initialize the tire pressure warning system

- STEP 1** Park the vehicle in safe place and turn the “ENGINE START STOP” switch OFF.

While the vehicle is moving, initialization is not performed.

- STEP 2** Adjust the tire inflation pressure to the specified cold tire inflation pressure level. (→P. 749)

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

- STEP 3** Turn the “ENGINE START STOP” switch to IGNITION ON mode.



Push and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times and a message appears on the multi-information display.

**STEP 5** Wait a few minutes for the multi-information display to show the tire inflation pressures (5 tires), and turn the "ENGINE START STOP" switch OFF.

### Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code of tire pressure warning valve and transmitter. Have the ID code registered by your Lexus dealer.

### ■ When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric or bulges indicating internal damage.
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage.

If you are not sure, consult with your Lexus dealer.

### ■ Replacing tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 20 minutes, the tire pressure warning light comes on after blinking for 1 minute to indicate a system malfunction.

### ■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if they have seldom or never been used or damage is not obvious.

### ■ If the tread wears down below 0.16 in. (4 mm) on snow tires

The effectiveness of the tires as snow tires is lost.

### ■ Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.



For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. (→P. 755)

### ■ Tire types

#### 1 Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

#### 2 All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions, as well as for use year round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

#### 3 Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restriction. Snow tires should be installed on all wheels. (→P. 305)

### ■ Initializing the tire pressure warning system

Initialize the tire pressure warning system with the tire inflation pressure adjusted to the specified level.

### ■ If you push the tire pressure warning reset switch accidentally

If initialization is performed, adjust the tire inflation pressure to the specified level and initialize the tire pressure warning system again.

### ■ When the initialization of the tire pressure warning system has failed

Initialization can be completed in a few minutes. However, in the following cases, the settings has not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by your Lexus dealer.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not flash 3 times and the setting message does not appear on the multi-information display.
- After carrying out the initialization procedure, the tire pressure warning light blinks for 1 minute then stays on after driving for about 20 minutes.

### ■ Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

### ■ Tire pressure warning system certification

TPMS Transmitter FCC ID: PAXPMV107J  
IC ID: 3729A-PMV107J  
TPMS Receiver FCC ID: HYQ13BCX  
IC ID: 1551A-13BCX

► For vehicles sold in the U.S.A.

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### CAUTION

#### ■ When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train, as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns.  
Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Lexus.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and winter tires.

#### ■ Using tires of a different size

Do not use tires of a different size from those equipped when the vehicle was new, as the front tire steering angle setting is designed for the original tire size. It is dangerous to use an incorrect wheel and tire combination as this may result in reduced vehicle stability.

#### ■ When initializing the tire pressure warning system

Do not push the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

 NOTICE**■ Repairing or replacing tires, wheels, tire pressure warning valves and transmitters and tire valve caps**

- When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Lexus dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.
- When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.

**■ To avoid damaging the tire pressure warning valves and transmitters**

Do not use liquid sealants on flat tires.

**■ Driving on rough roads**

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

**■ If tire inflation pressures become low while driving**

Do not continue driving, or your tires and/or wheels may be ruined.

# 4-3. Do-it-yourself maintenance

## Tire inflation pressure

### Tire inflation pressure

The recommended cold tire inflation pressure and tire size is displayed on the tire and loading information label. (→P. 749)



### ■ Inspection and adjustment procedure



1 Tire valve

2 Tire pressure gauge

**STEP 1** Remove the tire valve cap.

**STEP 2** Press the tip of the tire pressure gauge onto the tire valve.

**STEP 3** Read the pressure using the graduations of the gauge.

**STEP 4** If the tire inflation pressure is not within the recommended levels, adjust inflate the tire.

If you add too much air, press the center of the valve to lower.

**STEP 5** After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.

**STEP 6** Reinstall the tire valve cap.

### ■ Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month. Do not forget to check the spare.

### ■ Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drive train

If a tire needs frequent refilling, have it checked by your Lexus dealer.

### ■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold.  
If your vehicle has been parked for at least 3 hours and has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge.  
The appearance of the tire can be misleading. In addition, tire inflation pressures that are even just a few pounds off can degrade ride and handling.
- Do not bleed or reduce tire inflation pressure after driving. It is normal for the tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight.  
Passengers and luggage weight should be placed so that the vehicle is balanced.

 **CAUTION****■ Proper inflation is critical to save tire performance**

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards

 **NOTICE****■ When inspecting and adjusting tire inflation pressure**

Be sure to reinstall the tire valve caps.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps have been lost, replace them as soon as possible.

### Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause loss of handling control.

#### ■ Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and inset\*.

Replacement wheels are available at your Lexus dealer.

\*: Conventionally referred to as “offset”.

Lexus does not recommend using the following:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

#### ■ Aluminum wheel precautions

- Use only Lexus wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Lexus genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

---

#### ■ When replacing wheels

The wheels of your Lexus are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advanced warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, the tire pressure warning valves and transmitters must be installed. (→P. 655)

 **CAUTION****■ When replacing wheels**

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing serious injury or death.

 **NOTICE****■ Replacing tire pressure warning valves and transmitters**

- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Lexus dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Lexus dealer.
- Ensure that only Genuine Lexus wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

## 4-3. Do-it-yourself maintenance

### Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

#### ■ Front air conditioning filter


**STEP 1** Set the air conditioning system to recirculated mode.  
(→P. 331, 344)

The air conditioning filter case cannot be removed with the system in the outside air mode.


**STEP 2** Turn the “ENGINE START STOP” switch OFF.



Open the glove box. Lift and remove the partition.



Remove the filter cover.



Remove the filter case.


**STEP 6**

Remove the air conditioning filter from the filter case and replace it with a new one.

The “↑UP” marks shown on the filter and the filter case should be pointing up.

**STEP 7** Reset the air conditioning filter maintenance data. (→P. 670)**■ Rear air conditioning filter (if equipped)****STEP 1** Turn the “ENGINE START STOP” switch OFF.**STEP 2**

Open the trunk lid. Remove the filter cover.

**STEP 3**

Remove the air conditioning filter and replace it with a new one.

The “↑UP” marks shown on the filter should be pointing up.

### ■ Changing interval for the front air conditioning filter

Inspect and replace the air conditioning filter when a message is appeared on the multi-information display. In dusty areas or areas with heavy traffic flow, early replacement may be required.

### ■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

### ■ After changing the air conditioning filter

The air conditioning filter maintenance data should be reset. Perform the following procedures:

**STEP 1** Turn the "ENGINE START STOP" switch to IGNITION ON mode.

**STEP 2** Press and hold  (on the air conditioning panel) for 4 seconds or more.

A buzzer will sound to indicate that the maintenance data has been successfully reset.

### ■ Rear air conditioning filter (if equipped)

If it is necessary to clean or replace the filter, contact your Lexus dealer.

### ■ Climate control seat filter (if equipped)

Filters are installed in the seats. When it is necessary to clean or replace the filters, contact your Lexus dealer.

### NOTICE

### ■ When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

### Electronic key battery

Replace the battery with a new one if it is discharged.

■ You will need the following items:

- Flathead screwdriver
- Small Phillips-head screwdriver
- Lithium battery (CR1632)

■ Replacing the battery

STEP 1




Take out the mechanical key.

STEP 2



Remove the cover.

STEP 3



Remove the depleted battery.

Insert a new battery with the “+” terminal facing up.

### ■ If the electronic key battery is discharged

The following symptoms may occur:

- The smart access system with push-button start and wireless remote control will not function properly.
- The operational range is reduced.

### ■ Use a CR1632 lithium battery

- Batteries can be purchased at your Lexus dealer, jewelers, or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the local laws.

### ■ When the card key battery needs to be replaced (if equipped)

The battery for the card key is available only at Lexus dealers. Your Lexus dealer can replace the battery for you.

### CAUTION

#### ■ Removed battery and other parts

Keep away from children.

These parts are small and if swallowed by a child, they can cause choking.

### NOTICE

#### ■ For normal operation after replacing the battery

Observe the following precautions to prevent accidents:

- Always work with dry hands.  
Moisture may cause the battery to rust.
- Do not touch or move any other components inside the remote control.
- Do not bend either of the battery terminals.

## 4-3. Do-it-yourself maintenance

### Checking and replacing fuses


If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

**STEP 1** Turn the "ENGINE START STOP" switch OFF.

**STEP 2** Remove the engine compartment cover. (→P. 640)


**STEP 3** Open the fuse box cover.

► Engine compartment (type A fuse box)



Push the tabs in and lift the lid off.

► Engine compartment (type B fuse box)



Push the tab in and lift the lid off.

► Driver's side instrument panel



Remove the lid.

► Passenger's side instrument panel



Remove the lid.

► Trunk



Remove the lid.




Take out the pullout tool.

Only type A fuse can be removed using the pullout tool.

**STEP 5** Check if the fuse has blown.

## ► Type A

**1** Normal fuse**2** Blown fuse


Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

## ► Type B

**1** Normal fuse**2** Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

## ► Type C

**1** Normal fuse**2** Blown fuse

Contact your Lexus dealer.

### ► Type D



**1** Normal fuse

**2** Blown fuse

Contact your Lexus dealer.

### ■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 680)
- If the replaced fuse blows again, have the vehicle inspected by your Lexus dealer.

### ■ If there is an overload in the circuit

The fuses are designed to blow before the entire wiring harness is damaged.

 **CAUTION** **To prevent system breakdowns and vehicle fire**

Observe the following precautions.

Failing to do so may cause damage, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than indicated, or use any other object in place of a fuse.
- Always use a genuine Lexus fuse or equivalent.  
Never replace a fuse with a wire, even as a temporary fix.  
This can cause extensive damage or even fire.
- Do not modify fuses or the fuse box.

 **NOTICE** **Before replacing fuses**

Have the cause of electrical overload determined and repaired by your Lexus dealer.


## 4-3. Do-it-yourself maintenance

### Headlight aim

#### ■ Removing the engine compartment cover.

→P. 640

#### ■ Vertical movement adjusting bolts



1 Adjustment bolt A

2 Adjustment bolt B

#### ■ Before checking the headlight aim

**STEP 1** Make sure the vehicle has a full tank of gas and the area around the headlight is not deformed.

**STEP 2** Park the vehicle on level ground.

**STEP 3** Sit in the driver's seat.

**STEP 4** Bounce the vehicle several times.


#### ■ Adjusting the headlight aim



Turn bolt A in either direction using a Phillips-head screwdriver.

Remember the turning direction and the number of turns in mind.

## STEP 2



Turn bolt B the same number of turns and in the same direction as step 1 using a Phillips-head screwdriver.

If the error is over the value specified above, take the vehicle to your Lexus dealer to adjust the headlight aim

## 4-3. Do-it-yourself maintenance

### Light bulbs

You may replace the following bulbs by yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Lexus dealer.

For more information about replacing other light bulbs, contact your Lexus dealer.


#### ■ Preparing for light bulb replacement

Check the wattage of the light bulb being replaced. (→P. 751)

#### ■ Remove the engine compartment cover

→P. 640

#### ■ Front bulb locations



### ■ Rear bulb locations



### Replacing light bulbs

#### ■ Headlight high beams

**STEP 1** Before replacing the bulbs:

► Left side




Remove the securing bolt and move the washer fluid filler opening.


### ► Right side




Remove the securing bolts and nut, and move the fuse block.



Turn the cover counterclockwise and remove it.




Turn the bulb base counterclockwise.



Unplug the connector while pulling the lock release.

## ■ Front fog lights


### STEP 1



To allow enough working clearance, turn the steering wheel to the opposite side of the bulb to be replaced.


Remove the fender liner bolt and clips, and then remove the fender liner.

### STEP 2




Turn the bulb base counterclockwise.

### STEP 3



Unplug the connector while depressing the lock release.



Install the bolt and clips.

■ Front turn signal lights

**STEP 1** Before replacing the bulbs:

► Left side




Remove the securing bolt and move the washer fluid filler opening.


► Right side



Remove the securing bolts and nut, and move the fuse block.



Turn the cover counterclockwise and remove it.



Turn the bulb base counterclockwise.



Remove the light bulb.


### ■ Back-up lights

STEP 1



Open the trunk lid and remove the cover.

STEP 2



Turn the bulb base counterclockwise.


STEP 3



Remove the light bulb.

## ■ Rear turn signal lights

STEP 1



Open the trunk lid and remove the cover.

STEP 2



Turn the bulb base counterclockwise.

STEP 3



Remove the light bulb.

### ■ Lights other than the above

If any of the lights listed below has burnt out, have it replaced by your Lexus dealer.

- Headlight low beams or low/high beams (discharge bulb)
  - Parking lights
  - Side turn signal lights
  - Side marker lights
  - Stop lights
  - Tail lights
  - High mounted stoplight
  - License plate lights
- 

### ■ Condensation build-up on the inside of the lens

Contact your Lexus dealer for more information in the following situations. Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

- Large drops of water are built up on the inside of the lens.
- Water has built up inside the headlight.

### ■ Discharge headlights

If voltage to the discharge bulbs is insufficient, the bulbs may not come on, or may go out temporarily. The discharge bulbs will come on when normal power is restored.

### ■ LED light bulbs

The parking lights, side turn signal lights, side marker lights, stop lights, tail lights, high mounted stoplight and license plate lights consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Lexus dealer to have the light replaced.

 **CAUTION****■ Replacing light bulbs**

- Turn off the lights. Do not attempt to replace the bulb immediately after turning off the lights.  
The bulbs become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. Hold the bulb by the plastic or metal portion.  
If the bulb is scratched or dropped it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failing to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

**■ Discharge headlights**

- Contact your Lexus dealer before replacing discharge headlights (including light bulbs).
- Do not touch the high-intensity discharge headlight's high voltage socket when the headlights are turned on.  
An extremely high voltage of 20000 V will be discharged and could result in serious injury or death by electric shock.
- Do not attempt to take apart or repair the low beam discharge headlight bulbs, connectors, power supply circuits, or related components.  
Doing so could result in electric shock and serious injury or death.

**■ To prevent damage or fire**

Make sure bulbs are fully seated and locked.



## 5-1. Essential information

|                                            |     |
|--------------------------------------------|-----|
| Emergency flashers.....                    | 692 |
| If your vehicle needs to be<br>towed ..... | 693 |
| If you think something is<br>wrong .....   | 699 |
| Fuel pump shut off system....              | 700 |
| Event data recorder .....                  | 701 |

## 5-2. Steps to take in an emergency

|                                                                    |     |
|--------------------------------------------------------------------|-----|
| If a warning light turns<br>on or a warning buzzer<br>sounds... .. | 703 |
| If a warning message is<br>displayed.....                          | 712 |
| If you have a flat tire.....                                       | 715 |
| If the engine will not start ....                                  | 723 |
| If the shift lever cannot be<br>shifted from "P" .....             | 725 |
| If the parking brake<br>cannot be released.....                    | 726 |
| If the electronic key<br>does not operate<br>properly .....        | 728 |
| If the vehicle battery is<br>discharged .....                      | 732 |
| If your vehicle overheats ....                                     | 735 |
| If the vehicle becomes<br>stuck.....                               | 738 |

5-1. Essential information

Emergency flashers

Use the emergency flashers if the vehicle malfunctions or is involved in an accident.



Press the switch to flash all the turn signal lights. To turn them off, press the switch once again.



NOTICE

■ To prevent battery discharge

Do not leave the emergency flashers on longer than necessary when the engine is not running.

## 5-1. Essential information

### If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Lexus dealer or a commercial towing service, using a lift-type truck or a flatbed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

2WD models: If towing from the rear, the vehicle's front wheels and axles must be in good condition. (→P. 697)

If the vehicle is damaged, use a towing dolly or flatbed truck.

#### Before towing

The following may indicate a problem with your transmission. Contact your Lexus dealer before towing.

- The engine is running, but the vehicle will not move.
- The vehicle makes an abnormal sound.

#### Emergency towing

If a tow truck is not available, in an emergency your vehicle may be temporarily towed using a cable or chain secured to the emergency towing eyelet(s). This should only be attempted on hard, surfaced roads for short distances at low speeds.

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.



Towing eyelet

### ■ Before emergency towing

- Release the parking brake.
- Shift the shift lever to “N”.
- Turn the “ENGINE START STOP” switch to ACCESSORY (engine off) or IGNITION ON mode (engine running).

### CAUTION

#### ■ Caution while towing

- Use extreme caution when towing the vehicle.  
Avoid sudden starts or erratic driving maneuvers which place excessive stress on the emergency towing eyelets and the cables or chains. Always use caution for the surroundings and other vehicles while towing.
- If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.

### NOTICE

#### ■ To prevent causing serious damage to the transmission (2WD models)

Never tow this vehicle from the front with the rear wheels on the ground.  
This may cause serious damage to the transmission.

#### ■ To prevent causing serious damage to the transmission and the transfer (AWD models)


Never tow this vehicle with any of the wheels in contact with the ground.  
This may cause serious damage to the transmission and the transfer.

## Installing towing eyelets




Remove the eyelet cover using a flathead screwdriver.

To protect the bodywork, place a rag between the screwdriver and the vehicle body, as shown in the illustration.



Insert the towing eyelet into the hole and tighten partially by hand.



Tighten down the towing eyelet securely using a wheel nut wrench.

### ■ Location of the emergency towing eyelet

→P. 715

### CAUTION

#### ■ Installing towing eyelets to the vehicle

Make sure that towing eyelets are installed securely.

If not securely installed, towing eyelets may come loose during towing. This may lead to accidents that cause serious injury or even death.

### Towing with a sling-type truck




### NOTICE

#### ■ To prevent body damage

Do not tow with a sling type truck, either from the front or rear.


## Towing with a wheel lift-type truck

### ► From the front




Use a towing dolly under the rear wheels.

### ► From the rear (2WD models)



Switch to ACCESSORY mode so that the steering wheel is unlocked.

### ► From the rear (AWD models)



Use a towing dolly under the front wheel.

### NOTICE

#### ■ To prevent causing serious damage to the transmission (2WD models)

Never tow this vehicle from the front with the rear wheels on the ground.

#### ■ To prevent causing serious damage to the transmission and the transfer (AWD models)

Never tow this vehicle with any of the wheels in contact with the ground.


#### ■ To prevent damaging the vehicle

- Do not tow the vehicle with the “ENGINE START STOP” switch OFF.


The steering lock mechanism is not strong enough to hold the front wheels straight.

- When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

### Using a flat bed truck



If your Lexus is transported by a flat bed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.

### If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Lexus dealer as soon as possible.

#### ■ Visible symptoms

- Fluid leaks under the vehicle.  
(Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal.

#### ■ Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

#### ■ Operational symptoms

- Engine missing, stumbling or running rough
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

## 5-1. Essential information

### Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or an airbag inflates upon collision, the fuel pump shut off system stops supplying fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

**STEP 1** Switch to ACCESSORY mode or OFF.

**STEP 2** Restart the engine.

#### NOTICE

##### ■ Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked on to the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

## 5-1. Essential information

### Event data recorder

Your vehicle has computers that monitor and control certain aspects of your vehicle. These computers assist in driving and maintaining optimal vehicle performance.

Besides storing data useful for troubleshooting, there is an event data recorder (EDR) that records data in a crash or a near car crash event.

#### In a crash or a near car crash event

The SRS airbag sensor assembly contains the EDR. In a crash or a near car crash event, this device may record some or all of the following information:

- Engine speed
- Whether the brake pedal was applied or not
- Vehicle speed
- To what extent the accelerator pedal was depressed
- Position of the transmission shift lever
- Whether the driver and front passenger wore seat belts or not
- Driver's seat position
- SRS airbag deployment data
- SRS airbag system diagnostic data
- Front passenger's occupant classification

The information above is intended to be used for the purpose of improving vehicle safety performance. Unlike general data recorders, the EDR does not record sound data such as conversation between passengers.

### Disclosure of the data

Lexus will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the leasing company for a leased vehicle) is obtained
- Officially requested by the police or other authorities
- Used as a defense for Lexus in a law suit
- Ordered by a court law

However, if necessary Lexus will:

- Use the data for research on Lexus vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing details of the vehicle owner, and only when it is deemed necessary
- Disclose summarized data cleared of vehicle identification information to a non-Lexus organization for research purposes

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds...

Calmly perform the following actions if any of the warning lights turn on or flash. If a light turns on or flashes, but then turns off, this does not necessarily indicate a malfunction in the system.

Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact your Lexus dealer.

| Warning light                                                                              | Warning light/Details                                                                                                                                                   |
|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  (U.S.A.) | <b>Brake system warning light</b> <ul style="list-style-type: none"><li>• Low brake fluid</li><li>• Malfunction in the electronically controlled brake system</li></ul> |
|  (Canada) |                                                                                                                                                                         |

Stop the vehicle immediately.

The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Lexus dealer.

| Warning light                                                                       | Warning light/Details                                                                            |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
|  | <b>Charging system warning light</b><br>Indicates a malfunction in the vehicle's charging system |

Have the vehicle inspected by your Lexus dealer immediately.

Failing to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Lexus dealer immediately.

| Warning light                                                                                                                                                                                       | Warning light/Details                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div> (U.S.A.)<br/> (Canada)</div>  | <b>Malfunction indicator lamp</b><br>Indicates a malfunction in: <ul style="list-style-type: none"><li>• The electronic engine control system;</li><li>• The electronic throttle control system; or</li><li>• The electronic automatic transmission control system</li></ul> |
|                                                                                                                    | <b>SRS warning light</b><br>Indicates a malfunction in: <ul style="list-style-type: none"><li>• The SRS airbag system;</li><li>• The seat belt pretensioner system; or</li><li>• The active head restraints system</li></ul>                                                 |
| <div> (U.S.A.)<br/> (Canada)</div> | <b>ABS warning light</b><br>Indicates a malfunction in: <ul style="list-style-type: none"><li>• The ABS; or</li><li>• The brake assist system</li></ul>                                                                                                                      |
|                                                                                                                  | <b>Brake system warning light</b><br>Indicates a malfunction in: <ul style="list-style-type: none"><li>• The electronically controlled brake system; or</li><li>• The electric parking brake</li></ul>                                                                       |
|                                                                                                                  | <b>Electric power steering system warning light</b><br>Indicates a malfunction in the EPS (Electric Power Steering) system                                                                                                                                                   |
| <div> (Flashes)</div>                                                                                            | <b>Pre-collision system warning light (if equipped)</b><br>Indicates a malfunction in the pre-collision system (The warning light may go off after the correction procedure is performed. This indicates that the system has returned to normal.)                            |

| Warning light                                                                                   | Warning light/Details                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>(Comes on) | <b>Slip indicator</b><br>Indicates a malfunction in: <ul style="list-style-type: none"><li>• The VSC system;</li><li>• The TRAC system; or</li><li>• The hill-start assist control system</li></ul> |

■ **If the malfunction indicator lamp comes on while driving**

First check the following:

- Is the fuel tank empty?  
If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose?  
If it is, tighten it securely.

The lamp will go off after taking several driving trips.

If the light does not go off even after several trips, contact your Lexus dealer as soon as possible.

■ **Electric power steering system warning light**

When the battery is low or when the voltage drops temporarily, the electric power steering system warning light may come on.

 **CAUTION**

■ **When the electric power steering system warning light comes on**

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, firmly hold and operate it using more force than usual.

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

| Warning light                                                                                          | Warning light/Details                                                                                                                     | Correction procedure                           |
|--------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|
|                       | <b>Open door warning light (warning buzzer)*<sup>1</sup></b><br>Indicates that a door or the trunk is not fully closed.                   | Check that all doors and the trunk are closed. |
| <br>In the fuel gauge | <b>Low fuel level warning light</b><br>Remaining fuel<br>(Approximately 3.4 gal. [13L, 2.8 Imp. gal.] or less)                            | Refuel the vehicle.                            |
|                       | <b>Driver's seat belt reminder light (warning buzzer)*<sup>2</sup></b><br>Warns the driver to fasten his/her seat belt.                   | Fasten the seat belt.                          |
|                      | <b>Front passenger's seat belt reminder light (warning buzzer)*<sup>2</sup></b><br>Warns the front passenger to fasten his/her seat belt. | Fasten the seat belt.                          |
|                     | <b>Tire pressure warning light</b>                                                                                                        |                                                |
|                                                                                                        | When the light comes on:<br>Low tire inflation pressure                                                                                   | Adjust the tire pressure.                      |
|                                                                                                        | When the light comes on after blinking for 1 minute:<br>Malfunction in the tire pressure warning system                                   | Have the system checked by your Lexus dealer.  |

| Warning light                                                                     | Warning light/Details                                                                                                                                           | Correction procedure |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
|  | <b>Master warning light</b><br>A buzzer sounds and the warning light comes on or flashes to indicate that the master warning system has detected a malfunction. | →P. 712              |

**\*1: Open door warning buzzer:**

The open door warning buzzer sounds to alert one or more of the doors is not fully closed (with the vehicle having reached a speed of 3 mph [5 km/h]).

**\*2: Driver's and front passenger's seat belt buzzer:**

The driver's and front passenger's seat belt buzzer sounds to alert the driver and front passenger that his or her seat belt is not fastened. The buzzer sounds intermittently for 10 seconds after the vehicle reaches a speed of 12 mph (20 km/h). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

■ **Front passenger detection sensor and passenger seat belt reminder**

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash, even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

■ **When the tire pressure warning light comes on**

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch does not turn off the tire pressure warning light.

### ■ The tire pressure warning light may turn on due to natural causes

The tire pressure warning light may turn on due to natural causes such as natural air leaks or tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

### ■ When a tire is replaced with a spare tire

The spare tire is also equipped with the tire pressure warning valve and transmitter. The tire pressure warning light will turn on if the tire inflation pressure of the spare tire is low. If a tire goes flat, even though the flat tire is replaced with the spare tire, the tire pressure warning light does not turn off. Replace the spare tire with the repaired tire and adjust the proper tire inflation pressure. The tire pressure warning light will turn off after a few minutes.

### ■ If the tire pressure warning system is inoperative

The tire pressure warning system will be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If tires not equipped with tire pressure warning valves and transmitters are used.
- If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- If the tire inflation pressure is 73 psi (500 kPa, 5.1 kgf/cm<sup>2</sup> or bar) or higher.

The tire pressure warning system may be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If electronic devices or facilities using similar radio wave frequencies are nearby.
- If a radio set at similar frequencies is in use in the vehicle.
- If a window tint that affects the radio wave signals is installed.
- If there is a lot of snow or ice on the vehicle, in particular around the wheels or wheel housings.
- If non-genuine Lexus wheels are used. (Even if you use Lexus wheels, the tire pressure warning system may not work properly with some types of tires.)
- If tire chains are used.
- If the spare tire is in a location subject to poor radio wave signal reception.
- If a large metallic object which can interfere with signal reception is put in the trunk.

■ **If the tire pressure warning light comes on after blinking for 1 minute frequently**

If the tire pressure warning light comes on after blinking for 1 minute frequently when the “ENGINE START STOP” switch is turned to IGNITION ON mode, have it checked by your Lexus dealer.

■ **Customization**

The vehicle speed linked seat belt reminder buzzer can be disabled.  
(Customizable features →P. 766)

 **CAUTION**

■ **If the tire pressure warning light comes on**

Be sure to observe the following precautions. Failure to do so could cause loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If the tire is flat, change to the spare tire and have the flat tire repaired by the nearest Lexus dealer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.

■ **If a blowout or sudden air leakage should occur**

The tire pressure warning system may not activate immediately.

### CAUTION

#### ■ Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.

**NOTICE****■ Precaution when installing a different tire**

When a tire of a different specification or maker is installed, the tire pressure warning system may not operate properly.

## 5-2. Steps to take in an emergency

### If a warning message is displayed

The multi-information display shows warnings of system malfunctions, incorrectly performed operations, or shows messages that indicate a need for maintenance. When a message is shown, perform the correction procedure appropriate to the message.



#### 1 Master warning light

The master warning light comes on or flashes when a message is being shown on the multi-information display.

#### 2 Multi-information display

If any of the warning messages is shown again after its correction procedure has been performed, contact your Lexus dealer.

## Messages and warnings

The warning lights and warning buzzers operate as follows depending on the content of the message. If a message indicates the need for inspection by a dealer, have the vehicle inspected by your Lexus dealer immediately.

|  | System warning light | Warning buzzer* | Warning                                                                                                                                                             |
|-----------------------------------------------------------------------------------|----------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Comes on                                                                          | —                    | Sounds          | Indicates an important situation, such as when a system related to driving is malfunctioning or that danger may result if the correction procedure is not performed |
| —                                                                                 | Comes on or flashes  | Sounds          | Indicates an important situation, such as when the system shown on the multi-information display may be malfunctioning                                              |
| Flashes                                                                           | —                    | Sounds          | Indicates a situation, such as when damage to the vehicle or danger may result                                                                                      |
| Comes on                                                                          | —                    | Does not sound  | Indicates a condition, such as malfunction of electrical components, their condition, or indicates the need for maintenance                                         |
| Flashes                                                                           | —                    | Does not sound  | Indicates a situation, such as when an operation has been performed incorrectly, or indicates how to perform an operation correctly                                 |

\*: A buzzer sounds the first time a message is shown on the multi-information display.

### ■ System warning lights

The master warning light does not come on or flash in the following cases. Instead, a separate system warning light will come on or flash along with the message shown on the multi-information display.

- Malfunction of the AFS (Adaptive Front-lighting System)  
The “AFS OFF” indicator light flashes. (→P. 196)
- Malfunction of the brake system  
The brake system warning light (red indicator) comes on. (→P. 703)
- Malfunction of the electronically controlled brake system or electric parking brake  
The brake system warning light (yellow indicator) comes on. (→P. 704)
- Malfunction of the ABS  
The ABS warning light comes on. (→P. 704)
- Malfunction of the charging system  
The charging system warning light comes on. (→P. 703)
- High engine coolant temperature  
The needle of the engine coolant temperature gauge enters the red zone. (→P. 183)

### ■ When “Electrical equipment operation is limited” is shown

This message indicates that the battery is low. When the message is shown, operation of electrical equipment that uses a large amount of electric power, such as the air conditioning system, may be limited temporarily. This does not indicate a malfunction. Operation of electrical equipment will be restored after the battery is charged.


## 5-2. Steps to take in an emergency If you have a flat tire

Remove the flat tire and replace it with the spare provided.

### ■ Before jacking up the vehicle

- Stop the vehicle on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to "P".
- Stop the engine.
- Turn on the emergency flashers.

### ■ Location of the spare tire, jack and tools



### Penlight

The vehicle is equipped with a penlight, located inside the trunk. The penlight is provided in case it is necessary to perform an unexpected service operation at night, such as installation of the spare tire.



- 1 Turn the top portion to remove it.
- 2 Insert batteries.
- 3 Install the top portion.
- 4 On/off

### Taking out the jack and spare tire




Lift up the hook of the panel on the trunk floor.



Secure the panel using the hook provided.



Remove the tool tray.



Remove the jack after removing the hook.



Loosen the center fastener that secures the spare tire.

If the center fastener cannot be turned by hand, use the wrench that is stored in the trunk. (To secure the tire, tighten the center fastener by hand. Do not use the wrench or other tools.)

Replacing a flat tire

STEP 1



Chock the tires.


| Flat tire |                 | Wheel chock positions                      |
|-----------|-----------------|--------------------------------------------|
| Front     | Left-hand side  | Behind the rear right-hand side tire       |
|           | Right-hand side | Behind the rear left-hand side tire        |
| Rear      | Left-hand side  | In front of the front right-hand side tire |
|           | Right-hand side | In front of the front left-hand side tire  |

STEP 2



Slightly loosen the wheel nuts (one turn).

STEP 3



Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.



Raise the vehicle until the tire is slightly raised off the ground.




Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.

### Installing the spare tire


#### STEP 1



Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire may come off the vehicle.

#### STEP 2



Install the spare tire and loosely tighten each wheel nut by hand by approximately the same amount.


Turn the lug nuts until the washers come into contact with the wheel.

#### STEP 3



Lower the vehicle.

#### STEP 4



Firmly tighten each nut two or three times in the order shown in the illustration.

**Tightening torque:**

103.3 ft•lbf (140 N•m, 14.3 kgf•m)

**STEP 5** Stow the flat tire, tire jack and all tools.

#### ■ After completing the tire change

The tire pressure warning system must be reset. (→P. 655)

#### CAUTION

##### ■ Using the tire jack

Improper use of the tire jack may lead to death or serious injuries due to the vehicle suddenly falling off the jack.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.  
Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Always check that the tire jack is securely set to the jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start or run the engine while your vehicle is supported by the jack.
- Do not raise the vehicle while someone is in it.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- With electronically modulated air suspension: Be sure to turn off the height control and stop the engine.

Take particular care when lowering the vehicle to ensure that no one working on or near the vehicle may be injured.

### CAUTION

#### ■ Replacing a flat tire

Observe the following precautions to reduce the risk of death or serious injury:

- Never use oil or grease on the wheel bolts or wheel nuts.

Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.

- Have the wheel nuts tightened with a torque wrench to 103.3 ft•lbf (140 N•m, 14.3 kgf•m) as soon as possible after changing wheels.

Failure to follow these precautions could cause the nuts to loosen and the wheel may fall off, which could lead to an accident causing death or serious injury.

### NOTICE

#### ■ Do not drive the vehicle with a flat tire.

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

#### ■ When closing the trunk

Do not leave the luggage mat hook hooked on the edge of the trunk.

The luggage mat may get damaged.

#### ■ When replacing the tires

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Lexus dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

#### ■ To avoid damaging the tire pressure warning valves and transmitters

Do not use liquid sealants on flat tires.

## 5-2. Steps to take in an emergency

### If the engine will not start

If the engine will not start even though correct starting procedures are being followed (→P. 161), consider each of the following points.

■ **The engine will not start, even when the starter motor operates normally.**

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.

Refuel the vehicle.

- The engine may be flooded.

Try to restart the engine once more following correct starting procedures. (→P. 161)

- There may be a malfunction in the engine immobilizer system.

(→P. 112)

■ **The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.**

One of the following may be the cause of the problem:

- The battery may be discharged. (→P. 732)

- The battery terminal connections may be loose or corroded.

■ **The starter motor does not turn over.**

The following may be the cause of the problem:

- The engine starting system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, an interim measure is available to start the engine. (→P. 724)

- **The starter motor does not turn over, the interior lights and head-lights do not turn on, or the horn does not sound.**

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged. (→P. 732)
- There may be a malfunction in the steering lock system.

Contact your Lexus dealer if the problem cannot be repaired, or if repair procedures are unknown.

### Emergency start function

When the engine does not start, the following steps can be used as an interim measure to start the engine if the “ENGINE START STOP” switch is functioning normally:

**STEP 1** Set the parking brake.

**STEP 2** Shift the shift lever to “P”.

**STEP 3** Set the “ENGINE START STOP” switch to ACCESSORY mode.

**STEP 4** Press and hold the “ENGINE START STOP” switch about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle checked by your Lexus dealer.

## 5-2. Steps to take in an emergency

### If the shift lever cannot be shifted from “P”


If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Lexus dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted:

**STEP 1** Set the parking brake.

**STEP 2** Turn the “ENGINE START STOP” switch to ACCESSORY mode.

**STEP 3** Depress the brake pedal.



Pry the cover up with a flathead screwdriver or equivalent.



Press the shift lock override button.

The shift lever can be shifted while the button is pressed.

## 5-2. Steps to take in an emergency

### If the parking brake cannot be released

In the event that the battery is discharged or switch operation does not release the parking brake, the parking brake can be released manually using the procedure below. This procedure should be performed only if necessary, such as in an emergency.


If the switch cannot be operated even when the battery is normal, the parking brake system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

#### ■ Before releasing the parking brake manually

- Shift the shift lever to "P".
- Turn the "ENGINE START STOP" switch OFF.
- Check that the parking brake indicator is off.
- Chock the tires.

#### Releasing the parking brake manually


##### STEP 1



Take out the parking brake release tool and the screwdriver from the trunk. (→P. 715)

Install the parking brake release tool into the screwdriver handle.

##### STEP 2 Take out the spare tire. (→P. 715)



Remove the plug.



Insert the tool and press it down firmly while turning it counter-clockwise until it stops.

#### ■ Manual operation of the parking brake

The parking brake cannot be set manually.

#### ⚠ CAUTION

##### ■ When releasing the parking brake manually

- Shift the shift lever to "P", turn the "ENGINE START STOP" switch OFF and chock the tires.  
Failure to do so may cause the vehicle to move, resulting in an accident.
- Turn the "ENGINE START STOP" switch OFF and check that the parking brake indicator is off.  
Failure to do so may cause the system to operate and turn the parking brake release tool that is inserted, resulting in an injury.

## 5-2. Steps to take in an emergency

### If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted (→P. 41) or the electronic key cannot be used because the battery is depleted, the smart access system with push-button start and wireless remote control cannot be used. In such cases, the doors and trunk can be opened or the engine can be started by following the procedure below.

#### Locking and unlocking the doors, unlocking the trunk and key linked functions

##### ► Doors



Remove the cover on the driver's door handle using the mechanical key (→P. 33) in order to perform the following operations.

- 1** Locks all doors
- 2** Closes the windows (turn and hold)

The moon roof will also close.

- 3** Unlocks the door

Turning the key rearward unlocks the driver's door. Turning the key once again unlocks the other doors.

- 4** Opens the windows (turn and hold)

The moon roof will also open.

Return the cover to the original position after use.



► Trunk



Turn the mechanical key clockwise to open.

### Changing “ENGINE START STOP” switch modes and starting the engine

**STEP 1** Shift the shift lever to “P” and apply the brakes.



Touch the Lexus emblem side of the electronic key to the “ENGINE START STOP” switch.

If any of the doors is opened or closed after the key was touched to the switch to start the vehicle, an alarm will sound to indicate that the start function cannot detect the key.



**STEP 3** To change “ENGINE START STOP” switch modes: Within 5 seconds of the buzzer sounding, release the brake pedal and press the “ENGINE START STOP” switch. Modes can be changed each time the switch is pressed. (→P.162)

To start the engine: Press the “ENGINE START STOP” switch within 10 seconds [after the buzzer sounds], keeping the brake pedal depressed.

In the event that the engine still cannot be started, contact your Lexus dealer.

---

### ■ Stopping the engine

Shift the shift lever to "P" and press the "ENGINE START STOP" switch as you normally do when stopping the engine.

### ■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted.  
(→P. 671)

## 5-2. Steps to take in an emergency

### If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can call your Lexus dealer or qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Lexus following the steps below.

**STEP 1** Remove the engine compartment covers and battery cover.  
(→P. 640)

**STEP 2**



Connect the jumper cables.

- 1** Positive (+) battery terminal on your vehicle
- 2** Positive (+) battery terminal on the second vehicle
- 3** Negative (-) battery terminal on the second vehicle
- 4** Connect the jumper cable to ground on your vehicle as shown in the illustration.

**STEP 3** Start the engine of the second vehicle. Increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery of your vehicle.

**STEP 4** Open and close any of the doors with the “ENGINE START STOP” switch OFF.

**STEP 5** Maintain the engine speed of the second vehicle and turn the “ENGINE START STOP” switch to IGNITION ON mode, then start the engine.

**STEP 6** Once the engine has started, remove the jumper cables in the exact reverse order in which they were connected.

Once the engine starts, have the vehicle inspected at your Lexus dealer as soon as possible.

---

#### ■ Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

#### ■ To prevent battery discharge

- Turn off the headlights and the audio system while the engine is turned off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

### CAUTION

#### ■ Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery:

- Make sure the jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any part other than the intended terminal.
- Do not allow the jumper cables to come into contact with the “+” and “-” terminals.
- Do not allow open flame or use matches, cigarette lighters or smoke near the battery.

#### ■ Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.  
Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.

### NOTICE

#### ■ When handling jumper cables

Be careful that the jumper cables do not become tangled in the cooling fan or belt when connecting or disconnecting the cables.

## 5-2. Steps to take in an emergency If your vehicle overheats

If your engine overheats:

**STEP 1** Stop the vehicle in a safe place and turn off the air conditioning system.

**STEP 2** Check to see if steam is coming out from the engine area.

If you see steam:

Stop the engine. Carefully lift the hood after the steam subsides and then restart the engine.

If you do not see steam:

Leave the engine running and carefully lift the hood.

**STEP 3** Remove the engine compartment cover. (→P. 640)


**STEP 4** Check if the cooling fan is operating.

If the fans are operating:

Wait until the temperature of the engine (shown on the instrument cluster) begins to fall and then stop the engine.

If the fans are not operating:

Stop the engine immediately and call your local Lexus dealer.



After the engine has cooled down, check the engine coolant level and inspect the cooling system for leaks.

## 5-2. Steps to take in an emergency

STEP 6



Add engine coolant if necessary.

Water can be used in an emergency if engine coolant is unavailable. (→P. 745)

Have the vehicle inspected at your nearest Lexus dealer as soon as possible.

### ■ Overheating

The following symptoms may occur when your vehicle is overheating:

- The engine coolant temperature gauge enters the red zone or a loss of power is experienced.
- Steam is coming from the engine area.

 **CAUTION****■ To prevent an accident or injury when inspecting under the hood of your vehicle**

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot, causing serious injury such as burns.
- Keep hands and clothing away from the fan and other belts while the engine is running.
- Do not loosen the coolant reservoir cap while the engine and radiator are hot. Serious injury, such as burns, may result from hot coolant and steam released under pressure.

 **NOTICE****■ When adding engine coolant**

Wait until the engine has cooled down before adding engine coolant. When adding coolant, do so slowly. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

## 5-2. Steps to take in an emergency

### If the vehicle becomes stuck

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt, or snow:

**STEP 1** Stop the engine. Set the parking brake and put the shift lever in "P".

**STEP 2** Remove the mud, snow, or sand from around the stuck tire.

**STEP 3** Place wood, stones or some other material to help provide traction under the tires.

**STEP 4** Restart the engine.

**STEP 5** Shift the shift lever to the "D" or "R" position and carefully apply the accelerator to free the vehicle.

Turn off TRAC/VSC if these functions are hampering your attempts to free the vehicle. (→ P. 287)

#### CAUTION

##### ■ When attempting to free a stuck vehicle

If you choose to rock the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or persons. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

##### ■ When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

#### NOTICE

##### ■ To avoid damaging the transmission and other components

- Avoid spinning the wheels and do not rev the engine.
- If the vehicle remains stuck after trying these procedures, the vehicle may require towing to be freed.

6-1. Specifications

Maintenance data  
    (fuel, oil level, etc.) ..... 740

Fuel information ..... 752

Tire information..... 755

6-2. Customization

Customizable features ..... 766

6-1. Specifications

Maintenance data (fuel, oil level, etc.)

Dimensions and weights


|                                               |       |            |                                              |
|-----------------------------------------------|-------|------------|----------------------------------------------|
| Overall length                                |       | LS460      | 199.2 in. (5060 mm)                          |
|                                               |       | LS460L     | 203.9 in. (5180 mm)                          |
| Overall width                                 |       |            | 73.8 in. (1875 mm)                           |
| Overall height *1                             |       | 2WD models | 58.1 in. (1475 mm)*2<br>57.7 in. (1465 mm)*3 |
|                                               |       | AWD models | 58.1 in. (1475 mm)                           |
| Wheelbase                                     |       | LS460      | 116.9 in. (2970 mm)                          |
|                                               |       | LS460L     | 121.7 in. (3090 mm)                          |
| Tread                                         | Front | 2WD models | 63.6 in. (1615 mm)*4<br>63.4 in. (1610 mm)*5 |
|                                               |       | AWD models | 63.6 in. (1615 mm)                           |
|                                               | Rear  | 2WD models | 63.8 in. (1620 mm)*4<br>63.6 in. (1615 mm)*5 |
|                                               |       | AWD models | 63.6 in. (1615 mm)                           |
| Vehicle capacity weight (Occupants + luggage) |       |            | 825 lb. (375 kg)*6<br>675 lb. (305 kg)*7     |

- \*1: Unladen vehicles
- \*2: Vehicles without electronically modulated air suspension
- \*3: Vehicles with electronically modulated air suspension
- \*4: Vehicles with 18-inch tires
- \*5: Vehicles with 19-inch tires
- \*6: 5-seat models
- \*7: 4-seat models

## Vehicle identification

### ■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Lexus. It is used in registering the ownership of your vehicle.




This number is stamped on the top left of the instrument panel and in the engine compartment.



This number is also on the Certification Label.

■ Engine number

▶ 2WD models



The engine number is stamped on the engine block as shown.

▶ AWD models



The engine number is stamped on the engine block as shown.

Engine

|                    |                                         |
|--------------------|-----------------------------------------|
| Model              | 1UR-FSE                                 |
| Type               | 8-cylinder V type,<br>4-cycle, gasoline |
| Bore and stroke    | 3.70 × 3.27 in.<br>(94.0 × 83.0 mm)     |
| Displacement       | 281.2 cu.in.<br>(4608 cm <sup>3</sup> ) |
| Drive belt tension | Automatic adjustment                    |

Fuel

|                    |                                          |
|--------------------|------------------------------------------|
| Fuel type          | Unleaded gasoline only                   |
| Octane rating      | 91 (Research octane number 96) or higher |
| Fuel tank capacity | 22.1 gal. (84 L, 18.4 Imp. gal.)         |

Lubrication system


|                                                   |                               |
|---------------------------------------------------|-------------------------------|
| Oil capacity<br>(drain and refill)<br>with filter |                               |
| 2WD models                                        | 9.1 qt. (8.6 L, 7.6 Imp. qt.) |
| AWD models                                        | 9.5 qt. (9.0 L, 7.9 Imp. qt.) |
| without filter                                    | 8.9 qt. (8.4 L, 7.4 Imp. qt.) |

Engine oil selection

“Toyota Genuine Motor Oil” is used in your Lexus vehicle. Use Lexus approved “Toyota Genuine Motor Oil” or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC multigrade engine oil

Recommended viscosity: SAE 5W-20 or 0W-20



SAE 5W-20 or 0W-20 engine oil may be used. However, SAE 0W-20 is the best choice for good fuel economy and good starting in cold weather.

The 0W portion of the oil viscosity rating indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.

The 20 in 0W-20 indicates the oil viscosity when the oil is at its operating temperature. An oil with a higher viscosity may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container label:

The ILSAC (International Lubricant Standardization and Approval Committee) Certification Mark is added to some oil containers to help you select the oil you should use.



Cooling system

|              |            |                                                                                                                                                                                                                                                                                                               |
|--------------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Capacity     | 2WD models | 11.6 qt. (11.0 L, 9.7 Imp. qt.)                                                                                                                                                                                                                                                                               |
|              | AWD models | 11.7 qt. (11.1 L, 9.8 Imp. qt.)                                                                                                                                                                                                                                                                               |
| Coolant type |            | Use either of the following. <ul style="list-style-type: none"><li>• “Toyota Super Long Life Coolant”</li><li>• Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology</li></ul> Do not use plain water alone. |

Ignition system

|            |                    |
|------------|--------------------|
| Spark plug |                    |
| Make       | DENSO FK20HBR11    |
| Gap        | 0.043 in. (1.1 mm) |

 NOTICE

 **Iridium-tipped spark plugs**  
Use only iridium-tipped spark plugs. Do not adjust spark plug gap.

Electrical system

|                               |                                                                                                                                                                             |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Battery                       |                                                                                                                                                                             |
| Open voltage* at 68°F (20°C): | 12.6 — 12.8 V Fully charged<br>12.2 — 12.4 V Half charged<br>11.8 — 12.0 V Discharged<br>(*: Voltage checked 20 minutes after the engine and all the lights are turned off) |
| Charging rates                | 5A max.                                                                                                                                                                     |

Transfer (AWD models)

|                         |                                                                   |
|-------------------------|-------------------------------------------------------------------|
| Oil capacity            | 0.74 qt. (0.70 L, 0.62 Imp. qt.)                                  |
| Oil type and viscosity* | Toyota Genuine Differential gear oil LX 75W-85 GL-5 or equivalent |

\*: “Toyota Genuine Differential Gear Oil” is filled in your Lexus vehicle at factory fill. Use Lexus approved “Toyota Genuine Differential Gear Oil” or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

### Front differential (AWD models)

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| Oil capacity            | 0.79 qt. (0.75 L, 0.66 Imp. qt.)                                     |
| Oil type and viscosity* | Toyota Genuine Differential gear oil LT<br>75W-85 GL-5 or equivalent |

\*: “Toyota Genuine Differential Gear Oil” is filled in your Lexus vehicle at factory fill. Use Lexus approved “Toyota Genuine Differential Gear Oil” or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

### Rear differential

#### ► 2WD models

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| Oil capacity            | 1.42 qt. (1.35 L, 1.19 Imp. qt.)                                     |
| Oil type and viscosity* | Toyota Genuine Differential gear oil LT<br>75W-85 GL-5 or equivalent |

#### ► AWD models

|                         |                                                                      |
|-------------------------|----------------------------------------------------------------------|
| Oil capacity            | 1.42 qt. (1.35 L, 1.19 Imp. qt.)                                     |
| Oil type and viscosity* | Toyota Genuine Differential gear oil LX<br>75W-85 GL-5 or equivalent |

\*: “Toyota Genuine Differential Gear Oil” is filled in your Lexus vehicle at factory fill. Use Lexus approved “Toyota Genuine Differential Gear Oil” or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

Automatic Transmission

|                 |            |                                 |
|-----------------|------------|---------------------------------|
| Fluid capacity* | 2WD models | 10.9 qt. (10.3 L, 9.1 Imp. qt.) |
|                 | AWD models | 11.3 qt. (10.7 L, 9.4 Imp. qt.) |
| Fluid type      |            | Toyota Genuine ATF WS           |

\*: The fluid capacity is a reference quantity. If replacement is necessary, contact your Lexus dealer.

 NOTICE

Automatic transmission fluid type

Using automatic transmission fluid other than “Toyota Genuine ATF WS” may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the automatic transmission of your vehicle.

Brakes

|                                 |                                 |
|---------------------------------|---------------------------------|
| Pedal clearance*                | 3.7 in. (95.0 mm) Min.          |
| Pedal free play                 | 0.04 — 0.08 in. (1.0 — 2.0 mm)  |
| Brake pad wear limit            | 0.04 in. (1.0 mm)               |
| Parking brake lining wear limit | 0.04 in. (1.0 mm)               |
| Fluid type                      | SAE J1703 or FMVSS No.116 DOT 3 |

\*: Minimum pedal clearance when depressed with a force of 50 lbf (200 N, 20 kgf).

Steering

|           |                           |
|-----------|---------------------------|
| Free play | Less than 1.2 in. (30 mm) |
|-----------|---------------------------|

Tires and wheels

► 18-inch tires (type A)

|                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tire size                                                                | 235/50R18 97W                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Tire inflation pressure<br>(Recommended cold tire<br>inflation pressure) | Driving under normal conditions<br>Front: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Rear: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Spare: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Driving at high speeds above 100 mph (160 km/h) (in<br>countries where such speeds are permitted by law)<br>Add 8 psi (50 kPa, 0.5 kgf/cm <sup>2</sup> or bar) to the front<br>tires, 11 psi (70 kPa, 0.7 kgf/cm <sup>2</sup> or bar) to the rear<br>tires. Never exceed the maximum cold tire inflation<br>pressure indicated on the tire sidewall. |
| Wheel size                                                               | 18 × 7 1/2J                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Wheel nut torque                                                         | 103.3 ft•lbf (140 N•m, 14.3 kgf•m)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

► 18-inch tires (type B)

|                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tire size                                                                | P235/50R18 97V                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Tire inflation pressure<br>(Recommended cold tire<br>inflation pressure) | Driving under normal conditions<br>Front: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Rear: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Spare: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Driving at high speeds above 100 mph (160 km/h) (in<br>countries where such speeds are permitted by law)<br>Add 5 psi (30 kPa, 0.3 kgf/cm <sup>2</sup> or bar) to the front<br>tires, 11 psi (70 kPa, 0.7 kgf/cm <sup>2</sup> or bar) to the rear<br>tires. Never exceed the maximum cold tire inflation<br>pressure indicated on the tire sidewall. |
| Wheel size                                                               | 18 × 7 1/2J                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Wheel nut torque                                                         | 103.3 ft•lbf (140 N•m, 14.3 kgf•m)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

► 19-inch tires (type A)

|                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tire size                                                                | 245/45R19 98Y                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Tire inflation pressure<br>(Recommended cold tire<br>inflation pressure) | Driving under normal conditions<br>Front: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Rear: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Spare: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Driving at high speeds above 100 mph (160 km/h) (in<br>countries where such speeds are permitted by law)<br>Add 9 psi (60 kPa, 0.6 kgf/cm <sup>2</sup> or bar) to the front<br>tires, 11 psi (70 kPa, 0.7 kgf/cm <sup>2</sup> or bar) to the rear<br>tires. Never exceed the maximum cold tire inflation<br>pressure indicated on the tire sidewall. |
| Wheel size                                                               | 19 × 8J                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Wheel nut torque                                                         | 103.3 ft•lbf (140 N•m, 14.3 kgf•m)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

► 19-inch tires (type B)

|                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tire size                                                                | P245/45R19 98V                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Tire inflation pressure<br>(Recommended cold tire<br>inflation pressure) | Driving under normal conditions<br>Front: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Rear: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Spare: 33 psi (230 kPa, 2.3 kgf/cm <sup>2</sup> or bar)<br>Driving at high speeds above 100 mph (160 km/h) (in<br>countries where such speeds are permitted by law)<br>Add 8 psi (50 kPa, 0.5 kgf/cm <sup>2</sup> or bar) to the front<br>tires and rear tires. Never exceed the maximum cold<br>tire inflation pressure indicated on the tire sidewall. |
| Wheel size                                                               | 19 × 8J                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Wheel nut torque                                                         | 103.3 ft•lbf (140 N•m, 14.3 kgf•m)                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

Light bulbs

|          | Light Bulbs                                                | Bulb No. | W   | Type |
|----------|------------------------------------------------------------|----------|-----|------|
| Exterior | Headlights                                                 |          |     |      |
|          | High beam                                                  | 9005     | 60  | A    |
|          | Low or low/high beam                                       | —        | 35  | B    |
|          | Front turn signal lights                                   | —        | 21  | D    |
|          | Front fog lights                                           | 9006     | 51  | E    |
|          | Trunk lid light                                            | 194      | 3.8 | F    |
|          | Trunk light                                                | —        | 3.8 | C    |
|          | Rear turn signal lights                                    | 7440     | 21  | C    |
| Interior | Back-up lights                                             | 921      | 16  | C    |
|          | Outer foot lights                                          | —        | 5   | C    |
|          | Vanity lights                                              |          |     |      |
|          | Front                                                      | —        | 8   | C    |
|          | Rear                                                       | —        | 3   | F    |
|          | Interior lights                                            |          |     |      |
|          | Front                                                      | —        | 8   | C    |
|          | Rear                                                       | —        | 8   | F    |
|          | Rear personal lights (with rear seat entertainment system) | —        | 10  | G    |
|          | Door courtesy lights                                       | —        | 5   | C    |

- A: HB3 halogen bulbs  
B: D4S discharge bulbs  
C: Wedge base bulbs (clear)  
D: Wedge base bulbs (amber)  
E: HB4 halogen bulbs  
F: Double end bulbs  
G: Single end bulbs

## 6-1. Specifications

### Fuel information

Your vehicle must use only unleaded gasoline.

Premium unleaded gasoline with an octane rating of 91 (Research Octane Number 96) or higher required for optimum engine performance. If 91 octane cannot be obtained, you may use unleaded gasoline with an octane rating as low as 87 (Research Octane Number 91). Use of unleaded gasoline with an octane rating lower than 91 may result in engine knocking and significantly reduced performance. Persistent knocking can lead to engine damage and should be corrected by refueling with higher octane unleaded gasoline.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A. and CGSB3.5-M93 in Canada.

---

#### ■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your Lexus has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

#### ■ If your engine knocks

- Consult your Lexus dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

#### ■ Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Lexus dealer.

### ■ Gasoline quality standards

- Automotive manufacturers in the US, Europe and Japan have developed a specification for fuel quality called World-Wide Fuel Charter (WWFC) that is expected to be applied worldwide.
- The WWFC consists of four categories that are based on required emission levels. In the US, category 4 has been adopted.
- The WWFC improves air quality by lowering emissions in vehicle fleets, and customer satisfaction through better performance.

### ■ Lexus recommends the use of gasoline containing detergent additives

- Lexus recommends the use of gasoline that contains detergent additives to avoid build-up of engine deposits.
- All gasoline sold in the US contains detergent additives to clean and/or keep clean intake systems.

### ■ Lexus recommends the use of cleaner burning gasoline

Cleaner burning gasoline, including reformulated gasoline that contains oxygenates such as ethanol or MTBE (Methyl Tertiary Butyl Ether) is available in many areas.

Lexus recommends the use of cleaner burning gasoline and appropriately blended reformulated gasoline. These types of gasoline provide excellent vehicle performance, reduce vehicle emissions and improve air quality.

### ■ Lexus does not recommend blended gasoline

- Lexus allows the use of oxygenate blended gasoline where the oxygenate content is up to 10% ethanol or 15% MTBE.
- If you use gasohol in your Lexus, be sure that it has an octane rating no lower than 87.
- Lexus DOES NOT recommend the use of gasoline containing methanol.

### ■ Lexus does not recommend gasoline containing MMT

Some gasoline contains octane enhancing additive called MMT (Methylcyclopentadienyl Manganese Tricarbonyl).

Lexus DOES NOT recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Lexus dealer for service.

### NOTICE

#### ■ Notice on fuel quality

- Do not use improper fuels. If improper fuels are used the engine will be damaged.
- Do not use leaded gasoline.  
Leaded gasoline can cause damage to your vehicle's three-way catalytic converters causing the emission control system to malfunction.
- Do not use gasohol other than that stated here.  
Other gasohol may cause fuel system damage or vehicle performance problems.
- Using unleaded gasoline with an octane number or rating lower than that stated here will cause persistent heavy knocking.  
At worst, this will lead to engine damage.

#### ■ Fuel-related poor driveability

If after using a different type of fuel, poor driveability is encountered (poor hot starting, vaporization, engine knocking, etc.), discontinue the use of that type of fuel.

#### ■ When refueling with gasohol


Take care not to spill gasohol. It can damage your vehicle's paint.



**10** Summer tire or all season tire (→P. 658)

An all season tire has “M+S” on the sidewall. A tire not marked “M+S” is a summer tire.

**Typical DOT and tire identification number (TIN)**




- 1** DOT symbol\*
- 2** Tire Identification Number (TIN)
- 3** Tire manufacturer's identification mark
- 4** Tire size code
- 5** Manufacturer's optional tire type code (3 or 4 letters)
- 6** Manufacturing week
- 7** Manufacturing year

\*:The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

## Tire size


### Typical tire size information



The illustration indicates typical tire size.


- 1 Tire use  
(P = Passenger car,  
T = Temporary use)
- 2 Section width (millimeters)
- 3 Aspect ratio  
(tire height to section width)
- 4 Tire construction code  
(R = Radial, D = Diagonal)
- 5 Wheel diameter (inches)
- 6 Load index (2 digits or 3 digits)
- 7 Speed symbol  
(alphabet with one letter)

### Tire dimensions



- 1 Section width
- 2 Tire height
- 3 Wheel diameter

### Tire section names



- 1 Bead
- 2 Sidewall
- 3 Shoulder
- 4 Tread
- 5 Belt
- 6 Inner liner
- 7 Reinforcing rubber
- 8 Carcass
- 9 Rim lines
- 10 Bead wires
- 11 Chafer

### Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S.A. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Lexus vehicles with information on uniform tire quality grading.

Your Lexus dealer will help answer any questions you may have as you read this information.

#### ■ DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

## ■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

## ■ Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

## ■ Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades for this tire are established for a tire that is properly inflated and not overloaded.  
Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Glossary of tire terminology

| Tire related term              | Meaning                                                                                                                                                                                                                                                                                     |
|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cold tire inflation pressure   | Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition                                                                                                                                              |
| Maximum inflation pressure     | The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire                                                                                                                                                                                       |
| Recommended inflation pressure | Cold tire inflation pressure recommended by a manufacturer                                                                                                                                                                                                                                  |
| Accessory weight               | The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not) |
| Curb weight                    | The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine                                                                                                  |
| Maximum loaded vehicle weight  | The sum of:<br>(a) Curb weight<br>(b) Accessory weight<br>(c) Vehicle capacity weight<br>(d) Production options weight                                                                                                                                                                      |
| Normal occupant weight         | 150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows                                                                                                                                                                                       |

| Tire related term                             | Meaning                                                                                                                                                                                                                                                                                                |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Occupant distribution                         | Distribution of occupants in a vehicle as specified in the third column of Table 1* below                                                                                                                                                                                                              |
| Production options weight                     | The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim |
| Rim                                           | A metal support for a tire or a tire and tube assembly upon which the tire beads are seated                                                                                                                                                                                                            |
| Rim diameter (Wheel diameter)                 | Nominal diameter of the bead seat                                                                                                                                                                                                                                                                      |
| Rim size designation                          | Rim diameter and width                                                                                                                                                                                                                                                                                 |
| Rim type designation                          | The industry manufacturer's designation for a rim by style or code                                                                                                                                                                                                                                     |
| Rim width                                     | Nominal distance between rim flanges                                                                                                                                                                                                                                                                   |
| Vehicle capacity weight (Total load capacity) | The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity                                                                                                                                                                                                  |
| Vehicle maximum load on the tire              | The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two                                                                                                                                                     |
| Vehicle normal load on the tire               | The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two                                                                             |
| Weather side                                  | The surface area of the rim not covered by the inflated tire                                                                                                                                                                                                                                           |

| Tire related term     | Meaning                                                                                                                                                                                                                                                                    |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bead                  | The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim                                                                                                                                                     |
| Bead separation       | A breakdown of the bond between components in the bead                                                                                                                                                                                                                     |
| Bias ply tire         | A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread                                                                                                            |
| Carcass               | The tire structure, except tread and sidewall rubber which, when inflated, bears the load                                                                                                                                                                                  |
| Chunking              | The breaking away of pieces of the tread or sidewall                                                                                                                                                                                                                       |
| Cord                  | The strands forming the plies in the tire                                                                                                                                                                                                                                  |
| Cord separation       | The parting of cords from adjacent rubber compounds                                                                                                                                                                                                                        |
| Cracking              | Any parting within the tread, sidewall, or innerliner of the tire extending to cord material                                                                                                                                                                               |
| CT                    | A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire |
| Extra load tire       | A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire                                                                                                                                                          |
| Groove                | The space between two adjacent tread ribs                                                                                                                                                                                                                                  |
| Innerliner            | The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire                                                                                                                                                              |
| Innerliner separation | The parting of the innerliner from cord material in the carcass                                                                                                                                                                                                            |

| Tire related term                      | Meaning                                                                                                                                                                                                                                                                                                                                                       |
|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Intended outboard sidewall             | (a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or<br>(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle |
| Light truck (LT) tire                  | A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles                                                                                                                                                                                                                                  |
| Load rating                            | The maximum load that a tire is rated to carry for a given inflation pressure                                                                                                                                                                                                                                                                                 |
| Maximum load rating                    | The load rating for a tire at the maximum permissible inflation pressure for that tire                                                                                                                                                                                                                                                                        |
| Maximum permissible inflation pressure | The maximum cold inflation pressure to which a tire may be inflated                                                                                                                                                                                                                                                                                           |
| Measuring rim                          | The rim on which a tire is fitted for physical dimension requirements                                                                                                                                                                                                                                                                                         |
| Open splice                            | Any parting at any junction of tread, sidewall, or innerliner that extends to cord material                                                                                                                                                                                                                                                                   |
| Outer diameter                         | The overall diameter of an inflated new tire                                                                                                                                                                                                                                                                                                                  |
| Overall width                          | The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs                                                                                                                                                                                                |
| Passenger car tire                     | A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.                                                                                                                                                                                                 |
| Ply                                    | A layer of rubber-coated parallel cords                                                                                                                                                                                                                                                                                                                       |

| Tire related term   | Meaning                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ply separation      | A parting of rubber compound between adjacent plies                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Pneumatic tire      | A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load                                                                                                                                                                                                                                                             |
| Radial ply tire     | A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread                                                                                                                                                                                                                                                                                                                                  |
| Reinforced tire     | A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire                                                                                                                                                                                                                                                                                                                                                     |
| Section width       | The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands                                                                                                                                                                                                                                                                                                                 |
| Sidewall            | That portion of a tire between the tread and bead                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Sidewall separation | The parting of the rubber compound from the cord material in the sidewall                                                                                                                                                                                                                                                                                                                                                                                             |
| Snow tire           | A tire that attains a traction index equal to or greater than 110, compared to the ASTM E-1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol (  ) on at least one sidewall |
| Test rim            | The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire                                                                                                                                                                                                                                                                                                                                                        |

| Tire related term          | Meaning                                                                                                               |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Tread                      | That portion of a tire that comes into contact with the road                                                          |
| Tread rib                  | A tread section running circumferentially around a tire                                                               |
| Tread separation           | Pulling away of the tread from the tire carcass                                                                       |
| Treadwear indicators (TWI) | The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread |
| Wheel-holding fixture      | The fixture used to hold the wheel and tire assembly securely during testing                                          |

\*: Table 1 — Occupant loading and distribution for vehicle normal load for various designated seating capacities

| Designated seating capacity, Number of occupants | Vehicle normal load, Number of occupants | Occupant distribution in a normally loaded vehicle              |
|--------------------------------------------------|------------------------------------------|-----------------------------------------------------------------|
| 2 through 4                                      | 2                                        | 2 in front                                                      |
| 5 through 10                                     | 3                                        | 2 in front, 1 in second seat                                    |
| 11 through 15                                    | 5                                        | 2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat |
| 16 through 20                                    | 7                                        | 2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat |

6-2. Customization

Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

It is also possible to customize certain vehicle features yourself using the navigation screen.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Settings that can be customized at a dealer

The following table includes some settings that can be customized using the navigation system display. (→P. 772)

| Item                                                | Function                                   | Default setting                                                     | Customized setting             |
|-----------------------------------------------------|--------------------------------------------|---------------------------------------------------------------------|--------------------------------|
| Smart access system with push-button start (→P. 36) | Smart access system with push-button start | On                                                                  | Off                            |
|                                                     | Door unlock function                       | Driver's door                                                       | All the doors                  |
|                                                     |                                            |                                                                     | Each door                      |
|                                                     |                                            |                                                                     | Same side doors                |
| Wireless remote control (→P. 50)                    | Wireless remote control                    | On                                                                  | Off                            |
|                                                     | Unlocking operation                        | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |

| Item                                                                                | Function                                                                                            | Default setting | Customized setting |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|-----------------|--------------------|
| Wireless remote control (→P. 50)                                                    | Time elapsed before automatic lock function is activated if door is not opened after being unlocked | 60 seconds      | Off                |
|                                                                                     |                                                                                                     |                 | 30 seconds         |
|                                                                                     |                                                                                                     |                 | 120 seconds        |
|                                                                                     | Operational signal (Emergency flashers)                                                             | On              | Off                |
|                                                                                     | Trunk unlocking operation                                                                           | Push and hold   | Push twice         |
|                                                                                     |                                                                                                     |                 | One short push     |
|                                                                                     | Alarm (panic mode)                                                                                  | On              | Off                |
| Smart access system with push-button start and wireless remote control (→P. 36, 50) | Operation signal (Emergency flashers)                                                               | On              | Off                |
|                                                                                     | Open door warning buzzer                                                                            | On              | Off                |
| Door lock (→P. 53, 728)                                                             | Speed-detecting automatic door lock function                                                        | Off             | On                 |
|                                                                                     | Opening driver's door unlocks all doors.                                                            | Off             | On                 |
|                                                                                     | Shifting gears to "P" unlocks all doors.                                                            | On              | Off                |

| Item                                 | Function                                                                                                 | Default setting                                                     | Customized setting             |
|--------------------------------------|----------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|--------------------------------|
| Door lock<br>(→P. 53, 728)           | Shifting gears to position other than “P” locks all doors.                                               | On                                                                  | Off                            |
|                                      | Unlocking using a mechanical key                                                                         | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| Trunk<br>(→P. 58)                    | Power trunk opener and closer function                                                                   | On                                                                  | Off                            |
| Power easy access system<br>(→P. 81) | Driver's seat movement when exiting the vehicle                                                          | Full                                                                | Off<br>Partial                 |
|                                      | Steering wheel auto away and return function                                                             | On                                                                  | Off                            |
| Power windows<br>(→P. 103)           | One-touch close operation using the power window switches on the front passenger door and each rear door | On                                                                  | Off                            |

| Item                       | Function                                                                                                           | Default setting | Customized setting |
|----------------------------|--------------------------------------------------------------------------------------------------------------------|-----------------|--------------------|
| Power windows<br>(→P. 103) | One-touch front passenger window or rear window close operation using the power window switch on the driver's door | On              | Off                |
|                            | Mechanical key linked operation                                                                                    | Open and close  | Off                |
|                            |                                                                                                                    |                 | Open only          |
|                            |                                                                                                                    |                 | Close only         |
|                            | Wireless remote control linked operation                                                                           | Off             | On                 |
|                            | Linked entry function                                                                                              | On              | Off                |
| Moon roof<br>(→P. 105)     | Mechanical key linked operation                                                                                    | Open and close  | Off                |
|                            |                                                                                                                    |                 | Open only          |
|                            |                                                                                                                    |                 | Close only         |
|                            | Linked operation of components when mechanical key is used                                                         | Slide only      | Tilt only          |
|                            | Wireless remote control linked operation                                                                           | Off             | On                 |
|                            | Linked operation of components when wireless remote control used                                                   | Slide only      | Tilt only          |
|                            | Linked entry function                                                                                              | On              | Off                |

| Item                                        | Function                                                                                  | Default setting | Customized setting |
|---------------------------------------------|-------------------------------------------------------------------------------------------|-----------------|--------------------|
| Turn signal lever<br>(→P. 176)              | Times of flashing of the lane change signal flashers                                      | 3               | Off                |
|                                             |                                                                                           |                 | 5                  |
|                                             |                                                                                           |                 | 7                  |
|                                             |                                                                                           |                 | 9                  |
|                                             |                                                                                           |                 | 11                 |
| Automatic light control system<br>(→P. 195) | Light sensor sensitivity                                                                  | Standard        | -2 to 2            |
|                                             | Time elapsed before headlights automatically turn off after doors are closed              | 30 seconds      | 0 second           |
|                                             |                                                                                           |                 | 60 seconds         |
|                                             |                                                                                           |                 | 90 seconds         |
|                                             | Automatic high beam system                                                                | On              | Off                |
| Air conditioning system<br>(→P. 328, 337)   | Switching between outside air and recirculated air mode linked to “AUTO” switch operation | Auto            | Manual             |
|                                             | A/C Auto switch operation                                                                 | Auto            | Manual             |
|                                             | Exhaust gas sensor sensitivity                                                            | Standard        | -3 to 3            |
| Lights<br>(→P. 195)                         | Daytime running light system (U.S.A. only)                                                | On              | Off                |
| Intuitive parking assist<br>(→P. 223)       | Buzzer volume                                                                             | Level 3         | Level 1 to 5       |
|                                             | Distance at which the front and back sensors detect an obstacle                           | Level 1         | Level 2            |

| Item                            | Function                                                                           | Default setting | Customized setting |
|---------------------------------|------------------------------------------------------------------------------------|-----------------|--------------------|
| Illumination<br>(→P. 552)       | Time elapsed before the interior lights turn off                                   | 15 seconds      | Off                |
|                                 |                                                                                    |                 | 7.5 seconds        |
|                                 |                                                                                    |                 | 30 seconds         |
|                                 | Time elapsed before the exterior lights turn off                                   | 15 seconds      | Off                |
|                                 |                                                                                    |                 | 7.5 seconds        |
|                                 |                                                                                    |                 | 30 seconds         |
|                                 | Sensitivity of the ambient light sensor used for dimming the meter lights etc.     | Standard        | -2 to 2            |
|                                 | Sensitivity of the ambient light sensor used for brightening the meter lights etc. | Standard        | -2 to 2            |
|                                 | Operation when the doors are unlocked                                              | On              | Off                |
|                                 | Operation after the “ENGINE START STOP” switch is turned OFF                       | On              | Off                |
| Seat belt reminder<br>(→P. 706) | Footwell lighting                                                                  | On              | Off                |
|                                 | Shift lever lighting                                                               | On              | Off                |
|                                 | Vehicle speed linked seat belt reminder buzzer                                     | On              | Off                |

**Settings that can be customized using the navigation system display**

You can customize the following settings using the navigation system display.

(For further information on customizing settings using the navigation system display, refer to the Navigation System Owner's Manual.)

| Item                                                | Function                                                                                            | Default setting                                                     | Customized setting             |
|-----------------------------------------------------|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|--------------------------------|
| Smart access system with push-button start (→P. 36) | Smart access system with push-button start                                                          | On                                                                  | Off                            |
|                                                     | Door unlock function                                                                                | Driver's door                                                       | All the doors                  |
|                                                     |                                                                                                     |                                                                     | Each door                      |
|                                                     |                                                                                                     |                                                                     | Same side doors                |
| Wireless remote control (→P. 50)                    | Unlocking operation                                                                                 | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
|                                                     | Time elapsed before automatic lock function is activated if door is not opened after being unlocked | 60 seconds                                                          | Off                            |
|                                                     |                                                                                                     |                                                                     | 30 seconds                     |
|                                                     |                                                                                                     |                                                                     | 120 seconds                    |

| Item                                                                                | Function                                                   | Default setting                                                     | Customized setting             |
|-------------------------------------------------------------------------------------|------------------------------------------------------------|---------------------------------------------------------------------|--------------------------------|
| Smart access system with push-button start and wireless remote control (→P. 36, 50) | Operation signal (Emergency flashers)                      | On                                                                  | Off                            |
| Door lock (→P. 53, 728)                                                             | Speed-detecting automatic door lock function               | Off                                                                 | On                             |
|                                                                                     | Opening driver's door unlocks all doors.                   | Off                                                                 | On                             |
|                                                                                     | Shifting gears to "P" unlocks all doors.                   | On                                                                  | Off                            |
|                                                                                     | Shifting gears to position other than "P" locks all doors. | On                                                                  | Off                            |
|                                                                                     | Unlocking using a mechanical key                           | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| Power easy access system (→P. 81)                                                   | Driver's seat movement when exiting the vehicle            | Full                                                                | Off                            |
|                                                                                     |                                                            |                                                                     | Partial                        |

| Item                                        | Function                                                                                  | Default setting | Customized setting |
|---------------------------------------------|-------------------------------------------------------------------------------------------|-----------------|--------------------|
| Turn signal lever<br>(→P. 176)              | Times of flashing of the lane change signal flashers                                      | 3               | Off                |
|                                             |                                                                                           |                 | 5                  |
|                                             |                                                                                           |                 | 7                  |
|                                             |                                                                                           |                 | 9                  |
|                                             |                                                                                           |                 | 11                 |
| Automatic light control system<br>(→P. 195) | Light sensor sensitivity                                                                  | Standard        | -2 to 2            |
|                                             | Time elapsed before headlights automatically turn off after doors are closed              | 30 seconds      | 0 second           |
|                                             |                                                                                           |                 | 60 seconds         |
|                                             |                                                                                           |                 | 90 seconds         |
| Air conditioning system<br>(→P. 328, 337)   | Switching between outside air and recirculated air mode linked to "AUTO" switch operation | Auto            | Manual             |
|                                             | A/C Auto switch operation                                                                 | Auto            | Manual             |
|                                             | Exhaust gas sensor sensitivity                                                            | Standard        | -3 to 3            |
| Lights<br>(→P. 195)                         | Daytime running light system (U.S.A. only)                                                | On              | Off                |

| Item                      | Function                                                                           | Default setting | Customized setting |
|---------------------------|------------------------------------------------------------------------------------|-----------------|--------------------|
| Illumination<br>(→P. 552) | Time elapsed before the interior lights turn off                                   | 15 seconds      | Off                |
|                           |                                                                                    |                 | 7.5 seconds        |
|                           |                                                                                    |                 | 30 seconds         |
|                           | Time elapsed before the exterior lights turn off                                   | 15 seconds      | Off                |
|                           |                                                                                    |                 | 7.5 seconds        |
|                           |                                                                                    |                 | 30 seconds         |
|                           | Sensitivity of the ambient light sensor used for dimming the meter lights etc.     | Standard        | -2 to 2            |
|                           | Sensitivity of the ambient light sensor used for brightening the meter lights etc. | Standard        | -2 to 2            |

Multi-information display (→P. 190)

| Country | Available languages                          |
|---------|----------------------------------------------|
| U.S.A.  | English and Spanish                          |
| Canada  | English, French, German, Spanish and Italian |



|                                                                    |     |
|--------------------------------------------------------------------|-----|
| Reporting safety defects<br>for U.S. owners.....                   | 778 |
| Seat belt instructions<br>for Canadian owners<br>(in French) ..... | 779 |

## Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying the Lexus Division of Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-25-LEXUS).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Lexus Division of Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

## Seat belt instructions for Canadian owners (in French)

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

### Utilisation correcte des ceintures de sécurité



- Déroulez la sangle diagonale de telle sorte qu'elle passe bien sur l'épaule, sans pour autant être en contact avec votre cou ou glisser de votre épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier de siège. Asseyez-vous le dos le plus droit possible et calez-vous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

### Guide de confort de ceinture de sécurité (sièges arrière extérieurs)



Si la sangle diagonale est proche du cou de la personne, faites coulisser le guide de confort de ceinture de sécurité vers l'avant.

## Entretien et soin

### ■ Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Profitez de l'occasion pour vérifier régulièrement que les ceintures ne sont pas effilochées, entaillées, ou ne paraissent pas exagérément usées.

### ATTENTION

#### ■ Détérioration et usure des ceintures de sécurité

Inspectez les ceintures de sécurité périodiquement. Contrôlez qu'elles ne sont pas entaillées, effilochées, et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité défectueuse n'apporte aucune garantie de protection de l'occupant en cas d'accident.

## Index

**Abbreviation list ..... 782**

**Alphabetical index ..... 784**

**What to do if... ..... 794**

For details of equipment related to the navigation system, such as the audio system and clock, refer to the "Navigation System Owner's Manual".

Abbreviation/Acronym list

| ABBREVIATIONS | MEANING                                      |
|---------------|----------------------------------------------|
| 2WD           | 2 Wheel Drive                                |
| A/C           | Air Conditioning                             |
| ABS           | Anti-lock Brake System                       |
| AFS           | Adaptive Front-lighting System               |
| AI-SHIFT      | Artificial Intelligence Shift control        |
| ALR           | Automatic Locking Retractor                  |
| APGS          | Advanced Parking Guidance System             |
| AWD           | All Wheel Drive                              |
| CRS           | Child Restraint System                       |
| DISP          | Display                                      |
| ECO           | Economy/Ecology                              |
| ECT           | Electronic Controlled Transmission           |
| ECU           | Electronic Control Unit                      |
| EDR           | Event Data Recorder                          |
| ELR           | Emergency Locking Retractor                  |
| EPS           | Electric Power Steering                      |
| GAWR          | Gross Axle Weight Ratings                    |
| GPS           | Global Positioning System                    |
| I/M           | Emission Inspection and Maintenance          |
| INFO          | Information                                  |
| LATCH         | Lower Anchors and Tethers for Children       |
| LED           | Light Emitting Diode                         |
| LKA           | Lane-Keeping Assist                          |
| MMT           | Methylcyclopentadienyl Manganese Tricarbonyl |
| M + S         | Mud and Snow                                 |

| ABBREVIATIONS | MEANING                                |
|---------------|----------------------------------------|
| MTBE          | Methyl Tertiary Butyl Ether            |
| OBD           | On Board Diagnostics                   |
| PCS           | Pre-Collision System                   |
| PWR           | Power                                  |
| RF            | Radio Frequency                        |
| SRS           | Supplemental Restraint System          |
| TIN           | Tire Identification Number             |
| TPMS          | Tire Pressure Warning System           |
| TRAC          | Traction Control                       |
| VDIM          | Vehicle Dynamics Integrated Management |
| VGRS          | Variable Gear Ratio Steering           |
| VIN           | Vehicle Identification Number          |
| VSC           | Vehicle Stability Control              |

**A**

**A/C**

- Air conditioning filter ..... 668
- Front air conditioning system ..... 328, 337
- Rear air conditioning system ..... 351

**ABS.....285**

**ACCESSORY mode .....161**

**Adaptive front-lighting system..... 196**

**Advanced parking guidance system.....244**

**AFS .....196**

**Air conditioning filter .....668**

**Air conditioning system**

- Air conditioning filter ..... 668
- Front air conditioning system ..... 328, 337
- Rear air conditioning system ..... 351

**Airbags**

- Airbag operating conditions.....123
- Airbag precautions for your child.....127
- Airbag warning light .....704
- Curtain shield airbag operating conditions.....124
- Curtain shield airbag precautions .....127
- Front passenger occupant classification system.....132
- General airbag precautions .....127
- Locations of airbags.....119
- Modification and disposal of airbags .....131
- Proper driving posture.....117, 127
- Side airbag operating conditions.....124
- Side airbag precautions .....127
- SRS airbags .....119

**Alarm.....114**

**Antenna.....368**

**Anti-lock brake system.....285**

**Armrest .....587**

**Ashtrays.....575**

**Audio input.....383, 458**

**Audio system**

- Antenna.....368
- Audio input.....383, 458
- Audio visual input.....499
- AUX adapter .....383, 458
- A/V input adapter .....499
- CD player/changer .....369, 402
- DVD player.....399, 478, 479
- iPod® player .....446
- MP3/WMA disc.....375
- Optimal use .....381, 456
- Portable music player.....383, 458
- Radio .....365, 390
- Rear seat audio system .....459
- Rear seat entertainment system.....468
- Steering wheel audio switch.....384
- USB memory player .....446

**Audio visual input.....499**

**Automatic air conditioning system**

- Air conditioning filter .....668
- Front air conditioning system.....328, 337
- Rear air conditioning system.....351

**Automatic headlight leveling**

**system .....197**

**Automatic high beam .....198**

**Automatic light control system.....195**

**Automatic transmission**

- Automatic transmission .....165, 169

|                                                     |          |
|-----------------------------------------------------|----------|
| If the shift lever cannot be shifted from "P" ..... | 725      |
| M mode .....                                        | 173      |
| S mode .....                                        | 167      |
| <b>AUX adapter</b> .....                            | 383, 458 |
| <b>Auxiliary box</b>                                |          |
| Auxiliary box .....                                 | 568      |
| Non smokers box .....                               | 563      |
| <b>A/V input adapter</b> .....                      | 499      |

**B**

|                                               |     |
|-----------------------------------------------|-----|
| <b>Back-up lights</b>                         |     |
| Replacing light bulbs .....                   | 680 |
| Wattage .....                                 | 751 |
| <b>Battery</b>                                |     |
| Checking .....                                | 650 |
| If the vehicle has a discharged battery ..... | 732 |
| Preparing and checking before winter .....    | 305 |
| <b>Bluetooth® audio</b> .....                 | 434 |
| <b>Bluetooth® phone</b> .....                 | 503 |
| <b>Brake</b>                                  |     |
| Brake hold .....                              | 180 |
| Fluid .....                                   | 648 |
| Parking brake .....                           | 177 |
| <b>Brake assist</b> .....                     | 285 |
| <b>Brake hold</b> .....                       | 180 |
| <b>Break-in tips</b> .....                    | 153 |

**C**

|                             |          |
|-----------------------------|----------|
| <b>Care</b>                 |          |
| Exterior .....              | 620      |
| Interior .....              | 623      |
| Seat belts .....            | 624      |
| <b>Cargo capacity</b> ..... | 300      |
| <b>Cargo hooks</b> .....    | 600      |
| <b>CD changer</b> .....     | 369, 402 |

|                                                      |          |
|------------------------------------------------------|----------|
| <b>CD player</b> .....                               | 369, 402 |
| <b>Chains</b> .....                                  | 305      |
| <b>Child restraint system</b>                        |          |
| Booster seats, definition .....                      | 137      |
| Booster seats, installation .....                    | 145      |
| Convertible seats, definition .....                  | 137      |
| Convertible seats, installation .....                | 145      |
| Front passenger occupant classification system ..... | 132      |
| Infant seats, definition .....                       | 137      |
| Infant seats, installation .....                     | 145      |
| Installing CRS with LATCH system .....               | 143      |
| Installing CRS with seat belts .....                 | 145      |
| Installing CRS with top tether straps .....          | 148      |
| <b>Child safety</b>                                  |          |
| Airbag precautions .....                             | 127      |
| Battery precautions .....                            | 651, 734 |
| Child restraint system .....                         | 137      |
| Child-protectors .....                               | 54       |
| Heated steering wheel precautions .....              | 582      |
| How your child should wear the seat belt .....       | 95       |
| Installing child restraints .....                    | 142      |
| Moon roof precautions .....                          | 108      |
| Power window lock switch .....                       | 103      |
| Power window precautions .....                       | 104      |
| Removed electronic key battery precautions .....     | 672      |
| Seat belt comfort guide .....                        | 93       |
| Seat belt extender precautions .....                 | 97       |
| Seat belt precautions .....                          | 96       |
| Seat heater precautions .....                        | 586      |
| Trunk precautions .....                              | 61       |
| <b>Child-protectors</b> .....                        | 54       |

|                                   |     |
|-----------------------------------|-----|
| Cigarette lighter.....            | 576 |
| Cleaning                          |     |
| Exterior .....                    | 620 |
| Interior.....                     | 623 |
| Seat belts.....                   | 624 |
| Climate control seat.....         | 583 |
| Climate control seat filter.....  | 670 |
| Clock .....                       | 572 |
| Coat hooks.....                   | 598 |
| Coin holder .....                 | 559 |
| Compass .....                     | 608 |
| Condenser .....                   | 648 |
| Console box .....                 | 562 |
| Cool box.....                     | 564 |
| Cooling system                    |     |
| Engine overheating.....           | 735 |
| Cornering assist sensors .....    | 223 |
| Cruise control                    |     |
| Cruise control.....               | 208 |
| Dynamic radar cruise control..... | 212 |
| Cup holders .....                 | 560 |
| Curtain shield airbags.....       | 119 |
| Customizable features .....       | 766 |

|                                             |     |
|---------------------------------------------|-----|
| <b>D</b> Daytime running light system ..... | 196 |
| Defogger                                    |     |
| Rear window.....                            | 359 |
| Side mirrors.....                           | 359 |
| Dimensions.....                             | 740 |
| Dinghy towing .....                         | 310 |
| Display                                     |     |
| Dynamic radar cruise control.....           | 212 |
| Multi-information display.....              | 190 |
| Touch screen.....                           | 314 |
| Trip information.....                       | 191 |
| Warning message.....                        | 712 |

|                                        |               |
|----------------------------------------|---------------|
| Do-it-yourself maintenance.....        | 632           |
| Door courtesy lights                   |               |
| Door courtesy lights.....              | 552           |
| Wattage.....                           | 751           |
| Door pockets .....                     | 559           |
| Doors                                  |               |
| Door windows.....                      | 103           |
| Door lock .....                        | 36, 50, 53    |
| Side mirrors.....                      | 101           |
| Driver's seat belt reminder light..... | 706           |
| Driving                                |               |
| Break-in tips.....                     | 153           |
| Correct posture.....                   | 117           |
| Procedures.....                        | 152           |
| Winter driving tips.....               | 305           |
| Driving position memory.....           | 81            |
| DVD player.....                        | 399, 478, 479 |

|                                                         |          |
|---------------------------------------------------------|----------|
| <b>E</b> Eco mode.....                                  | 166, 171 |
| Electric power steering.....                            | 285      |
| Electronic key                                          |          |
| If the electronic key does not<br>operate properly..... | 728      |
| Electronically modulated air<br>suspension.....         | 239      |
| Emergency flashers                                      |          |
| Switch.....                                             | 692      |
| Emergency, in case of                                   |          |
| If a warning buzzer sounds.....                         | 703      |
| If a warning light turns on.....                        | 703      |
| If a warning message is<br>displayed.....               | 712      |
| If the electronic key does not<br>operate properly..... | 728      |
| If the engine will not start.....                       | 723      |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>If the parking brake cannot be released .....726</p> <p>If the shift lever cannot be shifted from "P" .....725</p> <p>If the vehicle has a discharged battery.....732</p> <p>If you have a flat tire .....715</p> <p>If you lose your keys .....35</p> <p>If you think something is wrong.....699</p> <p>If your vehicle becomes stuck ....738</p> <p>If your vehicle needs to be towed.....693</p> <p>If your vehicle overheats.....735</p> <p><b>Engine</b></p> <p>Accessory mode .....161</p> <p>Compartment.....638</p> <p>Engine switch .....161</p> <p>Hood .....635</p> <p>How to start the engine.....161</p> <p>Identification number.....741</p> <p>If the engine will not start.....723</p> <p>Ignition switch.....161</p> <p>Overheating.....735</p> <p>Engine compartment cover.....640</p> <p>Engine coolant</p> <p>Capacity.....745</p> <p>Checking .....646</p> <p>Preparing and checking before winter .....305</p> <p>Engine coolant temperature gauge .....183</p> <p>Engine immobilizer system.....112</p> <p>Engine oil</p> <p>Capacity.....744</p> <p>Checking .....642</p> | <p>Preparing and checking before winter .....305</p> <p>Engine oil maintenance data.....645</p> <p>Engine switch .....161</p> <p>EPS .....285</p> <p>Event data recorder .....701</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>F</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <p>First-aid kit storage belt .....600</p> <p>Floor mat .....599</p> <p>Fluid</p> <p>Brake.....648</p> <p>Washer .....653</p> <p>Fog lights</p> <p>Replacing light bulbs.....680</p> <p>Switch.....203</p> <p>Wattage.....751</p> <p>Footwell lighting.....552</p> <p>Front fog lights</p> <p>Replacing light bulbs.....680</p> <p>Switch.....203</p> <p>Wattage.....751</p> <p>Front passenger occupant classification system .....132</p> <p>Front passenger's seat belt reminder light.....706</p> <p>Front seats</p> <p>Adjustment.....65</p> <p>Driving position memory .....81</p> <p>Power easy access system .....84</p> <p>Seat position memory .....81</p> <p>Front turn signal lights</p> <p>Wattage.....751</p> <p>Fuel</p> <p>Capacity .....743</p> <p>Fuel gauge.....183</p> <p>Fuel pump shut off system.....700</p> |

|                                |     |
|--------------------------------|-----|
| Information.....               | 752 |
| Refueling .....                | 109 |
| Type.....                      | 743 |
| Fuel door .....                | 109 |
| Fuel filler door .....         | 109 |
| Fuel pump shut off system..... | 700 |
| Fuses .....                    | 673 |

|                                   |     |
|-----------------------------------|-----|
| <b>G</b> Garage door opener ..... | 602 |
| Gauges .....                      | 183 |
| Glove box .....                   | 558 |

|                                                                   |     |
|-------------------------------------------------------------------|-----|
| <b>H</b> Hands-free system<br>(for cellular phone) .....          | 503 |
| Hazard lights<br>Switch .....                                     | 692 |
| Head restraints<br>Active head restraint.....                     | 68  |
| Adjustment .....                                                  | 89  |
| Headlight aim .....                                               | 678 |
| Headlight cleaner .....                                           | 207 |
| Headlights<br>Automatic high beam.....                            | 198 |
| Discharge headlight<br>precautions .....                          | 689 |
| Replacing light bulbs.....                                        | 680 |
| Switch .....                                                      | 195 |
| Wattage.....                                                      | 751 |
| Heaters<br>Seat heaters.....                                      | 583 |
| Side mirrors.....                                                 | 359 |
| Steering wheel .....                                              | 581 |
| Height control<br>Electronically modulated air<br>suspension..... | 239 |
| Hill-start assist control .....                                   | 285 |

|                     |     |
|---------------------|-----|
| Hood.....           | 635 |
| Hooks<br>Cargo..... | 600 |
| Coat.....           | 598 |
| Shopping bag .....  | 600 |
| Horn.....           | 182 |

|                                |     |
|--------------------------------|-----|
| <b>I</b> I/M test .....        | 631 |
| Identification<br>Engine.....  | 741 |
| Vehicle.....                   | 741 |
| Ignition switch .....          | 161 |
| Illuminated entry system.....  | 552 |
| Indicator lights .....         | 186 |
| Inside rear view mirror .....  | 100 |
| Interior lights<br>Switch..... | 553 |
| Wattage.....                   | 751 |

|                                                 |     |
|-------------------------------------------------|-----|
| <b>J</b> Jack<br>Positioning a floor jack ..... | 636 |
| Vehicle-equipped jack.....                      | 715 |
| Jack handle .....                               | 715 |

|                                                         |     |
|---------------------------------------------------------|-----|
| <b>K</b> Keyless entry .....                            | 50  |
| Keys<br>Electronic key .....                            | 32  |
| Engine switch .....                                     | 161 |
| If the electronic key does not<br>operate properly..... | 728 |
| If you lose your keys .....                             | 35  |
| Ignition switch .....                                   | 161 |
| Key number.....                                         | 32  |
| Keyless entry.....                                      | 50  |
| Keys.....                                               | 32  |

|          |                                         |          |                                               |
|----------|-----------------------------------------|----------|-----------------------------------------------|
|          | Mechanical key .....33                  |          | Micro dust and<br>pollen filter..... 332, 346 |
|          | Wireless remote control key.....50      |          | Mirrors                                       |
| <b>L</b> | Lane-keeping assist .....232            |          | Inside rear view mirror .....100              |
|          | Lexus enform*                           |          | Side mirror heaters ..... 359                 |
|          | Light bulbs                             |          | Side mirrors .....101                         |
|          | Replacing..... 680                      |          | Vanity mirrors.....571                        |
|          | Wattage .....751                        |          | Moon roof.....105                             |
|          | Lights                                  |          | MP3 disc .....375, 402, 482                   |
|          | Door courtesy lights .....552           |          | Multi-information display .....190            |
|          | Emergency flasher switch.....692        | <b>N</b> | Noise from under vehicle..... 28              |
|          | Fog light switch.....203                | <b>O</b> | Odometer.....183                              |
|          | Hazard light switch.....692             |          | Oil                                           |
|          | Headlight switch .....195               |          | Engine oil.....642                            |
|          | Interior light switch.....553           |          | Opener                                        |
|          | Outer foot lights.....552               |          | Fuel filler door .....109                     |
|          | Overhead courtesy light .....552        |          | Hood.....635                                  |
|          | Personal light switch .....554          |          | Trunk ..... 58                                |
|          | Replacing light bulbs ..... 680         |          | Outer foot lights                             |
|          | Shift lever lighting .....552           |          | Outer foot lights .....552                    |
|          | Turn signal lever.....176               |          | Wattage.....751                               |
|          | Vanity lights.....571                   |          | Outside rear view mirrors                     |
|          | Wattage .....751                        |          | Adjusting and folding.....101                 |
|          | LKA.....232                             |          | Mirror position memory.....81                 |
|          | Load capacity .....303                  |          | Outside temperature                           |
| <b>M</b> | Maintenance                             |          | display .....191, 574                         |
|          | Do-it-yourself maintenance ..... 632    |          | Overhead console ..... 568                    |
|          | General maintenance.....628             |          | Overhead courtesy lights                      |
|          | Maintenance data .....740               |          | Overhead courtesy lights.....552              |
|          | Maintenance requirements.....626        |          | Wattage.....751                               |
|          | Meter                                   |          | Overheating, Engine..... 735                  |
|          | Instrument panel light control .....184 |          |                                               |
|          | Meters.....183                          |          |                                               |

\*: Refer to the "Navigation System Owner's Manual"

|          |                                              |          |
|----------|----------------------------------------------|----------|
| <b>P</b> | Paddle shift switches .....                  | 172, 173 |
|          | Parking assist sensors .....                 | 223      |
|          | Parking brake .....                          | 177      |
|          | Parking lights                               |          |
|          | Switch .....                                 | 195      |
|          | Wattage.....                                 | 751      |
|          | PCS .....                                    | 291      |
|          | Pelvic support seat with seat vibrator ..... | 76       |
|          | Penlight .....                               | 716      |
|          | Personal lights                              |          |
|          | Switch .....                                 | 554      |
|          | Power easy access system.....                | 84       |
|          | Power outlet.....                            | 578      |
|          | Power windows .....                          | 103      |
|          | Pre-collision system.....                    | 291      |
| <b>R</b> | Radar cruise control.....                    | 212      |
|          | Radiator .....                               | 648      |
|          | Radio .....                                  | 365, 390 |
|          | Radio data system .....                      | 367      |
|          | RDS .....                                    | 367      |
|          | Rear seat                                    |          |
|          | Adjustment.....                              | 71       |
|          | Seat position memory .....                   | 87       |
|          | Rear seat entertainment system .....         | 468      |
|          | Rear seat relaxation system .....            | 77       |
|          | Rear sunshade .....                          | 590      |
|          | Rear turn signal lights                      |          |
|          | Replacing light bulbs.....                   | 680      |
|          | Wattage.....                                 | 751      |
|          | Rear view mirror                             |          |
|          | Compass .....                                | 608      |
|          | Rear view monitor system.....                | 241      |
|          | Rear window defogger.....                    | 359      |

|                                   |        |
|-----------------------------------|--------|
| Replacing                         |        |
| Electronic key battery.....       | 671    |
| Fuses.....                        | 673    |
| Light bulbs .....                 | 680    |
| Tires.....                        | 715    |
| Reporting safety defects for      |        |
| U.S. owners.....                  | 778    |
| Retractable table .....           | 588    |
| <b>S</b>                          |        |
| Safety connect .....              | 612    |
| Seat belts                        |        |
| Adjusting the seat belt .....     | 93     |
| Automatic locking retractor ..... | 94     |
| Child restraint system            |        |
| installation .....                | 142    |
| Cleaning and maintaining          |        |
| the seat belts .....              | 624    |
| Emergency locking retractor ..... | 94     |
| How to wear your seat belt .....  | 92     |
| How your child should wear        |        |
| the seat belt.....                | 95     |
| Pregnant women,                   |        |
| proper seat belt use .....        | 94     |
| Reminder light.....               | 706    |
| Seat belt extenders.....          | 95     |
| Seat belt pretensioners .....     | 93     |
| Seat cushion airbag .....         | 119    |
| Seat heaters.....                 | 583    |
| Seat position memory.....         | 81, 87 |
| Seating capacity.....             | 303    |

## Seats

|                                     |        |
|-------------------------------------|--------|
| Adjustment .....                    | 65, 71 |
| Adjustment                          |        |
| precautions .....                   | 69, 79 |
| Child seats/child restraint         |        |
| system installation .....           | 142    |
| Cleaning .....                      | 623    |
| Climate control .....               | 583    |
| Climate control seat .....          | 583    |
| Driver's seat position memory ..... | 81     |
| Front passenger's seat              |        |
| position memory .....               | 81     |
| Head restraint .....                | 89     |
| Pelvic support seat with seat       |        |
| vibrator .....                      | 76     |
| Power easy access system .....      | 84     |
| Properly sitting in the seat .....  | 117    |
| Rear seat position memory .....     | 87     |
| Rear seat relaxation system .....   | 77     |
| Seat heaters .....                  | 583    |
| Seat position memory .....          | 81, 87 |

## Service reminder indicators .....186

## Shift lever

|                              |          |
|------------------------------|----------|
| Automatic transmission ..... | 165, 169 |
| If the shift lever cannot be |          |
| shifted from "P" .....       | 725      |

## Shift lever lighting .....552

## Shift lock system .....725

## Shopping bag hooks .....600

## Side airbags .....119

## Side marker lights

|              |     |
|--------------|-----|
| Switch ..... | 195 |
|--------------|-----|

## Side mirror

|                              |     |
|------------------------------|-----|
| Adjusting and folding .....  | 101 |
| Mirror position memory ..... | 81  |

## Smart access system with

### push-button start

|                           |     |
|---------------------------|-----|
| Entry function .....      | 36  |
| Starting the engine ..... | 161 |

## "SOS" button .....612

## Spare tire

|                          |     |
|--------------------------|-----|
| Inflation pressure ..... | 662 |
| Storage location .....   | 715 |

## Spark plug .....746

## Specifications .....740

## Speedometer .....183

## Steering wheel

|                                |     |
|--------------------------------|-----|
| Adjustment .....               | 99  |
| Audio switches .....           | 384 |
| Heated steering wheel .....    | 581 |
| Lock release .....             | 163 |
| Power easy access system ..... | 84  |
| Steering wheel position        |     |
| memory .....                   | 81  |

## Storage feature .....556

## Stuck vehicle

|                                     |     |
|-------------------------------------|-----|
| If your vehicle becomes stuck ..... | 738 |
|-------------------------------------|-----|

## Sun visors .....570

## Sunshades

|                 |     |
|-----------------|-----|
| Rear .....      | 590 |
| Rear door ..... | 593 |
| Roof .....      | 106 |

## Switch

|                                    |          |
|------------------------------------|----------|
| APGS pre-support switch .....      | 246      |
| Automatic high beam .....          | 198      |
| Eco mode switch .....              | 166, 171 |
| ECT switch .....                   | 166, 171 |
| Emergency flasher switch .....     | 692      |
| Engine switch .....                | 161      |
| Fog light switch .....             | 203      |
| Hazard light switch .....          | 692      |
| Heated steering wheel switch ..... | 581      |

|                                   |          |
|-----------------------------------|----------|
| Ignition switch.....              | 161      |
| Light switches.....               | 195      |
| Paddle shift switches.....        | 172, 173 |
| Parking brake switch.....         | 177      |
| Power door lock switch.....       | 53       |
| Power trunk opener and closer.... | 58       |
| Power window switch.....          | 103      |
| Window lock switch.....           | 103      |
| Wiper and washer switch.....      | 204      |

## **T** Tachometer..... 183

### **Tail lights**

|             |     |
|-------------|-----|
| Switch..... | 195 |
|-------------|-----|

### **Theft deterrent system**

|                                |     |
|--------------------------------|-----|
| Alarm.....                     | 114 |
| Engine immobilizer system..... | 112 |

### **Tire inflation pressure ..... 662**

### **Tire information**

|                                   |     |
|-----------------------------------|-----|
| Glossary.....                     | 760 |
| Size.....                         | 757 |
| Tire identification number.....   | 756 |
| Uniform tire quality grading..... | 758 |

### **Tires**

|                                      |          |
|--------------------------------------|----------|
| Chains.....                          | 305      |
| Checking.....                        | 654      |
| If you have a flat tire.....         | 715      |
| Inflation pressure.....              | 662      |
| Information.....                     | 755      |
| Replacing.....                       | 715      |
| Rotating tires.....                  | 654      |
| Size.....                            | 749      |
| Snow tires.....                      | 305      |
| Spare tire.....                      | 715      |
| Tire pressure warning<br>system..... | 654, 706 |

## **Tools..... 715**

## **Total load capacity ..... 303**

## **Touch screen..... 314**

### **Towing**

|                       |     |
|-----------------------|-----|
| Dinghy towing.....    | 310 |
| Emergency towing..... | 693 |
| Trailer towing.....   | 309 |

## **TRAC ..... 285**

## **Traction control..... 285**

## **Trip meter ..... 183**

### **Trunk**

|                        |     |
|------------------------|-----|
| Closer.....            | 58  |
| Extending a space..... | 596 |
| Opener.....            | 58  |

### **Trunk light**

|              |     |
|--------------|-----|
| Wattage..... | 751 |
|--------------|-----|

### **Turn signal lights**

|                            |     |
|----------------------------|-----|
| Replacing light bulbs..... | 680 |
| Switch.....                | 176 |
| Wattage.....               | 751 |

## **V** Vanity lights

|                    |     |
|--------------------|-----|
| Vanity lights..... | 571 |
| Wattage.....       | 751 |

## **Vanity mirrors ..... 571**

## **Variable gear ratio steering..... 285**

## **VDIM..... 285**

### **Vehicle dynamics integrated**

|                 |     |
|-----------------|-----|
| management..... | 285 |
|-----------------|-----|

## **Vehicle identification number ..... 741**

## **Vehicle stability control ..... 285**

## **VGRS..... 285**

## **VSC ..... 285**

**W**

**Warning buzzers**

|                          |     |
|--------------------------|-----|
| Master warning .....     | 706 |
| Open door .....          | 706 |
| Seat belt reminder ..... | 706 |

**Warning lights**

|                                           |          |
|-------------------------------------------|----------|
| Anti-lock brake system .....              | 704      |
| Brake assist system .....                 | 704      |
| Brake system .....                        | 703, 704 |
| Charging system .....                     | 703      |
| Electric power steering .....             | 704      |
| Electronic engine control<br>system ..... | 704      |
| Low fuel level .....                      | 706      |
| Malfunction indicator lamp .....          | 704      |
| Master warning .....                      | 706      |
| Open door .....                           | 706      |
| Pre-collision system .....                | 704      |
| Pretensioners .....                       | 704      |
| Seat belt reminder .....                  | 706      |
| Slip indicator .....                      | 704      |
| SRS airbags .....                         | 704      |
| Tire pressure .....                       | 706      |

**Warning messages..... 712**

**Washer**

|                                               |     |
|-----------------------------------------------|-----|
| Checking .....                                | 653 |
| Preparing and checking<br>before winter ..... | 305 |
| Switch .....                                  | 204 |

**Washing and waxing ..... 620**

**Weight**

|                      |     |
|----------------------|-----|
| Cargo capacity ..... | 300 |
| Load limits .....    | 303 |
| Weight .....         | 740 |

**Wheels ..... 666**

**Window lock switch..... 103**

**Windows**

|                            |     |
|----------------------------|-----|
| Power windows .....        | 103 |
| Rear window defogger ..... | 359 |
| Washer .....               | 204 |

**Windshield wiper de-icer..... 361**

**Windshield wipers..... 204**

**Wireless remote control key**

|                               |     |
|-------------------------------|-----|
| Replacing the battery .....   | 671 |
| Wireless remote control ..... | 50  |

**WMA disc ..... 375, 402, 482**

What to do if...  
What to do if...



A tire punctures

P. 715 If you have a flat tire



The engine does not start

P. 723 If the engine will not start

P. 112 Engine immobilizer system

P. 732 If the battery is discharged



The shift lever cannot be moved out

P. 725 If the shift lever cannot be shifted from "P"



The engine coolant temperature gauge enters the red zone

P. 735 If your vehicle overheats



Steam can be seen coming from under the hood



The key is lost

P. 35 If you lose your keys



The battery runs out

P. 732 If the battery is discharged



The doors cannot be locked

P. 53 Doors



The horn begins to sound

P. 114 Alarm



The vehicle is stuck in mud or sand

P. 738 If the vehicle becomes stuck



A warning light or indicator light comes on

P. 703

If a warning light turns on or a warning buzzer sounds...



## ■ Warning lights



Brake system warning light (red indicator)

or



P. 703



Malfunction indicator lamp

or



P. 704



"ABS" warning light

or



P. 704



Driver's seat belt reminder light

P. 706



Front passenger's seat belt reminder light

P. 706



Brake system warning light (yellow indicator)

P. 704



Master warning light with warning message

P. 706



Low fuel level warning light

P. 706



Electric power steering system warning light

P. 704



SRS warning light

P. 704



Pre-collision system warning light

P. 704



Open door warning light

P. 706



Tire pressure warning light

P. 706



Charging system warning light


P. 703



Slip indicator

P. 704

## GAS STATION INFORMATION



|                                           |                                                                                                                                    |                |
|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|----------------|
| Fuel tank capacity                        | 22.1 gal. (84 L, 18.4 Imp. gal.)                                                                                                   |                |
| Fuel type                                 | Unleaded gasoline only                                                                                                             | P. 110, 743    |
| Cold tire inflation pressure              |                                                                                                                                    | P. 749         |
| Engine oil capacity<br>(Drain and refill) | qt. (L, Imp. qt.)                                                                                                                  |                |
|                                           | With filter                                                                                                                        |                |
|                                           | 2WD models                                                                                                                         | 9.1 (8.6, 7.6) |
|                                           | AWD models                                                                                                                         | 9.5 (9.0, 7.9) |
|                                           | Without filter                                                                                                                     | 8.9 (8.4, 7.4) |
| Engine oil type                           | Toyota Genuine Motor Oil or equivalent<br>Oil grade: ILSAC multigrade engine oil<br>Recommended oil viscosity: SAE-5W-20 or -0W-20 |                |
|                                           |                                                                                                                                    | P. 744         |



Owner's Manual:  
Publication No. OM50A76U  
Part No. 01999-50A76  
Printed in Japan 02-0911-01 I  
LS 460 / LS 460 L (北米U)