

**Toyota and Lexus Carpeted / All-Weather Floor Mat Inspection, Application and Installation Instructions**




**Read these important Warnings BEFORE installing ANY type of Floor Mat.**

**A. General Floor Mat Warnings**

- Only install floor mats designed specifically for that model and model year.
  - Never install a floor mat if you are uncertain of the model application
  - Never install the floor mat upside down or turned over for any reason.
  - Only install the proper, designated driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with carpet floor mats. Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
  - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time
  - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation


**B. Floor Mat Inspection Instructions and Application Information**

- Before placing a floor mat in a vehicle be familiar with the procedure outlined below.
- Identify the correct driver's floor mat for the specific vehicle application
- Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).



Ensure the retainer clip is properly installed and secure into the eyelet(s) located in the driver's foot well

Make sure the floor mat is properly secured by the retaining hooks (clips)



Check:  
Accelerator pedal  
Brake Pedal  
Clutch pedal (if equipped)

Confirm that the retaining hooks (clips) are secured and have a grasp of the mat.

Check the pedal operation (fully depress the pedal) to assure the floor mat does not interfere with it. Make sure the vehicle is turned off and in the 'Park' position when testing.